

# The **FLEX-5000**<sup>™</sup> Series

HF-6m Transceivers

# Owner's Manual

Version 1.14.0

SOFTWARE DEFINED RADIO

# The FLEX-5000 Series Owner's Manual

---

© 2003–2008 FlexRadio Systems®  
All Rights Reserved

Reproduction of this document in any form is expressly forbidden unless explicitly authorized by FlexRadio Systems.

Information contained in this document may contain technical inaccuracies or typographical errors. Information may be changed or updated without notice. FlexRadio Systems may make improvements and/or changes in the materials at any time without notice.

All materials are provided "as is". FlexRadio Systems makes no representations or warranties, expressed or implied to the accuracy of the copyrighted materials. FlexRadio Systems will not be liable for any direct, indirect, special or consequential damages arising out of any use of the document.

FlexRadio Systems is a registered trademark of Bronze Bear Communications, Inc. DBA FlexRadio Systems.

The FlexRadio Systems Waves Design (logo), SDR-1000, FLEX-5000 and the FLEX-5000 logo, FlexWire, ClickTune, MultiRX, PanaFall and PanaScope are trademarks of FlexRadio Systems.

FlexRadio Systems  
13091 Pond Springs Rd #250 • Austin, TX 78729  
Phone: (512) 535-4713 • Fax: (512) 233-5143  
Email: sales@flex-radio.com

**Editor: Joe de Groot – AB1DO**

**Printer/Distributor: Peter Markavage - WA2CWA**

# Table of Contents

<b>PREFACE</b> .....	<b>XI</b>
<b>ACKNOWLEDGMENTS</b> .....	<b>XIII</b>
<b>USING THIS MANUAL IN ITS PDF FORM</b> .....	<b>XV</b>
<b>1 HARDWARE INSTALLATION</b> .....	<b>1</b>
<b>UNPACKING AND DECIDING ON A LOCATION</b> .....	<b>2</b>
Contents of the Carton.....	2
Location Considerations.....	3
<b>PHYSICAL CONNECTIONS</b> .....	<b>3</b>
Front Panel.....	4
(1) LED Push Button Power Switch.....	4
(2) Headphone Jack.....	5
(3) Microphone Connector.....	5
(4) Internal Speaker (FLEX-5000C Only).....	6
Back Panel.....	6
(1) Primary Antenna Ports (ANT1, ANT2 & ANT3).....	7
(2)-(3) Receive Only Antenna Ports (RX1 IN & RX2 IN).....	7
(2) External RX1 OUT to RX1 IN Receive Loop.....	7
(4)-(5) Dedicated Transverter Connections.....	7
(6) 13.8 VDC Power Socket.....	7
(7) Dual IEEE 1394 FireWire® Jacks.....	8
(8) Straight Key or Paddles (KEY).....	8
(9) External Keying Lines (AMP RLY TX1, TX2 & TX3).....	9
(10) External Frequency Reference Input.....	9
(11) Powered Speaker/Line Out Jack.....	10
(12) FlexWire™ Peripheral Interface Bus.....	10
(13) Line-Out and Line-In Audio Jacks.....	11
(14) Balanced Line Input.....	11
Connecting to a Balanced XLR Connector.....	11
(15) PTT Jack.....	12
(16) RF Ground Terminal.....	12
FLEX-5000C Computer Connections.....	13
Wireless Keyboard and Mouse.....	13
FireWire Cable.....	13
Monitor or LCD Display.....	13

## TABLE OF CONTENTS

Computer Speakers.....	13
Network Connection.....	14
<b>INSTALLING THE FLEX-5000C.....</b>	<b>14</b>
Power-up and Connect Keyboard and Mouse.....	14
Set up and Configure the Computer.....	15
Set Your Time Zone and the System Date/Time.....	16
Reference Documents.....	16
Installer Library.....	16
Hard Drive Restore Process.....	16
<b>INSTALLING THE FLEX-5000A.....</b>	<b>18</b>
Switch Off the FLEX-5000A and Install the FireWire Driver.....	18
Power Up the FLEX-5000A.....	23
Configuring the Driver with the FLEX-5000 Control Panel.....	26
<i>Sampling Rate and Buffer Size</i> .....	27
<i>Operation Mode</i> .....	29
DPC Latency Checker.....	30
<b>2 POWERSDR INSTALLATION &amp; SETUP.....</b>	<b>33</b>
<b>UPGRADING FROM AN EARLIER VERSION.....</b>	<b>33</b>
<b>POWERSDR INSTALLATION.....</b>	<b>33</b>
<b>POWERSDR SETUP WIZARD.....</b>	<b>38</b>
<b>INITIAL POWERSDR CONFIGURATION.....</b>	<b>43</b>
Transfer of Calibration Data.....	43
Audio Parameters.....	44
Antenna Port and External Keying Lines.....	45
Audio Mixer.....	46
<b>COMPLETELY FACTORY CALIBRATED.....</b>	<b>47</b>
<b>3 FRONT CONSOLE.....</b>	<b>49</b>
<b>(1) VFO A.....</b>	<b>51</b>
<b>(2) TUNING CONTROLS.....</b>	<b>52</b>
<b>(3) VFO B.....</b>	<b>52</b>
<b>(4 AND 4B) MULTIMETERS.....</b>	<b>53</b>
RX1 and RX2 Meters.....	53
TX Meters.....	54
<b>(5 AND 5B) BAND SELECTION &amp; BAND STACKING MEMORIES.....</b>	<b>55</b>
<b>(6 AND 6B) MODE SELECTION.....</b>	<b>56</b>
<b>(7 AND 7B) FILTER CONTROLS.....</b>	<b>57</b>
Labeled Filter Buttons.....	57
Variable Filter Buttons.....	58
<b>(8) MODE SPECIFIC CONTROLS.....</b>	<b>59</b>
Phone Controls .....	59
CW Controls.....	60
Digital Controls.....	62
<b>(9 AND 9B) DISPLAY CONTROLS.....</b>	<b>62</b>
Screen Controls.....	63
Display Selection Controls.....	63
Display Type Descriptions.....	63
<i>Spectrum</i> .....	64
<i>Panadapter (Panoramic Adapter)</i> .....	64
<i>Histogram</i> .....	65

**TABLE OF CONTENTS**

*Waterfall*.....66  
*Scope*.....67  
*Phase*.....67  
*Panafall*.....68  
*Panascope*.....68  
*Off*.....68  
*RX2 Display*.....68  
*Cursor and Peak Position*.....68

**(10) MULTIRX CONTROLS.....69**  
**(11 AND 11B) DSP CONTROLS.....70**  
**(12) VFO CONTROLS.....71**  
**(13) CPU %.....72**  
**(14) START/STOP BUTTON.....72**  
**(15) MON (MONITOR).....72**  
**(16) MOX (MANUALLY OPERATED TRANSMIT).....73**  
**(17) MUT (MUTE).....73**  
**(18) REC (RECORD) AND PLAY.....73**  
**(19) TUN (TUNE).....73**  
**(20) ATU AND BYP.....74**  
**(21) AF (AUDIO FREQUENCY GAIN).....74**  
**(22 AND 22B) AGC-T (AGC MAXIMUM GAIN).....74**  
**(23) DRIVE (TRANSMITTER POWER OUTPUT/TUNE POWER).....74**  
**(24 AND 24B) AGC (AUTOMATIC GAIN CONTROL).....75**  
**(25 AND 25B) PREAMP.....75**  
**(26 AND 26B) SQL (SQUELCH).....75**  
**(27) ANTENNA SELECTION DISPLAY.....76**  
**(28) DATE/TIME DISPLAY.....76**  
**(29) RX2 ON/OFF.....76**  
**(30) RX2 AUDIO CONTROLS.....76**  
**(31) SETUP FORM.....77**  
**(32) – (39) OPERATING FORMS.....77**

**4 SETUP FORM.....79**

**GENERAL TAB.....81**  
 Hardware Config Sub-Tab.....81  
     FLEX-5000 Config.....81  
     Receive Only.....81  
     Radio Model.....82  
     DDS.....82  
 Options Sub-Tab.....83  
     Options.....84  
     Process Priority.....84  
     ClickTune Offsets (Hz).....85  
     Miscellaneous.....85  
     Keyboard.....86  
     Custom Title Text.....86  
 Calibration Sub-Tab.....87  
 Filters Sub-Tab.....88  
 RX2 Sub-Tab.....89

**AUDIO TAB.....90**  
 Primary Sub-Tab.....90  
     Buffer Size.....90  
     Sample Rate.....90  
     Mic Boost.....91

## TABLE OF CONTENTS

Expert.....	91
Latency (with Expert checked).....	91
<b>VAC Sub-Tab.....</b>	<b>92</b>
Virtual Audio Cable Setup.....	92
Gain (dB).....	92
Latency.....	93
Mono/Stereo.....	93
Combine VAC Input Channels.....	93
Auto Enable.....	93
Allow PTT to override/bypass VAC for Phone.....	93
Direct IQ.....	94
<b>DISPLAY TAB.....</b>	<b>95</b>
Spectrum Grid.....	96
Refresh Rates.....	96
Waterfall.....	97
Multimeter.....	97
Phase Resolution.....	98
Scope Time Base.....	98
Averaging.....	98
Polyphase FFT.....	98
<b>DSP TAB.....</b>	<b>99</b>
Options Sub-Tab.....	99
Noise Reduction.....	99
Automatic Notch Filter.....	100
Use Peak Readings for TX Meter DSP Values.....	100
Buffer Size.....	101
Noise Blanker.....	102
Noise Blanker 2.....	102
Window .....	102
Image Reject Sub-Tab.....	104
Expert.....	104
Receive Rejection.....	105
Transmit Rejection.....	105
Keyer Sub-Tab.....	106
CW Pitch.....	106
Connections.....	107
Options.....	107
Signal Shaping.....	108
Break In.....	108
AGC/ALC Sub-Tab.....	109
AGC.....	109
Leveler.....	110
ALC.....	110
<b>TRANSMIT TAB.....</b>	<b>111</b>
TX Profiles.....	111
Transmit Filter.....	112
DC Block.....	112
Tune.....	112
Noise Gate.....	113
VOX.....	113
Monitor.....	114
AM Carrier Level.....	114
Standard TX Profiles.....	114
<b>PA SETTINGS TAB.....</b>	<b>115</b>
Gain By Band (dB).....	115
<b>APPEARANCE TAB .....</b>	<b>116</b>
Display Sub-Tab.....	116
Overall Display.....	117
Cursor/Peak Readout.....	117
Panadapter.....	118
General Sub-Tab.....	119

**TABLE OF CONTENTS**

VFO.....120  
 Band Data.....120  
 Meter Sub-Tab.....121  
     Original Style.....122  
     Edge Style.....122  
**KEYBOARD TAB.....123**  
**CAT CONTROL TAB.....124**  
     Cat Control .....125  
     PTT Control.....126  
     DigL/U Returns LSB/USB.....126  
     FlexProfiler Installed.....126  
     Allow Kenwood AI Command.....126  
     Test.....127  
     RTTY Offset.....128  
**TESTS TAB.....129**  
     Two Tone Test:.....129  
     Audio Balance Test.....129  
     Signal Generator.....130  
     Enable HW Signal Generator.....131

**5 OPERATING FORMS.....133**

**(32) MEMORY FORM.....134**  
     Save... 134  
     Recall.....135  
**(33) WAVE FORM.....136**  
     Playback.....136  
     Playlist.....137  
     Record.....137  
     TX Gain (dB).....137  
     Quick Rec and Quick Play.....137  
     Record Options.....138  
         Receive.....138  
         Transmit.....138  
         Sample Rate.....138  
**(34) EQUALIZER FORM.....139**  
     3-Band Equalizer.....139  
     10-Band Equalizer.....140  
**(35) XVTRS FORM.....141**  
**(36) CWX FORM.....143**  
     Standard CWX Controls.....143  
         *CWX Memories*.....144  
         *Special Characters*.....144  
     Keyboard and Extended Controls.....145  
         *Extended CWX Controls*.....145  
         *Morse Definition Editor*.....146  
**(37) MIXER.....148**  
     Input.....148  
     Output.....148  
**(38) ANTENNA.....149**  
     Simple.....150  
     Expert.....151  
**(39) ATU.....153**  
     Operating Mode.....153  
     Tuning Options.....153  
     SWR Threshold.....154  
     Tuner Feedback.....154  
**VOLTAGE AND TEMPERATURE INFORMATION.....154**

**6 OPERATION.....155**

**POWER-UP PROCEDURE.....156**

**POWER-DOWN PROCEDURE.....157**

**TUNING METHODS.....158**

*Spectrum Drag and Click.....158*

*Mouse Wheel.....158*

*Mouse Wheel Hover.....158*

*Spectrum Click Tuning.....158*

*Keyboard Keys.....159*

*USB Tuning Knob.....159*

**VOICE TRANSMISSION OPERATION.....160**

**CW TRANSMISSION OPERATION.....164**

    Initial Settings.....165

    Internal Keyer.....166

    External Keyer.....168

    CWX Form.....168

    Third Party Program.....169

**DIGITAL MODE OPERATION.....172**

    CAT Control Setup.....175

*Install VCOM.....175*

*Configure the VCOM Port Pairs.....181*

*Configure PowerSDR CAT Control.....183*

*Configure PowerSDR Keyer Connections.....184*

    Virtual Sound Connection.....185

*Create the Virtual Audio Cables.....185*

*Setup VAC in PowerSDR.....187*

    Setting up Third Party Digital Programs.....188

*Using MixW with PowerSDR.....188*

*Programs Needing to Connect to the Default Sound Device.....192*

**7 SPECIFICATIONS AND ARCHITECTURE.....195**

**FLEX-5000A AND FLEX-5000C TRANSCEIVER SPECIFICATIONS.....195**

**FLEX-5000C EMBEDDED COMPUTER SPECIFICATIONS.....197**

**FLEX-5000 ARCHITECTURE.....198**

**DECLARATIONS OF CONFORMITY.....199**

    FCC.....199

    EU Compliance.....199

**A BUFFERS AND SAMPLE RATE.....201**

**FILTER EFFECTS.....201**

**LATENCY EFFECTS.....204**

**UNDERLYING THEORY.....204**

**B UPDATING THE FLEX-5000 FIRMWARE.....207**

**AUTOMATICALLY.....207**

**MANUALLY.....207**

    Download and Extract the Firmware.....207

    Update the Firmware.....208



**TABLE OF CONTENTS**

**C OPTIMIZING THE AGC.....211**

**D WINDOW FUNCTIONS.....213**

# Preface

Welcome to the exciting world of software defined radio. The FLEX-5000™<sup>1</sup> software defined transceiver is the culmination of many years of experience gained with FlexRadio's ground breaking SDR-1000™ transceiver. The experience gained and lessons learned have resulted in an SDR platform that is truly state of the art, offering unsurpassed Amateur Radio performance. And unlike most other transceivers, which once acquired, rarely if ever change, the FLEX-5000 will continue to (rapidly) evolve, offering future capabilities currently only dreamed of.

Although the rapid development of the FLEX-5000 can be exhilarating, it can also be somewhat daunting. When first confronted with an FLEX-5000 and its PowerSDR™ operating software, the sheer number of connections, controls, and settings can seem mind boggling even to the most seasoned Ham radio operator. This operating manual attempts to both guide a user step by step through the setup process (both hardware and software) and to act as a reference once the radio has been set up. Additionally, the freely downloadable PowerSDR software will install with default settings that, in most cases, will require little adjustment. Any adjustments that you make are automatically saved and can be imported into an updated version of the software.

Due to the nature of the FLEX-5000, the largest part of this operating manual, by far, will refer to software. The operating manual has numerous screenshots of windows and forms to detail the various steps. Although the manual describes the latest official release of the PowerSDR software, you may occasionally notice an earlier version identified in the title bar of a screenshot. This is because FlexRadio Systems® has decided to only update a screenshot if it changes. If you have any ideas on how to improve the FLEX-5000, please feel free to contact us, or better still, to join our email reflector (see <http://kc.flex-radio.com/KnowledgebaseArticle50024.aspx>). Not only is the FLEX-5000 a software defined radio; it is also a user defined radio.

FlexRadio Systems is committed to ensuring that your experience with the FLEX-5000 will be one of the most enjoyable you have with Ham radio. If you have any questions, issues or problems operating PowerSDR and/or the FLEX-5000, you may be able to find the solution on the Support Pages of our website (<http://support.flex-radio.com/>), in our Knowledge Center (<http://kc.flex-radio.com/search.aspx>), our Forum (<http://forums.flex-radio.com/>), or through our highly active email reflector (<http://kc.flex-radio.com/KnowledgebaseArticle50024.aspx>). If none of these sources provide you the assistance required, please contact FlexRadio Systems using the information provided on the Contact Page of our website (<http://www.flex-radio.com/About.aspx?topic=contactus>).

---

<sup>1</sup> FlexRadio Systems is a registered trademark of Bronze Bear Communications, Inc. DBA FlexRadio Systems. The FlexRadio Systems Waves Design (logo), SDR-1000, FLEX-5000 and the FLEX-5000 logo, FlexWire, ClickTune, MultiRX, PanaFall and PanaScope are trademarks of FlexRadio Systems.

# Acknowledgments

FlexRadio Systems could not be as successful, nor could the FLEX-5000 radio be what it is today without the many selfless contributions from our users all over the world. These contributions have spanned and continue to span improvements to our hardware and software, ranging from bug reports and feature requests to actual design and implementation of certain functionality.

Identifying contributors by name would only risk leaving out others with equally valuable contributions. We therefore wish to suffice with a heartfelt thank you for your support and continued commitment.

[The rest of this page has been left blank intentionally]

# Using This Manual in its PDF Form

If you are viewing this manual on your computer screen, you can use a combination of built-in features of Adobe® Reader<sup>®1</sup> as well as the many cross-references and hyperlinks within the text:

- ❑ To find a word within the manual, type **ctrl + F** on your keyboard (or in the menu click **Edit - Find**), enter the desired word in the text box that opens and click **Next**.
- ❑ To jump to a chapter or section in the manual, click on the corresponding Bookmark, shown to the left of this page. (If not shown, click on the vertical tab labeled **Bookmarks**). To make them as useful as possible, we have made the bookmarks very detailed.
- ❑ Click on the "Previous View" arrow to go back to a previously viewed page. (Alternatively, in the menu, click **View - Goto - Previous View**, or on your keyboard type **Alt + Left Arrow**).
  - Similarly click on the "Next View" arrow to go forward to a subsequently viewed page. (Alternatively, in the menu, click **View - Goto - Next View**, or on your keyboard type **Alt + Right Arrow**).
- ❑ Within the text there are many cross-references. Although not obvious, these are all hyperlinks within the manual. Click on the referenced **Table n**, **Figure n**, **above**, **below** or page **n** (bold indicates the hyperlink) and you will immediately jump to the referenced Table/Figure/page of the manual.
  - To return to where you came from, use the "Previous View" arrow.
- ❑ Within the text there are also external hyperlinks, shown in blue and underlined. Click on these to open your browser and view the referenced website page. Many of these relate to articles in our expansive Knowledge Center.
  - If the hyperlink has been previously clicked, it will be shown in magenta instead of blue.

[The rest of this page has been left blank intentionally]

---

<sup>1</sup> Adobe and Reader are registered trademarks of Adobe Systems, Inc.

# Hardware Installation

To install the Flex-5000, you will need to:

- ❑ Unpack and decide on a location
- ❑ Physically connect the radio to a power supply, antenna(s), microphone, key, etc. Although not necessary, you should preferably make all these connections in advance. However, you must at least connect the FLEX-5000 to a 13.8VDC power supply and connect the IEEE 1394 FireWire<sup>® 1</sup> cable.
- ❑ Configure the FLEX-5000:
  - **FLEX-5000C:** Set up and configuring the FLEX-5000C's computer.
  - **FLEX-5000A:** Install and configure the FLEX-5000 FireWire Driver This driver is required to enable the computer to interface with the FLEX-5000.

[The rest of this page has been left blank intentionally]

---

<sup>1</sup> FireWire and the FireWire logo are registered trademarks of Apple, Inc., under license.

# Unpacking and Deciding on a Location

## Contents of the Carton

Inside the carton you should find the following items:

*Table 1: Contents of Carton for each FLEX-5000 Model*

Item	FLEX-5000 Model	
	A	C
FLEX-5000 Transceiver	5000A	5000C
6-pin to 6-pin FireWire cable (6 feet) <sup>1</sup>	✓	✓
Unterminated 12 AWG power cable (4 feet)	✓	✓
T-20 Torx driver	✓	✓
Quick Start Guide	✓	✓
CD ROM/USB Flash Drive with Owner's manual, Installation & Configuration Guide, Quick Start Guide, PowerSDR 1.12 or later, FLEX 5000 FireWire Driver	✓	✓
Wireless keyboard and mouse		✓
2 AA and 2 AAA batteries (for keyboard and mouse)		✓
Keyboard installation CD		✓
Keyboard Instructions		✓
Microsoft® Windows® <sup>2</sup> XP Professional CD		✓
Acronis® <sup>3</sup> True Image License		✓

(Other items may be included that are not listed above)

The FLEX-5000 power cable is unterminated on one end so that you can adapt it to various DC power connectors, such as Anderson Power Poles, Banana plugs, screw terminals or spade lugs. Connect the 2 red wires to the positive terminal and the 2 black wires to the negative terminal of your power supply<sup>4</sup>.

**Note 1:** Do not apply power to the FLEX-5000 until you are instructed to do so.

**Note 2:** Retain the FLEX-5000 packaging for future use. This packaging was specially designed for the radio to prevent damage which may occur during shipping. If you ever need to ship your FLEX-5000 anywhere, especially back to FlexRadio Systems, this is the preferred packaging to use.

<sup>1</sup> For the FLEX-5000A, you may need to acquire a 4-pin to 6-pin cable if using a laptop

<sup>2</sup> Microsoft and Windows are registered trademarks of Microsoft Corporation

<sup>3</sup> Acronis is a registered trademark of Acronis, Inc.

<sup>4</sup> Older radios may have only 1 red and 1 black wire, which are connected to the + and - terminals respectively.

## Location Considerations

To facilitate integrating your FLEX-5000 into your shack you may want to consider the following:

- ❑ Place the FLEX-5000A in close proximity to your computer. It is best to use the shortest FireWire cable possible to connect to your computer to minimize data errors and limit possible RFI getting into the computer. High quality, quad-shielded FireWire cables up to 10m in length have been used successfully with the FLEX-5000.
- ❑ Ensure convenient access to the back panel. The FLEX-5000 back panel is where most of your connections will be made. Having easy access to the back panel without moving the transceiver is optimal while getting started.
- ❑ Avoid placing the FLEX-5000 in direct sunlight. Placing the transceiver in direct sunlight will increase the ambient temperature inside the chassis (especially while transmitting) and make the high volume cooling fan's job more difficult.
- ❑ Heed air flow requirements. Air is drawn in through the bottom air vent in the front of the FLEX-5000 and is exhausted through the top vent in the rear for optimal cooling. Do not block either the front intake or the rear exhaust vent since this will reduce the cooling efficiency.
- ❑ Avoid contact with liquids. Although this is usually not a problem unless you are operating maritime mobile, accidental spills of liquids in the shack on the FLEX-5000 could result in voiding the warranty. Placing the FLEX-5000 away from food and drinks is highly recommended.

## Physical Connections

To facilitate integrating the FLEX-5000 into your station, it is worth taking a moment to study the radio's front and back panels. The many antenna and audio connections are not immediately intuitive. This is a direct consequence of the FLEX-5000's versatility in accommodating many configurations, including receive-only antennas, external signal enhancing equipment and transverters, all of which can be assigned on a per band basis, without requiring complex external switching arrangements.

We will now discuss first the front panel and then the back panel connections<sup>1</sup>.

**Hint:** You can also visit the interactive virtual tour on our website of the FLEX-5000A [front panel](#) and [back panel](#) respectively (on our website select Products and then Interactive Virtual Tours), where you can hover over a connector with your mouse to pop up its description.

[The rest of this page has been left blank intentionally]

---

<sup>1</sup> Identifiers refer to the same controls and connectors on the FLEX-5000A and C models.

## Front Panel



Figure 1: FLEX-5000A (top) and FLEX-5000C (bottom) Front Panel

### (1) LED Push Button Power Switch

The FLEX-5000 uses a delayed start push button to power up the radio.

- ❑ To turn on the radio, push the button in fully and release. After a few seconds you will hear the power relay click and see the blue LED illuminate to indicate that the radio is powered up.
- ❑ To turn off the radio, again push the button fully and release.
- ❑ For the **FLEX-5000C** the power switch turns on both the radio and the computer, but only turns off the radio. To shut down the computer, click **Start** (bottom left of screen) and select **Turn Off Computer**.

**Note 1:** Make sure the FLEX-5000 is turned on and then wait 10-15 seconds before starting PowerSDR. Otherwise, PowerSDR will indicate a communication error and offer the option to run in Demo mode. Click **No** to close PowerSDR, turn on the FLEX-5000 and restart PowerSDR.



**Note 2:** Make sure PowerSDR is shut-down before turning off the radio. Otherwise, close PowerSDR and power cycle the FLEX-5000 (turn on, off and on again) and restart PowerSDR.

**(2) Headphone Jack**

Accepts headphones with standard 1/4" stereo (TRS) plug. Recommended ratings for headphones are 40 mW into 16 Ohm load (typ) with a 1% THD+N. Higher impedance headphones will also work.

**Note:** Lower impedance headphones and headphones using a mono plug can result in popping audio as soon as PowerSDR is started.

**(3) Microphone Connector**

The 8-pin microphone connector offers the ability to connect a microphone and to key the radio via a PTT line. The pin-out is shown in Table 2 below<sup>1</sup>. To engage PTT, pin 6 must be grounded to pin 5 (Shield Ground) and not to pin 7, which is the microphone ground.

*Table 2: Microphone Connector Pin-Out*

Pin #	Signal	Diagram
1	Not Connected	
2	+5V DC (max 65mA)	
3	Not Connected	
4	Not Connected	
5	Chassis GND (Shield)	
6	PTT (+)	
7	Mic (-)	
8	Mic (+)	

**Note:** The FLEX-5000 has a 20dB microphone preamp built in. If you do not require this additional gain, you may want to try using either the unbalanced Line-In (13) or Balanced Line Input (14) jack on the back panel (see pages 6 and 10).

We recommend use of the Heil microphones, especially the PR series; however, the HM-10 and Goldline microphones will also work well with the FLEX-5000<sup>2</sup>.

<sup>1</sup> The pin-out is similar to that normally found on Yaesu radios

<sup>2</sup> These microphones may not sufficiently drive the rear audio inputs (13) and/or (14) (see page 10) without an external preamp.

**(4) Internal Speaker (FLEX-5000C Only)**

The FLEX-5000C does not require external, powered speakers as it comes with an internal speaker. However, you will need to use external powered speakers to take advantage of spatial diversity (such as binaural audio or spatially positioning multiple audio channels).

**Back Panel**



*Figure 2: FLEX-5000A (top) and FLEX-5000C (bottom) Back Panel*

**Note:** The right half of the FLEX-5000C back panel is identical to the back panel of the FLEX-5000A; the left half has all the connections for the built in computer.

The FLEX-5000 has the ability to connect up to three different antennas to the receiver and or transmitter and up to two additional receive only antennas. All of these are assignable on a per band basis. The antenna connections are as follows:

### ***(1) Primary Antenna Ports (ANT1, ANT2 & ANT3)***

Three SO239 antenna ports that can be software selected on a per band basis and assigned as either receive, transmit or both.

### ***(2)-(3) Receive Only Antenna Ports (RX1 IN & RX2 IN)***

Up to two additional receive only antennas can be connected, each of which is separately selectable on a per band basis.

- ❑ **RX1 IN** is the receive only antenna port for the first receiver.
- ❑ **RX2 IN** can be used to connect a receive only antenna to the optional second receiver<sup>1</sup>.

### ***(2) External RX1 OUT to RX1 IN Receive Loop***

With PowerSDR a dedicated receive path can be selected by band so that all of the receive signals input to either **ANT1, ANT2 or ANT3** are output to the **RX1 OUT** port and input back into the **RX1 IN** port. This enables the insertion of external signal enhancing devices such as preamps, filters and preselectors, without requiring complicated switching mechanisms to avoid transmitting through them.

### ***(4)-(5) Dedicated Transverter Connections***

The FLEX-5000 has been designed to support transverters through both a 28MHz and/or 144MHz IF interface.

- ❑ **XVTX/COM** outputs a 28MHz IF signal, adjustable up to +5dBm to drive external transverters
- ❑ **XVRX** accepts a 28MHz IF signal from external transverters. If your transverter does not have a separate IF output, then only use **XVTX/COM**
- ❑ **144MHz** is the output of the optional, internal transverter.

### ***(6) 13.8 VDC Power Socket***

The FLEX-5000 requires a stable 13.8 VDC power source rated for at least 25 Amps and 30 Amps peak for proper operation. Supplied with your radio was an unterminated 4-pin keyed Molex type power connector and cable set. Terminate this cable in the appropriate connector (if needed) for your DC power source such as Anderson PowerPoles®, banana plugs, spade or ring lugs, or tinned ends for screw terminals. Connect the 2 red wires to the positive terminal and the 2 black wires to the negative terminal of your power supply<sup>2</sup>. The Molex type connector is inserted into the white Molex receptacle labeled **-13.8 VDC+**.

[The rest of this page has been left blank intentionally]

---

<sup>1</sup> Second receiver is standard with the FLEX-5000D

<sup>2</sup> Older radios may have only 1 red and 1 black wire, which are connected to the + and – terminals respectively.

**(7) Dual IEEE 1394 FireWire<sup>®1</sup> Jacks**

The FLEX-5000 has two 400 Mb/s 6-pin IEEE 1394 FireWire jacks. These are 1394a connections not the 1394b (FireWire 800) type which run at 800 Mb/s. Connect the ferrite core end of the supplied 6-pin FireWire cable to either of these two jacks and connect the other end to

- ❑ **FLEX-5000A:** your computer’s FireWire jack (the host controller).
- ❑ **FLEX-5000C:** the computer jack marked “FireWire” in Figure 2 on page 6.

The second FireWire jack (7) can be used to “daisy chain” or extend the FireWire bus so that additional IEEE 1394 FireWire devices may be connected.

**CAUTION 1:** Do not connect the second FireWire jack to a second PC. Only one PC can be connected to the FLEX-5000.

**CAUTION 2:** Do not remove the ferrite cores as they are required for CE compliance and to minimize RFI at this ingress point.

**Note 1:** Even though the 1394b standard is supposedly downward compatible (9-pin to 6- or 4-pin cables are used), you should preferably only use 1394a host adapters to connect to the FLEX-5000. Please also refer to the Knowledge Center article [Selecting High Performance FireWire Cards for FlexRadio Transceivers](#) (search for *firewire card* in our Knowledge Center at <http://kc.flex-radio.com/search.aspx>).

**Note 2:** The FLEX-5000 FireWire controller does not supply voltage, so if you are connecting a device “down stream” that normally receives power from the FireWire cable you must supply external power to use that device.

**(8) Straight Key or Paddles (KEY)**

For CW operation, the ¼” TRS **KEY** jack will accept a TRS plug for operating a keyer with paddles or a TRS/TS plug for a straight key. The pin-out is shown in Table 3 below.

*Table 3: Key Jack Pin-Out*

Connector	Keyer Signal	Straight Key
Tip	Dot	Key
Ring	Dash	N/C
Sleeve	Common	Common

---

<sup>1</sup> FireWire is a registered trademark of Apple, Inc.

**Note:** Although not necessary, if you prefer to connect your paddles to a serial port on your PC you may do so using the pin-out shown in Table 4.

*Table 4: PC Serial Port Pin-Out*


Serial Port Pin*	Keyer Signal
4 (DTR)	Common
6 (DSR)	Dot
8 (CTS)	Dash

\* Assumes a 9-Pin connector

**(9) External Keying Lines (AMP RLY TX1, TX2 & TX3)**

These three independent keying lines can be used to key external devices such as linear power amplifiers or transverters. One or more of the keying lines can be used at any one time, can be given a delay and can be assigned on a per band basis on the Antenna Form (see page 150). For example, you may have an HF amplifier that covers 160-10 meters and another amplifier for 6 meters. You can assign **TX1** to bands 160 -10 meters to key the HF amplifier and **TX3** to 6 meters to key that amplifier when you select the 6 meter band.

These keying lines each use an open collector Darlington transistor switch that is rated at 400mA, 50VDC maximum. To ensure that your amplifier keying circuit does not damage the Darlington transistor switch, it is safest (even for modern amplifiers) to insert the circuit shown in Figure 3 below between each of TX1, 2 and/or 3 and your amplifier(s).



*Figure 3: Protective PTT Circuit Between TX1-3 and Amplifier*

**(10) External Frequency Reference Input**

Accepts input from an optional 10MHz, 0 to +10dBm reference source, such as a GPS disciplined or high precision clock source. This enables greater frequency stability for those operators requiring such, e.g. for VHF+ operators operating in the GHz range.

[The rest of this page has been left blank intentionally]

**(11) Powered Speaker/Line Out Jack**

This standard 1/8" TRS jack provides line-level (-10dBV, 600 Ohms) receive - *not computer* - audio<sup>1</sup>. For the FLEX-5000A (and if desired for the FLEX-5000C) connect this jack to an external audio amplifier, to computer-type powered speakers or any other external equipment that accepts line-level audio input. This jack provides two-channel (stereo) audio to enable binaural audio, MultiRX™<sup>2</sup> (single receiver) or dual receive (with optional second receiver installed). The audio level can be set on the FLEX-5000 Mixer Form (see page 148).

For more information on powered speakers used with FlexRadio products, refer to the Knowledge Center article [What Kind of Speakers Should I buy for my SDR?](#) (search for *speaker* in our Knowledge Center at <http://kc.flex-radio.com/search.aspx>).

**(12) FlexWire™ Peripheral Interface Bus**

FlexWire<sup>3</sup> is an intelligent, high speed, bi-directional communications interface that allows PowerSDR to communicate with a host of peripheral devices such as antenna tuners, rotor controllers, band switchers, etc. A family of FlexWire peripherals will be forthcoming from FlexRadio Systems. This is not another "CAT" port, but an industry standard bidirectional communications bus based on the I<sup>2</sup>C (pronounced "I squared C") protocol along with AF I/O lines.

*Table 5: FlexWire Connector Pin-Out*

Pin #	Signal	Diagram
1	Ground	
2	Line In	
3	(Blocked Pin)	
4	Interrupt (/INT 1)	
5	Ground	
6	I <sup>2</sup> C Clock (SCL)	
7	I <sup>2</sup> C Data (SDA)	
8	+13.8V, 1A max	
9	Line Out (in parallel with RCA Line Out)	

Table 5 above Shows the FlexWire connector pin-out. Complete specifications and the programming interface will be published to allow home brew and third-party add-on products.

**CAUTION:** Do NOT attempt to connect a PC serial port to the FlexWire connector (pin 3 has been blocked to stop this). Doing so may void your warranty and severely damage your FLEX-5000.

<sup>1</sup> The FLEX-5000C and FLEX-5000D also have a built-in speaker

<sup>2</sup>MultiRX is a trademark of FlexRadio Systems

<sup>3</sup> FlexWire is a trademark of FlexRadio Systems.

**(13) Line-Out and Line-In Audio Jacks**


Consumer level (-10 dBV) audio connections. Audio levels can be set on the FLEX-5000 Mixer Form (see page 148).

- ❑ **Line-Out** can drive external sound card-based applications if VAC is not, or cannot be used. It can also provide audio for external audio equipment such as recorders and audio spectrum analyzers. Line Out impedance equals 600 Ohms.
- ❑ **Line-In** allows the connection of external audio equipment, VAC or an external sound card, e.g. to play back prerecorded audio over the air. Line In impedance equals 5 kOhms.

**(14) Balanced Line Input**

1/4" TRS jack to connect to audio processing equipment supplying balanced audio (+4dB $\mu$  max), such as a microphone preamplifier or (chain of) equalizers, compressor/limiters, aural exciters and other effects processors. This jack can be used instead of the Microphone connector on the front panel. However, unlike the front panel Microphone connector, there is no 20dB preamp in line. The Pin-Out is shown in Table 6 below. Balanced Line Input input impedance is >50 k Ohms.


*Table 6: Pin-Out of Balanced Line-In Connector*

Contact	Description	Connector
Tip	Positive phase for balanced mono signals or mic (+)	
Ring	Negative phase for balanced mono signals or mic (-)	
Sleeve	Ground or shield connection	

**Connecting to a Balanced XLR Connector**

The most common way to use the balanced line-in connector is when using a balanced microphone, usually having a male XLR connector (see Table 7 below).

*Table 7: XLR Male and Female Connector Pin-out*

Contact	Description	Connector
Pin 1	Ground or shield connection	
Pin 2	Positive phase for balanced mono signals or mic (+)	
Pin 3	Negative phase for balanced mono signals or mic (-)	

To interface this type of microphone to the FLEX-5000 a balanced XLR (female) to balanced ¼" TRS (male) cable is necessary, which should be wired as shown in Figure 4a. You can also connect audio processing equipment using a similar cable. If you have a ground loop or a lack of proper grounding (indicated by hum or buzz in your output), adding a simple filter to the shield may resolve the problem (see Figure 4b). The filter consists of typically a 100 Ohm resistor to attenuate small DC currents, decoupled for RF by typically a 4pF – 10nF capacitor.




Figure 4: Wiring Diagrams to Connect Between Balanced TRS and XLR Connectors

**(15) PTT Jack**

Connect to external hardware devices such as foot pedals or hand switches to key the rig. The transmitter will be engaged when the center conductor is grounded.

**(16) RF Ground Terminal**

Connect to the single point ground system in your shack. Alternatively, if you have no single point grounding system, ground the FLEX-5000 to the metal chassis of your computer with a low impedance ground strap, such as a 1" braid or copper strip (the screws that hold the computer power supply in place make an excellent grounding point).

[The rest of this page has been left blank intentionally]



## FLEX-5000C Computer Connections

### *Wireless Keyboard and Mouse*

- ❑ Insert (2) AAA batteries into the battery compartment in the bottom of the wireless computer keyboard. Additional instructions may be found on the label underneath the keyboard.
- ❑ Insert (2) AA batteries into the wireless mouse. The battery door covers the lower half of the mouse and may be removed by a pressing/sliding motion on top of the product logo. With the mouse in the operating position, the battery cover slides away from the buttons/scroll wheel and toward you as you remove it.
- ❑ Plug the USB connector of the wireless receiver into one of 4 USB ports, indicated as **USB** in Figure 2 on page 6. (The green and purple 6-pin MiniDIN PS/2-style connectors on the wireless interface are not used if a USB connection is made.)
- ❑ If connecting additional USB devices, any USB jack will work with any USB device.

### *FireWire Cable*

Connect the supplied FireWire cable between the Computer FireWire jack (**FireWire** in Figure 2) and one of the two radio's FireWire jacks (**7**) as described on page 8. Make sure the ferrites are closest to the radio's FireWire jacks (**7**). Do not remove these ferrites since they are required for CE compliance and to minimize RFI.

### *Monitor or LCD Display*

Connect a monitor or LCD display to the **VGA** connector.

**Note:** Even though the system supports digital video through the two additional **DVI** connectors, it is necessary to use the **VGA** connector to initialize the computer. Either **DVI** or **VGA** connector(s) may be used after initialization

### *Computer Speakers*

If desired, connect external computer speakers to the green jack marked **Speaker** in Figure 2. These are used to output audio from the operating system and any programs you may use.

**Note:** Do not confuse these with the internal speaker or external speakers you may have connected to the Powered Speakers jack (**11**), which are strictly used for receive audio by the FLEX-5000.

[The rest of this page has been left blank intentionally]

## Network Connection

**WARNING!** Install an anti-virus protection application *before* connecting to networks or the Internet. FlexRadio is not responsible for problems caused by virus, spyware or other malware exposure.

Using one of the three Ethernet network jacks (marked **Network** in Figure 2 on page 6), you may connect your FLEX-5000C computer to your local area network or to your Internet modem. To make the connection, use a standard CAT5 network cable. The Network jacks support 10/100/1000 Ethernet.

## Installing the FLEX-5000C

**Note:** This section is only relevant for the FLEX-5000C. If you own a FLEX-5000A, please skip to **Installing the FLEX-5000A** on page 18.

Before proceeding, write down the **Product Key** (see Figure 2 on page 6) from the label on the rear of the radio. This Microsoft **Product Key** appears in 5 groups with 5 letters/numbers in each group. You will enter these during the setup process.

## Power-up and Connect Keyboard and Mouse

Position the radio, display, keyboard, mouse and wireless keyboard controller in their operating positions

1. Turn the mouse and keyboard upside down for easy access to the **connect** buttons.
2. Turn on your display/monitor/LCD panel and select D-sub or analog source if applicable .
3. Turn on your 13.8 VDC power supply.
4. Turn on the FLEX-5000C using the power button on the front panel (press momentarily). A delay of a few seconds until seeing the blue light is normal (see page 4).

The blue light should show on the power button, the fans should start inside and the green light on the wireless keyboard controller should illuminate. If not, cut the 13.8 VDC power and recheck your connections.

5. Press and release the **connect** button on the wireless keyboard controller and press and release the **connect** button on the bottom of the keyboard. Wait at least 20 seconds before the next step.
6. Press and release the **connect** button on the wireless keyboard controller again and press and release the **connect** button on the bottom of the mouse.
7. Move the mouse and check for pointer motion on the display.

**Note:** The mouse and keyboard reference sheet provides additional details.

At this point you should see the Microsoft opening screen (and hear sound if you added computer speakers). If you are unable to spend about 5 minutes completing the next section, you may turn off the system by turning off the power supply. It will not be possible to stop the computer by using the front panel button.

## Set up and Configure the Computer

The operating system is preinstalled but in a “sealed” state. It is not usable until you accept the *End User Licensing Agreement* contained in the operating system. FlexRadio is not in control of this process since the software use agreement is between you, the end user, and Microsoft.

**Note:** The following steps summarize much of the more detailed information in your *Start Here* operating system booklet from Microsoft. That booklet is packed in the box with your new radio. Please refer to that booklet for additional information if needed during the setup process.

The screens you will see during the setup process and the suggested actions are:

1. Welcome to Microsoft Windows: click **Next**.
2. End User License Agreement: if you agree, click **Yes** to accept, then click **Next**.
3. Is this a genuine copy of Microsoft Windows?/Product Key Entry: enter the Product Key you copied from the back panel label, then click **Next**.
4. What's your computer's name?: accept the default name or enter a name of your choosing, click **Next**.
5. What's your Administrator Password?: enter a password if desired (recommended if on a network), click **Next**.
6. Is this computer in a Domain?: for almost all users - click **next**. Users in a large network **with a domain controller** should get specific instructions from the network administrator.
7. Checking your Internet Connectivity: results will depend on whether a network cable is connected:
  - If an Internet connection is found, several screens will follow to set up your Internet connection.
  - If the search times out, you will see “An Internet connection could not be chosen”. Click **Next**.
  - To skip the search, click **Skip** and go directly to the next screen.

8. Ready to Activate Windows?:
  - If connected to the Internet, you may activate by clicking **Yes** and then **Next**.
  - If you will activate Windows later or by phone click **No** and then **Next**.
9. Thank you: click **Finish**.

## Set Your Time Zone and the System Date/Time

To set your computer time zone and the correct date/time:

1. Double-click the clock in the lower right corner of the desktop view.
2. Click the **Time Zone** tab at the top.
  - Select your time zone from the list (above the map).
  - Click **Apply**.
1. Click the **Date & Time** tab at the top
  - Set your date by clicking on the calendar
  - Set your time by entering where shown then click apply

You are now ready to operate your FLEX-5000C. Please skip to chapter 2 on page 33 to learn how to setup PowerSDR.

## Reference Documents

Your reference documents are accessible from the startup menu and by double-clicking the **FlexRadio Documentation** folder shortcut shown on your desktop. Most reference documents are in Adobe PDF format and are read by using the PDF Reader application. **You must install the PDF reader before attempting to open any PDF document.** Your Owners Manual is also in PDF format. The PDF reader may be downloaded from the Adobe web site and is free software. Please see <http://www.adobe.com>

## Installer Library

Drivers and documentation for your computer system board as well as software, firmware and drivers used by FlexRadio are stored in your *Installer Library*. These items are preinstalled and are provided as backup copies in the event you need to remove/reinstall any of them. The folder is located at the root level of the C: drive. There is also a menu entry under *All Programs*.

## Hard Drive Restore Process

The computer within your radio has a hidden restore partition on the hard drive called the Secure Zone<sup>®1</sup>. It contains a complete copy of the originally shipped factory software. In the event you have a

---

<sup>1</sup> Secure Zone and Recovery Manager are registered trademarks of Acronis, Inc.

virus infection, major problem with the operating system, accidental folder deletion or other major disturbance, it is possible to completely reinstall the operating system, application programs, FlexRadio programs and tools from this restore partition.

**CAUTION:** Any files you added or modified along with all new software and data will be erased and replaced with only the files FlexRadio installed at time of manufacture. This means the loss of all logs, email, photos, new programs and your PowerSDR memory file (called PowerSDR.mdb in the PowerSDR v.n.n.n folder). These files may be preserved by copying them to a USB memory key or even e-mailing them.

The restore software is included in the purchase price of your radio. A serial number for your copy of this software is listed on a separate page packed with your system. You also have the opportunity (but not the obligation) to upgrade this software and use additional features by contacting the software vendor (Acronis) directly. Your Secure Zone will restore the original configuration additional times if future errors occur. It is not necessary to register or upgrade the Acronis software to use the restore process again in the future. If the hard drive fails, the secure zone and restore image could be lost. In this case, contact FlexRadio for instructions.

When your computer first starts, a brief screen image will display the Acronis logo. By quickly pressing the <F10> key, the Recovery Manager® will appear. You may have to press this key several times starting after you power up your radio since some monitors might not show any image before this screen has disappeared. The Recovery Manager screen will offer three choices. You may elect to restore your system, shut it down, or continue to start Windows normally. If you click the Restore option and click yes on the warning notice, the restore process will begin. It is normal for 1-2 minutes to elapse as the program loads. After that, information screens will describe each step. Restarting your system at the end of the process will return you to the same software experience as new, out-of-the-box. The entire restore process should take less than ten minutes.

[The rest of this page has been left blank intentionally]

## Installing the FLEX-5000A

**Note:** This section is only relevant for the FLEX-5000A. If you own a FLEX-5000C, please see **Installing the FLEX-5000C** on page 14.

### Switch Off the FLEX-5000A and Install the FireWire Driver

**Note 1:** To install the FLEX-5000 FireWire Driver, you must at least connect the FLEX-5000A to a 13.8VDC power supply and an IEEE 1394 FireWire computer port.

**Note 2:** If there is a (Edirol FA-66 or Presonus Firebox) sound card connected to the same FireWire host controller you are planning to use with the FLEX-5000A, **disconnect** it until the installation is complete and the FLEX-5000A is fully operational.

**WARNING!** It has been reported that data corruption occurred when trying to use a FireWire hard disk. We do not recommend that you have a FireWire hard disk connected to the same FireWire controller (bus) as the FLEX-5000. Both of these devices use the FireWire bus extensively and performance of both will be degraded significantly.

Download the FLEX-5000 FireWire Driver at <http://support.flex-radio.com/Downloads.aspx?id=165> or from the downloads page (<http://support.flex-radio.com/Downloads.aspx?fr=1>) of our website and save the zip file to a convenient location on your computer. Then go to the saved zip file and extract its contents.

Before proceeding with the installation, make sure the power switch on **the FLEX-5000A is turned off** (blue LED is off, see Figure 1 on page 4). It is also a good idea to close all other applications.

Double click on the extracted driver installation file to open the FLEX-5000 Setup Wizard (Figure 5).

[The rest of this page has been left blank intentionally]




*Figure 5: FLEX-5000 Driver Setup Wizard*

Click the **Next** button to continue to Figure 6 <sup>1</sup>.

[The rest of this page has been left blank intentionally]

---

<sup>1</sup> All screenshots in this manual are as they would appear when using the Microsoft Windows XP operating system. The screenshots may look slightly different when using Microsoft Vista, but the steps are the same.




*Figure 6: FLEX-5000 Driver Setup Wizard - Select Destination Location*

We recommend you accept the default location to install the FLEX-5000 FireWire to. Click the **Next** button to continue to Figure 7.

[The rest of this page has been left blank intentionally]






*Figure 7: FLEX-5000 Driver Setup Wizard - Select Additional Tasks*

If you do not want the FLEX-5000 Control Panel icon on your desktop, uncheck the "Create a desktop icon" option. Click the **Next** button to continue to Figure 8.

[The rest of this page has been left blank intentionally]



*Figure 8: FLEX-5000 Driver Setup Wizard - Ready to Install*


Verify that the options selected in the previous two steps are correct. If not, click the **Back** button to make any changes. Click the **Next** button to confirm these settings and to copy the necessary files to the selected install directory. If a Software Installation warning<sup>1</sup> appears, click the **Continue Anyway** button to proceed.

Once the files have been copied, you will see the screen shown in Figure 9.

[The rest of this page has been left blank intentionally]

---

<sup>1</sup> This warning is displayed because the hardware driver has not passed the formal Windows Logo Testing program. The FLEX-5000 driver has, however, been extensively tested and will not destabilize or impair your system



*Figure 9: Completing the FlexRadio FLEX-5000 Setup Wizard*

You will need to restart your computer before you can continue. We recommend you do this now by accepting the default selection, verifying that **the FLEX-5000A is not powered on** and clicking on the **Finish** button.

## Power Up the FLEX-5000A

After your computer has rebooted, press and release the power button on the FLEX-5000A to power it up. After a brief moment, you will hear the power relay click and the blue LED will illuminate the power button. When this happens, Windows XP will detect the FLEX-5000A and display the Found New Hardware Wizard (Figure 10).

[The rest of this page has been left blank intentionally]




*Figure 10: Found New Hardware Wizard*

Select the option **No, not this time** when you are prompted to use Windows Update to search for software. Click on the **Next** button to continue to Figure 11.

**Note:** Figure 10 above may not show up in some systems.

[The rest of this page has been left blank intentionally]




*Figure 11: Found New Hardware Wizard - Installing the Software*

The Found New Hardware Wizard will recognize that you are trying to install a **FlexRadio FLEX-5000**. Select the option **Install the software automatically (Recommended)**. Click on the **Next** button to continue.

The Found New Hardware Wizard will request you to please wait while it installs the software. If a Hardware Installation warning appears, click the **Continue Anyway** button to proceed.

[The rest of this page has been left blank intentionally]



*Figure 12: Found New Hardware Wizard - Software Installation Indicator*


After the driver files are installed you will see the Completing the Found New Hardware Wizard screen (Figure 12) to indicate that the wizard has finished installing the software for the FlexRadio FLEX-5000. Click on the **Finish** button to continue. You should see a prompt in the bottom right hand corner of your display that indicates that your new hardware is ready to use.

## Configuring the Driver with the FLEX-5000 Control Panel

Before operating the FLEX-5000 you will need to select the driver's appropriate **Sampling Rate**, **Buffer Size in Samples** and **Operation Mode** using the FLEX-5000 Control Panel (see Figure 13 on page 27). If you elected to create a desktop icon during driver installation (see Figure 7 on page 21), simply double click on this icon to open the control panel. Alternatively, click on the **Start** button (bottom left of your screen) and then on **All Programs**. Select the **FlexRadio FLEX-5000** program folder and double click on the **FlexRadio FLEX-5000** application.

[The rest of this page has been left blank intentionally]

## Sampling Rate and Buffer Size



**Figure 13: FLEX-5000 Control Panel Sample Rate and Buffer Size Settings**

To set the sample rate and buffer size, click on the **Bus** tab at the top right (Figure 13). These settings depend on the modes you primarily operate. For CW, minimum latency (smaller buffers) is paramount; for digital and phone modes, larger buffers may increase stability, especially if using VAC or other third-party audio programs.

- ❑ The lower the sampling rate, the smaller the buffer size can be to achieve the same overall system latency.
- ❑ The minimum buffer size at a certain sample rate depends on the available computing power: smaller buffers require more interrupts per unit of time (audio dropouts are an indication of too low a buffer size). Given a sample rate, the minimum buffer size is limited by the Operation Mode setting (see next section).

Table 8 below shows initial settings for the driver's Sampling Rate, Buffer Size and Operation Mode. You should start with these values and if you desire you can experiment with other settings. In some cases, where audio drop outs are being experienced, larger buffers may need to be used. Also, see Appendix A for more detail.

*Table 8: Initial Driver Configuration Settings*

Modulation Mode	Sample Rate (kHz)	Buffer Size	Operation Mode
CW	48	512	Safe Mode 1
	96	512	
	192	1024	
Phone	48	512	Safe Mode 1
	96	1024	
	192	2048	


**Note 1:** If this is the first time you are using a software defined radio, a conservative sample rate such as 48 kHz or 96 kHz is recommended until you know how your PC is going to perform.

**Note 2:** The sample rate will automatically follow whatever is set in PowerSDR (see page 44).

[The rest of this page has been left blank intentionally]



## Operation Mode



*Figure 14: FLEX-5000 Control Panel Operation Mode Setting*

Click on the **Advanced** tab at the top right (Figure 14). There are four **Operation Modes**<sup>1</sup> to choose from: Normal and Safe Mode Levels 1 – 3, where Normal is the most aggressive and Safe Mode 3 the safest. The default operation mode is **Safe Mode Level 1** and should be used in almost all cases. If you choose to operate with the Normal mode and your FLEX-5000 freezes up, you should revert to Safe Mode Level 1. In very rare circumstances your PC may have internal latencies where Safe Mode Level 1 does not work optimally with your system. In these cases, you should select either Safe Mode 2 or Safe Mode 3 to provide a stable environment to run the FLEX-5000.

Once you have verified that all is working well, you may fine tune the settings to best match your system and favored modulation mode.

<sup>1</sup> Technically these Operation Modes control how successfully the hardware driver recovers from buffer over and under runs. Some hardware drivers and third-party applications issue what are called delayed procedure calls (DPCs). Higher Safe Modes allow the driver to handle longer DPC latencies at the cost of more audio latency.

- Note 1:** We strongly recommend you leave the Operation Mode in Safe Mode Level 1, which offers the best trade-off between ability to recover (no freeze-ups) and audio latency. However, if you experience regular freeze-ups, you should increase the Safe Mode Level to either 2 or 3
- Note 2:** We strongly suggest you select buffer sizes that are powers of 2 (256, 512, 1024 and 2048).
- Note 3:** The minimum buffer size that can be set is a function of both the sample rate and the Safe Mode setting. For Safe Mode 1, the minimum buffer size at 192 kHz is 2048, at 96kHz is 1024 and at 48 kHz is 512.

### DPC Latency Checker




Figure 15: FLEX-5000 Control Panel DPC Latency Checker

The Flex-5000 Driver comes with a DPC latency checker to check the maximum latency incurred on your system. To enable it click the **DPC** tab at the top right (Figure 15) and click **Enable DPC Latency Checker**. For the result to be meaningful, you should run all applications you usually do while running PowerSDR (email, digital mode software, logger, etc.) and let it run for at least 5 minutes. The checker will show the maximum latency found during the test period and recommend an Operation Mode based on the result. While it may some times recommend Normal Mode, we recommend to keep your Operation Mode at Safe Mode 1 unless you experience latency issues. For further information go to the FlexRadio Knowledge Center on our website and read the article [How to Use the FlexRadio FireWire Driver DPC Latency Checker to Determine Operating Mode](#) (search for *firewire card* in our Knowledge Center at <http://kc.flex-radio.com/search.aspx>).

[The rest of this page has been left blank intentionally]

# PowerSDR Installation & Setup


**Note:** Although PowerSDR is already preinstalled on the FLEX-5000C, the following sections are relevant if you are upgrading to a later version of PowerSDR. Otherwise, please skip to **PowerSDR Setup Wizard** on page 38.

## Upgrading From an Earlier Version

We recommend that you leave older versions of PowerSDR installed when upgrading from a previous version. After reviewing the new version and verifying that your setup works, uninstalling previous versions is fine (but not necessary). Note that in order to completely remove previous versions you must manually delete the database file (PowerSDR.mdb) from the application directory (usually c:\Program Files\FlexRadio Systems\PowerSDR vn.n.n).

## PowerSDR Installation


Download PowerSDR v1.14.0 or later from the FlexRadio downloads page at <http://support.flex-radio.com/Downloads.aspx?fr=1> to a directory on your hard drive (we recommend saving to the Desktop). If you downloaded the zip file, extract its contents. Double click the Setup file (Setup.exe) to start the installation process. The PowerSDR installation will prompt you to install the .NET framework version 1.1<sup>1</sup> if it is not installed and it will point you to the appropriate web address for downloading as seen in Figure 16.



*Figure 16: Prompt for .NET Framework*

<sup>1</sup> Multiple versions of the .NET Framework can reside on your computer side by side.


Follow the instructions to install the framework using the download from Microsoft's website and then restart the Setup.exe program. You should see the screen shown in Figure 17.



*Figure 17: PowerSDR Installation Welcome Screen*

Click the **Next** button to continue to Figure 18.


[The rest of this page has been left blank intentionally]



*Figure 18: PowerSDR Installation Folder Selection*

You can change the installation directory here, though we recommend you use the default for troubleshooting purposes. Click the **Next** button to continue to Figure 19.


[The rest of this page has been left blank intentionally]



*Figure 19: PowerSDR Installation License Agreement*

Read the GNU Public License. If you accept, click **I Agree** and click the **Next** button to continue to Figure 20. Otherwise click **Cancel**.

[The rest of this page has been left blank intentionally]




*Figure 20: PowerSDR Installation Confirmation*

Click the **Next** button to confirm these settings and to copy the necessary files to the selected install directory. Once the files have been copied, you will see the screen shown in Figure 21.

[The rest of this page has been left blank intentionally]






*Figure 21: PowerSDR Installation Complete*

Click the **Close** button to complete the installation and close the dialog.

## PowerSDR Setup Wizard

Power up the FLEX-5000 to load its driver and start up the PowerSDR console using the shortcut on the Desktop (or through the Start menu). When you run a new release of PowerSDR for the first time an optimization routine will run and the screens shown in Figure 22 will appear.

[The rest of this page has been left blank intentionally]




*Figure 22: Optimization Routine*

Click **OK** and let the routine run.

**Note:** This routine aims to optimize the FFT calculations for the environment (hardware and software) in which the calculations will be performed. For optimal performance, you should therefore close all applications you will normally not be running simultaneously with PowerSDR. The routine will save a file called **wisdom** to the directory in which PowerSDR resides. If you wish to run FFTW again, delete this file from the directory and start up PowerSDR, or simply run the `fft_wisdom.exe` file in the PowerSDR directory.

When the routine has completed, a brief startup sequence will follow, after which you should be greeted by the PowerSDR Setup Wizard as shown in Figure 23 below.

[The rest of this page has been left blank intentionally]



*Figure 23: PowerSDR Setup Wizard Welcome*

**CAUTION:** Starting with PowerSDR 1.10.2 you will *not* be prompted to import a previous database. The FLEX-5000 database is significantly different in structure than the one used with the SDR-1000 and you need to start out with a fresh (automatically created) database where all of the parameters are configured to their system defaults.

**Hint:** You can copy selected tables from your existing SDR-1000 (or previous FLEX-5000) database to the new default database by using K9DUR's [Data Transfer Utility](http://kc.flex-radio.com/search.aspx) (search for *data transfer* in our Knowledge Center at <http://kc.flex-radio.com/search.aspx>). We recommend that you only transfer the tables *BandStack*, *BandText*, *EQForm*, *GroupList*, *Memory*, *TXProfile*, *UCB* and/or *WaveOptions* if any.

We recommend you keep a copy of your original database before transferring any tables.

Click the **Next** button to continue to Figure 24.

[The rest of this page has been left blank intentionally]




*Figure 24: PowerSDR Setup Wizard - Radio Model*

Select the FLEX-5000 radio model as shown in Figure 24 above. Click the **Next** button to continue to Figure 25.

**Note:** If you are running without a radio, e.g. for demonstration purposes, select Demo/None. For the SDR-1000 see the SDR-1000 Owner's Manual.

[The rest of this page has been left blank intentionally]



*Figure 25: PowerSDR Setup Wizard – Finished*

The Setup Wizard is now complete. Click the **Finish** button to complete the wizard.

**Note:**

If you forgot to power up the FLEX-5000 before starting PowerSDR, a communication error message will be displayed and PowerSDR will offer the ability to start in demo mode. Click **No** to close PowerSDR, power up the FLEX-5000 and restart PowerSDR.

[The rest of this page has been left blank intentionally]

## Initial PowerSDR Configuration

Before operating the FLEX-5000 several PowerSDR parameters need to be configured. To do so, start up PowerSDR to open the Front Console, but **do not** yet click on the **Start** button.

**Note:**

From time to time the FLEX-5000 firmware may need to be updated. If PowerSDR detects an incompatible version of the firmware, it will display an error message similar to that shown in Figure 26 below.




*Figure 26: FLEX-5000 Firmware Version Error*

Click **OK** and if a Driver Error message follows, click **OK** again. PowerSDR will start up, but the **Start** button will be grayed out. Close PowerSDR and refer to the procedure described in Appendix B to update your firmware.

## Transfer of Calibration Data


PowerSDR will need to transfer your radio's calibration data from its EEPROM to the new database. In this case you will see the message shown in Figure 27.



*Figure 27: Calibration Data Transfer Message*

Click the OK button to start the transfer of calibration data. You will see the progress indicator shown in Figure 28. When the transfer is complete, PowerSDR will complete starting up.

[The rest of this page has been left blank intentionally]




*Figure 28: Calibration Retrieval Progress Indicator*

Do **not** click **Start** just yet as you will first need to configure Audio parameters, Antenna ports and Mixer settings.

## Audio Parameters

Click on **Setup** at the left of the menu at the top of the Front Console to open the Setup Form. Select the Audio tab and then the Primary sub-tab shown in Figure 29.



*Figure 29: Setup Form - Audio Tab, Sound Card Sub-Tab*


Change the Buffer Size to the same value you entered in the FLEX-5000 Control Panel (see Figure 13 on page 27). Click on the **OK** button when done.

**Note:**

If the sample rate and buffer size set for the FLEX-5000 hardware driver (see Figure 13 on page 27) are different than the PowerSDR sample rate and audio buffer size (Figure 29), audio drops will most likely occur due to buffer alignment issues.

## Antenna Port and External Keying Lines

You will next need to configure the antenna ports such that the correct antenna is selected for each band as well as the correct keying line(s), if any. To do so, click on **Antenna** in the menu of the Front Console (Figure 30). We will only describe certain controls at the **Simple** complexity level here. For more detailed information, including **Expert** level, see page 149).



*Figure 30: Antenna Form - Simple*

- ❑ **Complexity: Simple** uses the same antenna port for all bands, whereas **Expert** allows you to select different antenna ports for each band. If you use only one antenna, choose **Simple**.
- ❑ **Antenna:** The following selections are possible:
  - **Receiver 1:** ANT1 (default), ANT2, ANT3 or RX1 IN
  - **Receiver 2:** (if installed) RX2 IN (default), RX1 Tap (the same antenna port as selected for receiver 1), ANT1<sup>1</sup>, or N/C (not connected).
  - **Transmit:** ANT1 (default), ANT2 or ANT3<sup>2</sup>.

<sup>1</sup> Earlier versions of the FLEX-5000, with the HRFIO board Assembly Number (ASSY) 27 installed instead of the later HRFIO board ASSY 34, do not have ANT1 available as an option for Receiver 2. You can check which board is installed in your FLEX-5000 by opening the Setup Form – General Tab, Hardware Config Sub-Tab, in the section marked FLEX-5000 Config. The Assembly Number is shown between brackets at the end of the line beginning with RFIO (see e.g. Figure 64 on page 81). Also see the Knowledge Center articles [HRFIO Capabilities by Assembly Number](#), [How to Identify the HRFIO Assembly Number](#) and [Antenna Selection Options for the RX2](#) (a search for HRFIO in our Knowledge Center at <http://kc.flex-radio.com/search.aspx> will yield all these articles). If you have the earlier HRFIO ASSY 27, you can upgrade to ASSY 34. See the [Flex-Radio Systems website](#) (<http://www.flex-radio.com/>) for more information.

<sup>2</sup> For the earlier HRFIO board ASSY 27 (see footnote 1 above), the 6m transmit antenna port is fixed to ANT3 and cannot be changed. Only the ANT3 port meets the -60dBc spurious output requirement at 6m. For the later HRFIO ASSY 34, this is not the case and the 6m transmit antenna port can be assigned to any of ANT1-3, just like any other band.



**WARNING!** Make sure you have an antenna connected to the Transmit antenna port you selected. Failing to do so may damage your radio and void your warranty.


**WARNING!** Do not switch the transmit antenna while transmitting (hot switching). You could damage your radio and void your warranty.

- ❑ **Switch Relay with TR:** Select the keying line(s) you use, if any, to key your amplifier(s) or other external equipment. If you want to sequence the switching, set the appropriate **Delay** times for each keying line.

Close the Antenna Form when you are done.

## Audio Mixer

The FLEX-5000 input and output audio channels are managed with an audio mixer, much the same as for your Windows sound card(s). To configure the audio mixer, click on **Mixer** on the Front Console menu (Figure 31).



*Figure 31: Audio Mixer*

Select the desired **Input** and **Output** channels. Only one Input channel can be selected, but multiple Output channels can be selected. **Mic** is the front panel microphone connector, whereas all other channels refer to the various audio inputs and outputs on the back panel. For more detailed information see page 148).

**Note:** The Internal Speaker output is unavailable for the FLEX-5000A, which has no internal speaker.

## Completely Factory Calibrated

The FLEX-5000 comes to you completely factory calibrated and therefore, unlike the SDR-1000, no further calibration is usually required. If due to some unlikely event you suspect your radio needs to be recalibrated, please contact [FlexRadio Support](#), (on our Website, select About FlexRadio and then Contact Us) who will guide you through the process.

You are now ready to use your FLEX-5000. Click on **Start** on the Front Console and you should hear receive audio. If you do not, double check all your connections and settings (especially for the Mixer and Antenna forms).

We urge you to read the remainder of this manual to help you fully understand the FLEX-5000 and PowerSDR. This will enable you to optimize your radio for your personal operating style and environment. You may also want to visit our extensive and ever expanding [Knowledge Center](#) (<http://kc.flex-radio.com/search.aspx>) for more detailed and more up-to-date information on many topics.


**Note:**

Experienced PowerSDR users may also find it beneficial to read the remainder of this manual, as the FLEX-5000 has several options and settings in PowerSDR unavailable to the SDR-1000. Especially new are the Mixer, Antenna and ATU forms.

[The rest of this page has been left blank intentionally]

# Front Console

In this chapter and those following many types of software controls will be referred to. The myriad of various bells and whistles can sometimes be a bit overwhelming. Figure 32 below is a key that will help to introduce the basic controls for those less familiar with windows software.



*Figure 32: Control Key*

- ❑ The **Form** refers to the entire window with the **Title Bar** showing the Form Name.
- ❑ The **Menu** is just under the Title Bar. Menu controls generally open other forms.
- ❑ **Labels** are callouts usually for other controls.
- ❑ **Buttons** can trigger events or act like an On/Off switch.
- ❑ **Text Boxes** allow text to be entered or displayed.
- ❑ **Radio Buttons** allow the user to choose between several options.
- ❑ **Drop Down Boxes** (also called Combo Boxes) enable the ability to offer many options without taking up as much window space as a Radio Button.
- ❑ **Sliders** allow easy modification of a numerical value.
- ❑ **Color Buttons** are used as color selectors. You can pick a generic color (yellow or green) or even make your own using the drop down menu.
- ❑ **Up/Down** controls are similar to a Text Box, but are limited to numeric input. They also have arrows for simple increment/decrement behavior.

[The rest of this page has been left blank intentionally]




Figure 33: PowerSDR 1.14.0 Front Console

- Note 1:** The front console controls the basic functions of the radio: frequency, mode, filters, and display. In addition to these basic features, there are many other controls that are described in detail below. The exact behavior of many of these controls can be configured with the Setup Form.
- Note 2:** The lower part of the front console will only be visible if you have the second receiver (RX2) installed.
- Note 3:** Corresponding main and second receiver control identifiers have corresponding numbers, with the latter appended by the letter b.

**Hint:** Hovering with your mouse over any control will show a brief description of that control's function.

## (1) VFO A




Figure 34: VFO A

VFO A is the main tuning VFO for the primary receiver RX1 and the transmitter. It consists of a frequency and a band description (related to the selected frequency). VFO A (and VFO B see below) act slightly differently, depending on whether the secondary receiver RX2 is on or not:

- When RX2 is **off** (or not installed), VFO A is the the main tuning VFO and VFO B tunes the primary receiver's secondary (split transmit or multiRX) frequency.
  - With Split off, the transmit frequency is displayed in VFO A (VFO A **TX** indicator is red)
  - With Split on, the transmit frequency is displayed in VFO B (VFO B **TX** indicator is red)

**Note:** Split and MultiRX are only available for the primary receiver RX1.

- When RX2 is **on**, VFO A is exclusively dedicated to RX1 (and VFO B to RX2). As can be seen in Figure 34 above, in this case the RX1 split transmit or multiRX frequency is shown as a sub-frequency in the lower section of the display, where otherwise the band description would be.<sup>1</sup>
  - Clicking on the **TX** indicator in VFO A or VFO B will switch the transmit frequency to either the RX1 (VFO A) or RX2 (VFO B) frequency.
  - If **Split** is on, the RX1 transmit frequency is the VFO A sub-frequency, displayed in red.


The upper frequency area of the VFO is a Text Box and may be edited as such (click and drag highlighting, etc).The same holds for the lower area, when it displays a frequency instead of a band description. The upper area may also be changed by entering a numeric character (without any mouse interaction). An underline will indicate the digit that will be tuned when hovering over the frequency display. **See the Tuning Methods on page 158 for more details on how to tune.** Note that when

<sup>1</sup> The band text returns by turning RX2 off, or leaving RX2 on, but turning split and/or multiRX off.

using the keyboard to enter a frequency, you can return to the previous frequency at any time by pressing the 'Escape' (Esc) key before you press the Enter key.

The band text information below the frequency gives general information about the FCC Amateur bands as well as the Short Wave Radio bands and WWV. If not on a recognized frequency, the text will display "Out Of Band". If not in an amateur band, the text background will change from black to gray. Note that this information is only a lookup in a database and has no bearing on the current operating mode. The band text information can be edited in the BandText table using Microsoft Access.

## (2) Tuning Controls



*Figure 35: Tuning Controls*


**VFO Sync** keeps VFO B synchronized to VFO A. This can be especially useful when using both RX1 and RX2 for diversity reception.

**VFO Lock** keeps the frequency from being changed inadvertently. This is a handy feature to use while in a QSO to keep from accidentally losing the frequency due to clicking in the wrong area or hitting the wrong key on the keyboard.

The **Tune Step** displays the current tuning rate when using the mouse wheel (or Ctrl + Up/Down Arrow) to tune the radio. Rotating the mouse wheel away from you will increase the frequency by the step rate per click while rotating the wheel toward you will decrease the frequency. You can change the Tune Step by clicking either of the **-** or **+** buttons, clicking the mouse wheel button (or using Ctrl + Left/Right Arrow).

The **Save** button quickly saves a frequency, mode and filter. The saved frequency is shown in the box to its left. The **Restore** button restores the most recently saved frequency (displayed), mode and filter.

## (3) VFO B




*Figure 36: VFO B*

The operation of VFO B is similar to that of VFO A. However, VFO B is used only in specific instances.

- ❑ Without RX2 installed or with RX2 installed but **Off**:
  - VFO B displays in red the transmit frequency when operating split (**SPLT** button active).
  - VFO B displays in yellow the second receive channel's frequency when activating the multi receive function (**MultiRX** button active). Otherwise, it can be viewed as a storage container to copy VFO data to and from VFO A (see the VFO Controls section on page 71).
- ❑ With RX2 installed and **On**, VFO B tunes RX2 exclusively. In this case the RX1 split or multi RX frequencies are displayed in the lower section of VFO A (see above).
  - The red TX indicator identifies the transmit frequency. Clicking on the TX indicator of VFO A or VFO B will change the transmit frequency to either RX1 (VFO A) or RX2 (VFO B).

## (4 and 4b) Multimeters



*Figure 37: Primary (left) and RX2 (right) Multimeters*

The multimeter displays both digitally and graphically various RX and TX signal parameters as determined by the selection from the (two) drop down boxes at the top.

The text display below the meter selections shows the digital data for either the receiver or the transmitter (Signal strength in Figure 37 above). The lower display at the bottom of this section shows the data graphically as an edge meter. Alternatively a bar graph display can be selected (see the description of the Setup Form - Appearance Tab, Meter Sub-Tab on page 121).

## RX1 and RX2 Meters

- ❑ **Signal (Signal Level)**: Calculates the true RMS power in dBm of the current signal within the passband, as measured at the selected FLEX-5000 antenna port.
- ❑ **Sig Avg (Signal Average)**: Calculates the true RMS power in dBm of a time-averaged signal within the passband, as measured at the selected FLEX-5000 antenna port.
- ❑ **ADC L (Analog To Digital Left)**: Calculates the level in dBFS (decibel full scale) of the Left input from the internal I/Q ADC.
- ❑ **ADC R (Analog To Digital Right)**: Calculates the level in dBFS (decibel full scale) of the Right input from the internal I/Q ADC.

- ❑ **ADC2 L (Analog To Digital RX2 Left):** If the second receiver RX2 is installed, calculates the level in dBFS (decibel full scale) of the Left input from the internal I/Q ADC for RX2. If RX2 is not installed, displays -200.
- ❑ **ADC2 R (Analog To Digital RX2 Right):** If the second receiver RX2 is installed, calculates the level in dBFS (decibel full scale) of the Right input from the internal I/Q ADC for RX2. If RX2 is not installed, displays -200.
- ❑ **Off:** Used for debugging purposes or to save CPU cycles on slower machines.

## TX Meters

- ❑ **Fwd Pwr (Forward Power):** Reads out forward power minus reflected power in Watts as measured by the internal ADC on the PA. The meter shows average power.

**Note:** In SSB, the typical male voice peak to average ratio is 14dB. This means that without the compressor and/or compander enabled an *average* meter will only read 4-10W (with a typical voice) when *peaking* at 100W.

With the ALC we are using the average power. With these controls, very high average power can be tolerated.


- ❑ **Ref Pwr (Reflected Power):** Reads out reflected power as measured by the internal ADC on the PA.
- ❑ **SWR (Standing Wave Ratio):** Reads out the standing wave ratio as calculated from the measured forward and reflected power. (Only available with TUN on)
- ❑ **Mic:** Reads modulation power from -20 dB to 3 dB. Ideal operation will peak around 0 dB and will rarely if ever hit 3 dB. If it is hitting 3 dB, the ALC is cutting back the power. Adjust the MIC control on the front console to give more or less modulation.
- ❑ **EQ:** Reads the power in dB following the equalizer, where 0dB is ideal. If the equalizer is not enabled, the equalizer power is equal to the Mic power.
- ❑ **Leveler:** Reads the power in dB following the leveler, where 0dB is ideal. The leveler attempts to level the voice coming from the microphone as the head and mouth change position relative to the microphone element. If the leveler is not enabled, this power is identical to EQ.
- ❑ **Lev Gain:** Reads the gain in dB currently being applied by the leveler.
- ❑ **ALC:** Reads the power in dB after the ALC, where 0dB is ideal.
- ❑ **ALC Comp:** Reads the gain in dB applied by the ALC algorithm. The gain is always  $\leq 0$  in dB. The minus sign is implicit.
- ❑ **CPDR:** Reads the power in dB after the compander, where 0dB is ideal. If the compander is not enabled, it reads the same as Comp.



- ❑ **Off:** Used for debugging purposes or to save CPU cycles on slower machines.

The **TX** meters **Mic**, **EQ**, **Leveler**, **CPDR** and **ALC** show either peak or true RMS values, depending on whether TX meter is set to use peak readings for DSP Values (see Setup Form – DSP Tab on page 99)

## (5 and 5b) Band Selection & Band Stacking Memories



*Figure 38: Primary (left) and RX2 (right) Band Selection*

The Band Selection controls perform multiple roles in PowerSDR. First, when tuning the VFO to a specific frequency the band indicator will move to the appropriate band (GEN if not in one of the specific bands listed). This is used to quickly identify which band you are in, or when you are stepping over a band edge boundary. The RX1 band is displayed in yellow, and (if installed and on) the RX2 band is displayed in green, or red if it is also the transmit band (see Figure 38).

Secondly, clicking on one of the Band Selection buttons (5) will change the frequency, mode and filter to the one last used on that band for RX1. At this stage, the same is not true for RX2, when selecting a band from the RX2 band drop down list.


The third role is a feature called Band Stacking Memories (RX1 only). A single memory is defined as a frequency, mode, and filter combination. Each band has several memories associated with it. Clicking on a band button repeatedly will cycle through the available memories repeating from the beginning after the last memory (hence the stacking memories). This is useful to quickly tune to various frequencies within a band. To replace one of the memories with the frequency, mode, and filter of your choice, first click the band button for the band memory you would like to modify. Then change the frequency, mode, and filter to the desired settings (the frequency must be in the band selected). Finally click the band button again to save the values.

The modified memories will be saved to the database upon graceful exit of the console. A crash will prevent changed memories from being saved in order to keep faulty data from making it into the database.

**Note :** Some band memory frequencies (such as 60m and WWV) are fixed in software and cannot be changed.

The **VHF+** button (RX1 only) will swap between the typical HF bands and any configured transverter bands (see the description of the XVTRs Form on page 141). The VHF band buttons work in the same way, but for the frequencies within the transverter frequency range.

## (6 and 6b) Mode Selection



*Figure 39: Primary (left) and RX2 (right) Mode Selection*

The Mode Selection controls allow you to change the selected demodulation routine. Changing modes will select the last frequency and filter used for that mode. Additionally, it will display the (configurable) filter settings available for that mode (see Figure 41 below) as well as display the appropriate mode specific controls on the front console (see page 59). Following is a list of the available modes:

- ❑ **LSB:** Lower Side Band
- ❑ **USB:** Upper Side Band
- ❑ **DSB:** Double Side Band
- ❑ **CWL: CW Lower Side Band**
- ❑ **CWU: CW Upper Side Band**
- ❑ **FMN:** Frequency Modulation (FM) Narrow
- ❑ **AM: Amplitude Modulation**
- ❑ **SAM: Synchronous (PLL) Amplitude Modulation**
- ❑ **SPEC (RX1 only): Spectrum mode** (DC IF, max bandwidth determined by the selected sampling rate)
- ❑ **DIGL: Digital Lower Side Band** (Enables VAC if VAC Auto Enable is engaged, see page 93)
- ❑ **DIGU: Digital Upper Side Band** (Enables VAC if VAC Auto Enable is engaged, see page 93)
- ❑ **DRM: Digital Radio Mondiale** (requires licensed external demodulator software not available from FlexRadio Systems; Enables VAC if VAC Auto Enable is engaged, see page 93)

Hotkeys are available in the Setup-Form, Keyboard Tab to cycle through the various modes using the keyboard (see page 123).

[The rest of this page has been left blank intentionally]

## (7 and 7b) Filter Controls




Figure 40: Primary (left) and RX2 (right) Filter Controls

The filter controls consist of ten customizable, mode-specific, labeled filter buttons and two variable filter buttons.

### Labeled Filter Buttons


Clicking on any of the labeled buttons in the top half of the filter controls section sets the filter bandwidth. The available filters depend on the selected modulation mode. The 3 groups of default filter selections for CW (CWL, CWU), SSB (LSB, USB, DIGL, DIGU) and DSB (DSB, FMN, AM, SAM) are shown below. The SPEC (RX1 only) mode has no filters associated with it and the DRM filter is fixed at 12kHz.

	CW Default Filters	SSB Default Filters	DSB Default Filters																																				
RX1	Filter - 100 <table border="1"> <tr><td>1.0k</td><td>800</td><td>750</td></tr> <tr><td>600</td><td>500</td><td>400</td></tr> <tr><td>250</td><td>100</td><td>50</td></tr> <tr><td>25</td><td>Var 1</td><td>Var 2</td></tr> </table>	1.0k	800	750	600	500	400	250	100	50	25	Var 1	Var 2	Filter - 2.7k <table border="1"> <tr><td>5.0k</td><td>4.4k</td><td>3.8k</td></tr> <tr><td>3.3k</td><td>2.9k</td><td>2.7k</td></tr> <tr><td>2.4k</td><td>2.1k</td><td>1.8k</td></tr> <tr><td>1.0k</td><td>Var 1</td><td>Var 2</td></tr> </table>	5.0k	4.4k	3.8k	3.3k	2.9k	2.7k	2.4k	2.1k	1.8k	1.0k	Var 1	Var 2	Filter - 6.6k <table border="1"> <tr><td>16k</td><td>12k</td><td>10k</td></tr> <tr><td>8.0k</td><td>6.6k</td><td>5.2k</td></tr> <tr><td>4.0k</td><td>3.1k</td><td>2.9k</td></tr> <tr><td>2.4k</td><td>Var 1</td><td>Var 2</td></tr> </table>	16k	12k	10k	8.0k	6.6k	5.2k	4.0k	3.1k	2.9k	2.4k	Var 1	Var 2
1.0k	800	750																																					
600	500	400																																					
250	100	50																																					
25	Var 1	Var 2																																					
5.0k	4.4k	3.8k																																					
3.3k	2.9k	2.7k																																					
2.4k	2.1k	1.8k																																					
1.0k	Var 1	Var 2																																					
16k	12k	10k																																					
8.0k	6.6k	5.2k																																					
4.0k	3.1k	2.9k																																					
2.4k	Var 1	Var 2																																					
RX2	RX2 Filter - 500 <table border="1"> <tr><td>1.0k</td><td>800</td><td>750</td></tr> <tr><td>600</td><td>500</td><td>400</td></tr> <tr><td>250</td><td>Var 1</td><td>Var 2</td></tr> </table> Low -850 High -350	1.0k	800	750	600	500	400	250	Var 1	Var 2	RX2 Filter - 2.7k <table border="1"> <tr><td>5.0k</td><td>4.4k</td><td>3.8k</td></tr> <tr><td>3.3k</td><td>2.9k</td><td>2.7k</td></tr> <tr><td>2.4k</td><td>Var 1</td><td>Var 2</td></tr> </table> Low 150 High 2850	5.0k	4.4k	3.8k	3.3k	2.9k	2.7k	2.4k	Var 1	Var 2	RX2 Filter - 6.6k <table border="1"> <tr><td>16k</td><td>12k</td><td>10k</td></tr> <tr><td>8.0k</td><td>6.6k</td><td>5.2k</td></tr> <tr><td>4.0k</td><td>Var 1</td><td>Var 2</td></tr> </table> Low -3300 High 3300	16k	12k	10k	8.0k	6.6k	5.2k	4.0k	Var 1	Var 2									
1.0k	800	750																																					
600	500	400																																					
250	Var 1	Var 2																																					
5.0k	4.4k	3.8k																																					
3.3k	2.9k	2.7k																																					
2.4k	Var 1	Var 2																																					
16k	12k	10k																																					
8.0k	6.6k	5.2k																																					
4.0k	Var 1	Var 2																																					

Figure 41: Default Mode Dependent Filters

Each of the 10 (7 for RX2) labeled filter buttons can be customized for any of the modes. To do so, right click on a filter button and select **Configure...** to bring up the screen shown in Figure 42.

[The rest of this page has been left blank intentionally]



*Figure 42: Filter Setup Screen*

On the left, select the **Mode** for which to setup the filter and select the filter button to change. Then on the right adjust its settings. An indication of the filter is displayed in the lower section of this screen, which can be dragged as a whole, or the edges of which can be dragged as an alternative way of adjustment. When done, you can select another button and/or mode to change the filter for. When finished, just close the Filter Setup Screen. To revert back to the default settings, right click on a filter button, select **Reset to Defaults** and click **Yes**.

**Note:** Although there are 3 groups of mode-dependent default filter settings, you can customize the labeled filter for each mode independently. E.g. you can have different filters for LSB and USB, for FMN and AM, etc.

## Variable Filter Buttons

The variable filter buttons **Var 1** and **Var 2** offer two separate filters, each of which can be adjusted with the **Low**, **High** and for RX1 also with **Width**, **Shift** and **Res** controls described below as well as the mouse. The Panadapter display setting is good for visualizing changes to variable filter controls

- ❑ **Low:** Selects the low cutoff frequency for the filter. The value is the plus or minus offset from the center frequency as shown in the VFO display. Note that in lower side band modes (LSB, CWL and DIGL) this value can be negative.
- ❑ **High:** Selects the high cutoff frequency for the filter. Note that in lower side band modes (LSB, CWL and DIGL) this value can be negative.
- ❑ **Width:** Widens the filter as the slider is moved right, and narrows the filter as it is moved left. The behavior of this control is set in the Setup Form – General Tab, Filter Sub-Tab (page 88).
- ❑ **Shift:** Shifts the selected filter passband up or down from its normal center frequency. This can help to eliminate interference caused by signals in close proximity of the received signal. The behavior of this control is set in the Setup Form – General Tab, Filter Sub-Tab (page 88).

- After a variable filter (**Var 1**, **Var 2**) has been shifted you can use the **IF→V** button to translate a filter shift to a new VFO frequency (see the VFO Controls section on page 71)
- **Res:** Returns the **Shift** control to the default middle position and restores the filter to its original position (i.e. before the **Shift** was used).
- When the display is set to Panadapter, the mouse can be used to directly adjust the selected variable filter (**Var 1** or **Var 2**). To do so right click with the mouse on the Panadapter display until no cross-hairs are showing. Then click on the filter and drag it to shift the filter as a whole or click on a band edge and drag it to adjust the filter bandwidth.


The **Var 1** and **Var 2** filters are saved just like the labeled filters and are mode-dependent (i.e. you can save a different **Var 1** filter for **LSB** than for **AM**). Hotkeys are available in the Setup Form-KeyBoard Tab (described on page 123) to change the filters using the keyboard.

## (8) Mode Specific Controls

This section of the front console displays key controls specific to the selected modulation mode. There are three sets of controls: Phone, CW and Digital.

### Phone Controls

The phone controls, shown below, are available for all phone modes (LSB, USB, DSB, FMN, AM and SAM). Most of these controls can also be found on the Setup Form-Transmit Tab (see page 111, where a more detailed description may also be found)



*Figure 43: Mode Specific Controls - Phone*

- **Mic Gain:** adjusts the software microphone gain. This is a simple multiplier applied to the input samples when in transmitting. The control can be adjusted using either the slider or the text box. Note that increasing the MIC Gain control will also raise the amount of noise in the signal. A hardware preamp will give the best performance for amplifying microphone signals. Having said that, the software gain works very well in many setups. Voice modes are typically optimized when the peak reading on the TX Mic Meter reads just below 0dB (see page 54 above)
- **DX:** click to enable the DX compander (a form of compression), which has been optimized to give your voice an extra punch, especially useful in DX situations. Adjust its level with either the slider or the text box.

- ❑ **CPDR:** click to enable the compander and adjust its level with either the slider or the text box.
- ❑ **VOX:** click to enable the VOX and adjust its level with either the slider or the text box. See also the Setup Form-Transmit Tab (page 113). When enabled, a bar graph will show just below the slider control. The green part of this bar graph shows the portion of the sound level that will not activate the transmitter; the red part the portion that will. VOX should be adjusted such that ambient noise will not activate the transmitter, but a normal voice will.
- ❑ **GATE:** click to enable the Noise Gate and adjust its level with either the slider or the text box. See also the Setup Form-Transmit Tab (page 113). When transmitting, a bar graph will show just below the slider control. The green part of this bar graph shows the portion of the sound level that will not open the Noise Gate; the red part the portion that will. The level should be adjusted such that ambient noise will not open the Noise Gate, but a normal voice level will.


**Hint:** The Noise Gate can (and should) be enabled in all situations where ambient noise will render your transmissions less clear, irrespective of whether VOX is engaged.

- ❑ **Transmit Profile:** select the transmit profile to use for phone transmissions. The default profiles are **Default** and **Default DX**. See also the Setup Form-Transmit Tab (page 111)
- ❑ **Show TX Filter on Display:** when checked, the band edges of the transmit filter, set on the Setup Form-Transmit Tab (page 112) will be shown as 2 yellow lines on the display when set to Panadapter. It can be an especially useful visual aid when operating split to position your transmit frequency where desired (in a pile-up) using VFO B (or VFO A sub-frequency when RX2 is on). Additionally, it will give you a quick visual impression of whether your transmit filter needs to be adjusted or not.
- ❑ **RX EQ:** activates either the receive three-band or ten-band equalizer. See also the Equalizer form described on page 139.
- ❑ **TX EQ:** activates either the transmit three-band or ten-band equalizer. See also the Equalizer form described on page 139.
- ❑ **VAC:** activates *Virtual Audio Cable* (<http://software.muzychenko.net/eng/>), a third party program (written by Eugene Muzychenko) to enable digital audio transfer between PowerSDR and other third party (digital) programs. See also the Setup Form – Audio Tab, VAC Sub-Tab described on page 92. VAC is not automatically enabled for phone modes, even if **Auto Enable** has been checked on the VAC Sub-Tab.

## CW Controls

The CW controls, shown in Figure 44 below are available when either CWL or CWU is selected. Most of these controls can be found on the Setup Form-DSP Tab, Keyer Sub-Tab (see page 106, where you can also find a more detailed description).

[The rest of this page has been left blank intentionally]



*Figure 44: Mode Specific Controls - CW*


- ❑ **CW Speed:** sets the CW speed when using the internal keyer in Iambic mode. Adjust the speed with either the text box or the slider.
- ❑ **Iambic:** check to set the internal keyer to Iambic mode (see also page 107)
- ❑ **Disable Monitor:** check to disable the monitor (this can be useful when using an external keyer).
- ❑ **Show CW TX Frequency:** check to show the CW TX frequency as a single yellow line when the display is set to Panadapter. It can be an especially useful visual aid when operating split to position your transmit frequency where desired (in a pile-up) using VFO B (or the VFOA sub-frequency when RX2 is on).
- ❑ **Pitch Freq (Hz):** sets the desired audio frequency for CW listening at the center of the CW filters. This will determine the offset that is applied to the carrier in receive and transmit. The display will continue to read the actual carrier frequency, but the software will provide for an offset to get the desired CW tone. This pitch will determine the automated tuning frequency using the display and mouse ClickTune™<sup>1</sup> functions.
- ❑ **VAC:** click to enable *Virtual Audio Cable* (<http://software.muzychenko.net/eng/>), a third party program (written by Eugene Muzychenko) to enable digital audio transfer between PowerSDR and other third party (digital) programs. See also the Setup Form – Audio Tab, VAC Sub-Tab described on page 92. VAC is not automatically enabled for CW modes, even if **Auto Enable** has been checked on the VAC Sub-Tab.
- ❑ **Break In:** check the **Enabled** box to activate Break In for the internal keyer. Set the delay in the **Delay** text box. See also page 108.

[The rest of this page has been left blank intentionally]

<sup>1</sup> ClickTune is a trademark of FlexRadio Systems.

## Digital Controls

The digital controls, shown below are available when either DIGL, DIGU or DRM is selected. These controls can mostly be found on the Setup Form- Audio Tab, VAC Sub-Tab (see page 92, where you can also find a more detailed description).



*Figure 45: Mode Specific Controls - Digital*


- ❑ **VAC:** click to enable *Virtual Audio Cable* (<http://software.muzychenko.net/eng/>), a third party program (written by Eugene Muzychenko) to enable digital audio transfer between PowerSDR and other third party (digital) programs. See also the Setup Form – Audio Tab, VAC Sub-Tab described on page 92. If **Auto Enable** (page 93) has been checked on VAC Sub-Tab, then VAC will automatically be enabled when either DIGL, DIGU or DRM is selected.
- ❑ **RX & TX Gain:** Adjust the gain for signals coming in and out of the VAC interface. Use the RX Gain control to adjust the audio level going to third party programs. (Note that for third party applications this control supersedes the front panel AF control). Similarly, use the TX control to adjust the volume of audio coming from third party applications (adjust for 0 dB on the ALC meter).
- ❑ **Sample Rate:** sets the sample rate of the VAC interface. This needs to be matched to your third party software sample rate.
- ❑ **Mono/Stereo:** sets the VAC interface to operate either mono or stereo. This can be of importance, depending on your third party software. (E.g. MixW requires the mono setting, whereas DREAM requires stereo).

## (9 and 9b) Display Controls

The main display controls, shown in Figure 46 below, consist of two sections: Screen adjustment controls and display selection controls. The former act on the screen as a whole, where as the later determine the display type to be used for RX1 (9) and RX2 (9b) respectively.

[The rest of this page has been left blank intentionally]





*Figure 46: Display Controls*

## Screen Controls

The screen controls adjust the view of the Panadapter or Waterfall display (see Figure 48 and Figure 50 below), they are not functional for any of the other display types.

- ❑ **Pan:** adjust the slider to pan the Panadapter or Waterfall display from left to right. Click on **Center** to quickly center the display.
- ❑ **Zoom:** adjust the slider to zoom in on or out of the display. Additionally click on either on of the 4 buttons to the right to quickly zoom to the labeled setting. (The maximum frequency span of the Panadapter or Waterfall is dependent on the audio sample rate setting)

## Display Selection Controls

The main display is able to visualize received (and transmitted) signals in various ways (display types), which can be selected from the list boxes for RX1 and RX2 respectively. These various display types are detailed below with a snapshot of each type. The sampling rate (Frames Per Second, FPS) of the main display can be modified on the Setup Form-Display Tab (see page 96).

- ❑ **AVG (Average):** click to view time-averaged signals. This will smooth fast-changing signals and is a good way to separate real from stochastic (noise) signals. The averaging time can be set on the Setup Form-Display Tab (see page 98). **AVG** must be enabled for the **0 Beat** VFO Control to be available.
- ❑ **Peak:** click to hold the peak value for each frequency in the display.

## Display Type Descriptions

**Note:** The actual display in PowerSDR is crisper than the compressed images shown below.

For RX1 there are six frequency domain display types (Spectrum, Panadapter, Histogram Waterfall, Panafall™<sup>1</sup> and Panascope™<sup>2</sup>) and three time domain display types (Scope, Phase and Phase2). Panafall and Panascope are only available when RX2 of off (or not installed). For RX2 the choice is


<sup>1</sup> Panafall is a trademark of FlexRadio Systems.

<sup>2</sup> Panascope is a trademark of FlexRadio Systems.

limited to either Panadapter or Waterfall. All the colors used in the display (text, data line, background, etc) are completely customizable using the Setup Form-Appearance Tab, Display Sub-Tab (page 116).

We will now first discuss the display types for RX1 only, followed by the combination of RX1 and RX2.

## *Spectrum*



*Figure 47: Spectrum Display*

The Spectrum Display shows a classical spectral view of the frequency with the ends of the display determined by the bandwidth of the filter. The scale across the top shows the frequency offset in Hz from the VFO A frequency. Rather than only using half the display window when in lower or upper sideband, we expand the display moving the 0Hz line to the left or right margin (1.2kHz tone in USB mode with a 2.7kHz filter shown).

## *Panadapter (Panoramic Adapter)*



*Figure 48 Panadapter Display*


The Panadapter Display is similar to the Spectrum Display with several differences.

- The maximum display width is a function of the selected sampling rate, no matter what filter bandwidth is selected.

- ❑ The selected filter is displayed as an overlay to help the user visualize the filter. Shown are the main RX filter (green, VFO-A), the MultiRX filter (blue, VFO-B) and the TX filter edges (yellow vertical lines). The color of all the filter overlays can be changed independently using the Setup Form-Appearance Tab, Display Sub-Tab (page 116).
- ❑ The frequency scale shows the actual frequency (in MHz).
- ❑ The edges of the amateur bands are marked as red vertical lines and the corresponding frequencies are displayed in red
- ❑ With the mouse, filters and filter edges can be varied by dragging and dropping
- ❑ Point click tuning is available with mouse and cross hairs showing.

The Panadapter is useful because although you hear only the signals within the audio passband, you can see in real time all signals within the receiver's passband (as determined by the sampling rate). This gives a much more complete picture of the surrounding area in the band, especially when there is abundant signal activity (e.g. contest and DX situations).

### *Histogram*



*Figure 49: Histogram Display Mode*

The Histogram Display is similar to the Spectrum Display, but instead of a single color data line, additional colored data is used. Blue signals are real-time (current) signals that are below a signal threshold (roughly below the average plus a small margin). The red signals are real-time (current) signals that are above that same threshold. The green signals are previous peaks on that same frequency that will fade as time goes by (a type of history, hence the name).

[The rest of this page has been left blank intentionally]

## Waterfall




*Figure 50: Waterfall Display*

The Waterfall Display shows a scrolling view of activity within the receiver's passband (as determined by the sampling rate). This makes tracking narrow band signals much easier and can even allow visualization of CW signals at slower speeds (longer line is a dash, short line is a dot, no line is a pause).

- ❑ Across the top the audio passband filters are displayed, similar to the panadapter.
- ❑ The filter widths and positions can be adjusted with the mouse, similar to the panadapter.
- ❑ All mouse tuning methods available in the panadapter are also available in the waterfall.
- ❑ The frequencies corresponding to the Amateur band edges are displayed in red.
- ❑ The Waterfall Display can be customized on the Setup Form- Display Tab This allows custom setting of the dynamic range and coloring for the display. (See the Setup Form-Display Tab on page 97 for more details.)

[The rest of this page has been left blank intentionally]


## Scope



*Figure 51: Scope Display*

The Scope Display shows the received or transmitted audio signal in the time domain. Shown is an SSB signal. The Scope Display is particularly useful when transmitting to monitor your audio waveform, e.g. to see the effects of DX (page 59) or equalization (page 139). The time base can be adjusted on the Setup Form- Display Tab (see page 98).

## Phase



*Figure 52: Phase Display*

The Phase Display maps the filtered I and Q (Left and Right) channels to the X and Y coordinate planes. This is useful for making sure the two channels are 90 degrees out of phase as they should be. There is also a **Phase2** Display that maps the unfiltered data directly from the ADC. When a continuous carrier signal is received, the unfiltered data in the Phase2 Display should produce as near to a perfect circle as possible. If the circle distorts into an oval or a straight line, the input phase is off balance which would indicate a connection or hardware problem.

[The rest of this page has been left blank intentionally]

### *Panafall*

This display is a combination of the Panadapter and the Waterfall displays described above. It is only available when the second receiver RX2 is off.

### *Panascope*

This display is a combination of the Panadapter and the Scope displays described above. It is only available when the second receiver RX2 is off.

### *Off*

In this setting the display is turned off. It is mainly used for debugging purposes, but can also be used with slower systems to decrease the CPU load to more reasonable levels.

### *RX2 Display*

With RX2 installed and on, the RX2 available display types are Panadapter and Waterfall. The screen then shows the RX1 display type above the RX2 display type, as illustrated in Figure 53.



*Figure 53: Combined RX1 Panadapter and RX2 Waterfall Display*

### *Cursor and Peak Position*

There are two sets of data side by side under the display that are used to communicate cursor (left) and peak signal (right) information to the user. For each the data shown equals Offset from VFO, Signal Level and Frequency. For example, in Figure 54 below, the peak signal is offset -8639.4 Hz from the VFO frequency (14.187 MHz). The peak signal level is -81.6 dBm, and the peak signal is at 14.178361 MHz. Note that these values are fairly low resolution due to the discrete nature of the pixel display. When RX1 and RX2 displays are both showing, the cursor position read-out relates to the respective display the cursor is in, either the RX1 (upper) or RX2 (lower) display.

[The rest of this page has been left blank intentionally]



*Figure 54: Cursor and Peak Position Information*

- ❑ In the frequency domain displays (Spectrum, Panadapter, Histogram, Waterfall), right clicking the mouse cycles through yellow crosshairs, red crosshairs (only if **SPLT** or **MultiRX** is enabled), or no crosshairs. The crosshairs span the width and height of the display (yellow cross hairs are shown in Figure 54 above).
- ❑ Together with the **AVG** control they allow easy measurement of signals on the display. For example, in Figure 54 the cursor position is offset -10230.3 Hz from the VFO frequency and is at 14.176770 MHz. Its "level" is at -80.6 dBm.
- ❑ Another feature of the crosshairs is ClickTuning. Clicking the left mouse button with the yellow crosshairs visible tunes VFO A (and for RX2 VFO B) to the frequency indicated by the cursor position data (or if Snap ClickTune is on (see page 85), to the nearest multiple of the Tune Step). The red crosshairs tune VFO B if RX2 is either not installed or off, or the lower section of VFO A (see page 51). This is an excellent way to tune CW signals as it will zero beat the tone to the set CW pitch.

## (10) MultiRX Controls

The MultiRX controls, shown below, allow you to enable a second receive channel for RX1 only within the receiver's passband, which is determined by the audio sample rate setting. Both the primary and the secondary receive channel can be positioned independently in the audio spectrum to facilitate separating the two signals in your head.



*Figure 55: MultiRX Controls*

Click **MultiRX** to enable the second receive channel. The second receive channel will be tuned to the frequency shown in either VFO B if RX2 is not installed or off, or in the lower section of VFO A if RX2 is on (see page 51). In the Panadapter and Waterfall Displays, its passband is shown in blue, but only if it

is within the range of the Panadapter/Waterfall. Use the upper and lower horizontal sliders to position the primary and secondary channel respectively anywhere in the left-right audio spectrum. Use the left and right vertical sliders to adjust their respective volumes. Check **Swap** to swap the audio between the left and right speakers.


**Hint 1:** In split operation you can use the secondary receive channel to listen to the pile-up, while using the primary receive channel to listen to the DX.

**Hint 2:** With the second receiver RX2 installed and on, you can also use these controls to adjust the volume L/R position of RX1 and RX2 independently. To do so, deactivate **MultiRX** and activate **RX2**. The left vertical slider will then adjust the RX1 volume only and the right slider RX2 volume only. Use the 2 horizontal sliders to position RX1 and RX2 independently anywhere in the L/R audio spectrum.

Although you can manipulate the RX2 audio separately with the **RX2 Audio Controls** (see Figure 62 on page 76), you can only manipulate the RX1 audio independently using the MultiRX controls.

**Hint 3:** If you activate **MultiRX** and **RX2** simultaneously, these vertical sliders will effect both the RX2 audio and the second RX1 channel audio simultaneously. You can then also use the **RX2 Audio Controls** for RX2 to adjust it independently (see Figure 62 on page 76).

## (11 and 11b) DSP Controls



*Figure 56: DSP Controls*

These controls enable the DSP functions. The first four are described in detail in the Setup Form-DSP Tab, Options Sub-Tab (see page 99); SR is described in the Setup Form-General Tab, Options Sub-Tab (page 84).


- ❑ **NR (DSP Noise Reduction):** Activates the DSP Noise Reduction algorithm (see page 99).
- ❑ **ANF (Automatic Notch Filter):** Activates the Automatic Notch Filter algorithm.
- ❑ **NB (Impulse Noise Blanker):** Activates the Noise Blanker algorithm (see page 102).
- ❑ **NB2 (Mean Rank Noise Blanker):** Activates the Mean Rank Noise Blanker algorithm (see page 102).



- ❑ **SR (Spur Reduction):** Activates the Spur Reduction algorithm (see page 84).
- ❑ **BIN (Binaural Audio):** Activates the Binaural algorithm. Binaural audio is a special feature of PowerSDR. It generates a pleasing effect as the two phased channels (I and Q) are mapped to the left and right audio channels. The phasing of the demodulated and filtered audio signal within the passband gives a stereo-like, spatial effect to the received signal. When tuning across CW signals, they will seem to move in “space” as you tune the radio. Many experienced operators feel that binaural audio gives them a competitive advantage under contest conditions where the effect allows them to more easily pick signals out of a pile up. Wearing headphones increases the effect of the spatial separation.

**Note:** **BIN** is not available when operating **FMN**, **AM** or **SAM**.

## (12) VFO Controls



*Figure 57: VFO Controls*

These controls are only available for the main receiver RX1.

- ❑ **SPLT (Split):** Enables Split operation using VFO B (or the lower section of VFO A if RX2 is on, see page 51) for the transmit frequency. The frequency text in VFO B (or lower part of VFO A) will turn red to indicate that it is the transmit frequency.
- ❑ **0 Beat:** Centers the signal peak within the RX1 filter passband. An exception is made in CW mode if the CW Pitch is within the passband. In this case, the signal is tuned to the CW Pitch.

**Note:** **0 Beat** is only available if **AVG** is enabled for the Display.

- ❑ **IF→V:** Translates any offset created by Filter **Shift** and shifts it back to baseband. Useful when chasing a signal with the Filter **Shift** control (see also page 58).
- ❑ **A >B:** Transfers the contents of VFO **A** to VFO **B** (frequency, mode, and filter). If RX2 is on, this tunes RX2 to the same frequency RX1 is on.
- ❑ **A <B:** Transfers the contents of VFO **B** to VFO **A** (frequency, mode, and filter). If RX2 is on, this tunes RX1 to the same frequency RX2 is on.

- ❑ **A<>B:** Swaps the contents of VFO **A** and **B** (frequency, mode, and filter). If RX2 is on, this swaps the frequencies RX1 and RX2 are tuned to.
- ❑ **XIT (Transmit Incremental Tuning):** Click to enable XIT. XIT may be used as a quick way to operate split at a specific offset. When enabled, the transmit frequency is increased from the VFO A frequency by the amount shown in Hz while leaving the receive frequency intact. With **SPLT** activated, XIT modifies the VFO B (or lower part of VFO A if RX2 is on) frequency. Click the **0** button next to the XIT button to clear the XIT control to 0.
- ❑ **RIT (Receive Incremental Tuning):** Click to enable RIT. When enabled, the receive frequency is increased from the VFO A frequency by the amount shown in Hz while leaving the transmit frequency intact. Click the **0** button next to the RIT button to clear the RIT control to 0.

## (13) CPU %

This displays the total CPU load as seen in the Windows Task Manager under the Performance Tab. Note that running other applications will cause the CPU load to increase. If your CPU load is peaking at close to 100%, audio and possibly video artifacts will become noticeable. In this case closing additional applications and turning down some of the functions may improve the performance.

## (14) Start/Stop Button

Click **Start** to activate PowerSDR, click **Stop** to deactivate it. As Figure 58 shows, the button also acts as a RX/TX indicator.



*Figure 58: Power Button States*

**Note:** Please see also the Power-Up/Down procedures described on page 156 for information on best practices.

## (15) MON (Monitor)

When enabled, the transmitted audio is monitored through the receiver's speakers. The MON function is not available in AM, SAM, or FM modes as those modes are transmitted at the Intermediate Frequency (IF, usually 9kHz). In voice operation the **MON** feature will allow you to hear the effects of MIC gain, TX equalization, compression and compansion and to adjust them in real time. The **AF** control can be used to adjust the monitor volume.

[The rest of this page has been left blank intentionally]

## (16) MOX (Manually Operated Transmit)

When enabled MOX activates the transmitter. It is used primarily for voice operation. MOX will not generate a CW carrier. To generate a carrier for tuning, refer to the tune (**TUN**) button description on page 73.

**Note 1:** If the radio ever seems like it is stuck transmitting, try disabling the Push-To-Talk (PTT) function by selecting **Disable PTT** on the Setup Form-General Tab, Options Sub-Tab.

**Note 2:** To use PowerSDR without any hardware attached to the PC you must disable PTT. On the Setup Form-General Tab, select either **Disable PTT** on the Options Sub-Tab, or **Demo/None** on the Hardware Config Sub-Tab

## (17) MUT (Mute)

This button Mutes the speaker audio. (If RX2 is installed and on, it will mute both RX1 and RX2.) The receiver(s) may also be muted by pressing the \* (asterisk) key on the keyboard.

## (18) Rec (Record) and Play

The **Rec** and **Play** buttons offer a quick and easy way to record and play back a signal audible on the main receiver RX1. Click **Rec** to record a signal and click **Rec** again to stop recording. Once recorded, the signal can be played back by clicking **Play**. Subsequently clicking **Rec** will overwrite any audio file previously recorded in this way. The **Rec** and **Play** buttons are the same as the **QuickRec** and **QuickPlay** buttons on the **Wave Form** (see page 137)

**Note:** The audio file is saved as SDRQuickAudio.wav in the same directory where your PowerSDR.exe file resides. The saved file contains post-processed audio, and can be played back with any wav file player.

## (19) TUN (Tune)

- ❑ Without the automatic antenna tuner (ATU), **TUN** transmits a continuous (CW) carrier at the level set with the **Tune Power** control (default 10W) on the Setup Form-Transmit Tab (page 111) and outputs a tone at the CW Pitch. This power is shown on the **Drive** control while **TUN** is activated. Any changes to the **Drive** control while **TUN** is active are saved when the **TUN** button is turned off. This feature is used to simplify the antenna tuning process for proper load matching.
- ❑ With the ATU, **TUN** activates the ATU tuning function. When the ATU is in Bypass, the **TUN** function operates just as if the ATU were not present.

**Note:** The **TUN** button will stay enabled after a tune cycle where the ATU is set to Memory or Full. The button will become deselected when the ATU is bypassed, whether it be due to tuning to another band or manually selecting Bypass in the **ATU** Form (see page 153).

## (20) ATU and BYP

Click **ATU** to activate the Antenna Tuning Unit (ATU) and place it in Semi-Automatic mode. Click **BYP** to bypass the ATU. See also the description of the ATU Form on page 153.

## (21) AF (Audio Frequency Gain)

This control sets the audio gain. If RX2 is installed and on, it sets the combined gain of the RX1 and RX2 audio. To adjust the RX1 audio independently, use the MultiRX controls (see page 69), or the RX2 Audio Controls (see Figure 62 on page 76).

The AF gain may also be adjusted by pressing the **+** (plus) and **-** (minus) keys on the numeric keypad. For best performance of the FLEX-5000A, or FLEX-5000C when using an external speaker, set the external speaker volume control to the high end of the scale so that the AF control can be set to a lower value.

## (22 and 22b) AGC-T (AGC Maximum Gain)

These controls set the *maximum gain* of the AGC for RX1 and RX2 respectively. It is the same control as can be found on the Setup Form-DSP Tab, AGC/ALC Sub-Tab (page 109). The operational use of the AGC control is essentially the same as that of an RF gain control found in more traditional receivers.

**Hint:** For optimal use, set the **AGC** control such that the band noise level is comfortable, yet weak signals still jump out of the noise. Then adjust the **AF** control to comfortably hear the received signal. See also Appendix C and the Knowledge Center article [How to Effectively Use the PowerSDR 1.x AF\[Gain\] and AGC\[Threshold\] Controls](#) (search for AF AGC in our Knowledge Center at <http://kc.flex-radio.com/search.aspx>)

## (23) Drive (Transmitter Power Output/Tune Power)

This control adjusts the percentage of maximum power that will be available when transmitting. The **Drive** control may be adjusted while either receiving or transmitting.

[The rest of this page has been left blank intentionally]

**Note:** The control doubles in function as the power level setting for the **TUN** (Tune) button described above. The Tune power may be adjusted while the **TUN** button is activated or by using the control on the Setup Form-Transmit Tab.

While great care is taken to ensure that this value is accurate and that selecting a **Drive** value will give approximately that amount when using the 100W PA, there are variances in the filter components and transmitter characteristics that make it difficult for this to be exactly right over the whole range (1-100).

## (24 and 24b) AGC (Automatic Gain Control)


These controls set, for each receiver RX1 and RX2 respectively, the Automatic Gain to one of the following settings: Fixd (Fixed or off), Long, Slow, Med (Medium), Fast, or Custom. The Custom setting uses the controls on the Setup Form-DSP Tab, AGC/ALC Sub-Tab (page 109), where also a more expansive explanation of the AGC can be found.

## (25 and 25b) Preamp

This control switches the 15dB preamp on or off. For the HF frequencies best results are achieved with the preamp on for the upper bands and off for the lower.

**Note:** The preamp is unavailable for the 160m band to avoid interference from the broadcast bands. However, you can either insert a dedicated preamp using the RX1 Out/In receive loop (see page 7), or connect one at a receive only antenna and configure the appropriate antenna selection with the Antenna Form (see page 149).

## (26 and 26b) SQL (Squelch)




*Figure 59: Squelch Controls*

The **SQL** button enables the Squelch function. The threshold can be set with either the value to its right or the slider below. The bar graph displays in green the signal level below the threshold (squelch closed) and in red above (squelch open: only the red level is audible with **SQL** enabled). Squelch can be very useful to remove all noise from CW signals, especially in narrow filter settings.

[The rest of this page has been left blank intentionally]


## (27) Antenna Selection Display



*Figure 60: Antenna Selection Display*

The antenna selection display can be a helpful reminder of which antenna ports are selected for the main receiver RX1, the transmitter TX and the secondary receiver RX2. These ports are selected using the Antenna Form, described on page 150).

## (28) Date/Time Display




*Figure 61: Date/Time Display*

The date and time display can be especially helpful when taking screenshots, but can also be a quick reference to UTC time for those of us who are "time zone challenged." Click inside the Date or Time area to cycle between *LOC* (Local Time), *UTC* (UTC Time), and *Off*.

## (29) RX2 On/Off

If RX2 is installed, this button will turn RX2 on or off.

## (30) RX2 Audio Controls



*Figure 62: RX2 Audio Controls*

These controls allow you to adjust the audio of the second receiver RX2, if installed.

- ❑ **Pan:** Move left or right to position RX2 anywhere in the left-right audio spectrum.
- ❑ **Vol:** Adjusts the RX2 audio volume relative to the total RX1 + RX2 audio gain. The latter is controlled with the **AF** slider (see above).

- **Mute:** Mutes the second receiver's audio.

## **(31) Setup Form**

The Setup Form contains numerous controls for everything from the hardware configuration to transmit settings. Please refer to the next chapter for more detailed information.

## **(32) – (39) Operating Forms**

Each of these items opens a form, which is used while operating. Please refer to the Operating Forms chapter below for more detailed information on each one.


[The rest of this page has been left blank intentionally]

## Setup Form

The Setup Form contains a vast assortment of controls and settings from hardware setup to detailed DSP options. These controls are available on Tabs of the Form. Due to space concerns, several of the Tabs (e.g. General, Audio and DSP) have been split into Sub-Tabs. Take care when changing the controls to pay attention which Tab (and Sub-Tab) you are on.

Along the bottom of the Setup Form are five global buttons. These are:

- ❑ **Reset Database:** This displays the warning shown in Figure 63. Click **No** to avoid resetting the database. Click **Yes** to reset the database, which entails closing PowerSDR, copying the database file PowerSDR.mdb to your desktop and deleting it from its current location. The next time you start-up PowerSDR it will automatically create a new, clean database and read the EEPROM data from your FLEX-5000 to the database.



*Figure 63: Reset Database Warning*

**Note:** The database saves all of the radio options and its current state. It also contains the data read from the EEPROM in your FLEX-5000. If you have used the default directory during installation as recommended, the database file will be in C:\Program Files\FlexRadio Systems\PowerSDR vn.n.n\. The database file is called PowerSDR.mdb.

[The rest of this page has been left blank intentionally]



- ❑ **Import Database:** Allows a backwards-compatible database to be imported. To import another database, click this button and then browse to the directory of the database to import. The database file is called PowerSDR.mdb. Double click this file and it will attempt to import all the settings. A confirmation message will let you know if the import was successful.
- ❑ **OK:** Saves the current values to the database and closes the form.
- ❑ **Cancel:** Reloads the values from the database into the Setup Form and closes the form. This button can be used to reverse unintended changes to the Setup controls.
- ❑ **Apply:** Immediately saves the current values to the database.

[The rest of this page has been left blank intentionally]

# General Tab

## Hardware Config Sub-Tab




Figure 64: Setup Form - General Tab, Hardware Config Sub-Tab

### FLEX-5000 Config

This section lists the S/N, installed Firmware version and the installed hardware boards of your radio.


- ❑ ATU and RX2, shown in Figure 64, will only be listed if indeed installed in the radio.
- ❑ RFIO will read HRFIO in later versions of the FLEX-5000. The HRFIO or RFIO board house the antenna switching matrix and the HRFIO has more capabilities than the earlier RFIO (see also page 150).

**Use Ext. Ref. Input:** Check this box if you have an external reference clock oscillator connected to the Ext Ref Input port on the back panel (see (10) in Figure 2 on page 6 and also page 9) and wish to use it.

### Receive Only

Check this box to use only the receiver, while disabling the transmitter. When checked, MOX, TUN and VOX will become unavailable on the Front Console and PTT (either via the MIC connector or the back panel PTT connector) will also not function.


**Radio Model**



*Figure 65: Radio Model Selection*

Use this selection to choose the hardware (if any) that is connected to the computer running the PowerSDR software. When the FLEX-5000 is selected, the center block shows its configuration. Displayed are the radio model and serial number, the firmware version and the serial numbers of the various internal circuit boards, except the ATU, which if installed is just marked as "Present".

**DDS**



*Figure 66: DDS*

DDS Stands for Direct Digital Synthesis. The DDS chip in the FLEX-5000 produces an analog sine wave at up to micro Hertz resolution. The DDS is used as a local oscillator to tune the radio.

- **Clock Offset:** Allows software corrections to be made manually if the DDS clock oscillator is not running at exactly 500MHz. Changing the clock offset will change the frequency calibration of your radio. Typically there will be no need to do so as the radio has been completely factory calibrated. However, as the radio ages, the oscillator frequency may change slightly.
  - To adjust the frequency calibration of your radio, first use the automatic Frequency Calibration controls described on page 87.
  - To manually adjust the frequency calibration of your radio, start the internal signal generator by opening the Setup Form, Tests Tab (page 129) and checking **Enable HW Signal Generator**. Select **DSB** mode and tune VFO A to the desired frequency. With **SPLT** turned off you should see a -25 dBm signal at the VFO frequency. Change the display to the Phase display and you will see a single dot. Next, go to the Setup Form - General Tab, Hardware Config Sub-Tab and check **Expert** to reveal Figure 66 above. Adjust the Clock Offset control until the dot in the phase display is (almost) standing still. Don't forget to turn the internal signal generator off, when you are done.

[The rest of this page has been left blank intentionally]

- The Clock Offset can also be calculated as follows. Divide the DDS frequency (500MHz) by the known signal frequency (say, 10MHz WWV) and then multiply by the difference between the known and the measured frequency. For example, say you tune the VFO to 10MHz and the peak shows up at 9.999700MHz (difference is  $10.0 - 9.999700 = +300\text{Hz}$ ). The Clock Offset would be  $500/10 * 300 = 15000$ . Plugging in 15000 into the Clock Offset control should zero beat the signal. Note that if the measured frequency were 10.000300MHz, the offset would be -15000. Fine adjustments may be made directly on the **Clock Offset** control using the phase display as described above.

**Note:** Any adjustments you make are saved to your database only and not to the radio's EEPROM. Therefore, if you start PowerSDR with a clean database, you will lose these adjustments.

- **IF (Hz):** Controls the **I**ntermediate **F**requency used in the software to avoid low frequency noise. The default value is 9,000 Hz and can be varied between 0 and 20,000 Hz. Normally there will be no need to adjust this. However, if you are experiencing low frequency noise, such as spurs that cannot be eliminated with the Spur Reduction (**SR**) enabled, you might try adjusting the IF.

### Options Sub-Tab





Figure 67: Setup Form - General Tab, Options Sub-Tab

## Options



*Figure 68: Options*


- ❑ **Spur Reduction:** Adds the use of a software oscillator to avoid DDS frequencies known to have a higher phase truncation related spurious response. In short, rather than tuning each frequency using the DDS (this is what happens when this option is turned off), the software tunes the DDS in 3kHz steps and does fine-tuning in software. Tuning in 3kHz steps also has the advantage of having to send fewer command signals to the hardware. For a complete description of the spur reduction algorithm used, see [A Technical Tutorial On Digital Signal Synthesis](#) available from Analog Devices.
- ❑ **Disable PTT:** Disables the ability to use external Push-To-Talk lines (MIC and PTT connectors) to key the radio.
- ❑ **All Mode Mic PTT:** When checked, PTT through the Front Panel **MIC** connector will be enabled. Otherwise, this PTT line will be disabled for digital (**DIGL**, **DIGU**) and **DRM** modes.
- ❑ **Disable Split on Band Change:** When checked and if Split is enabled, Split will be disabled when the band is changed.

## Process Priority

Sets the process priority for PowerSDR. Some users have reported that setting the priority higher than Normal can allow slower systems to perform more reliably and with smoother audio. While FlexRadio Systems recommends using the Normal setting, if you are experiencing audio glitches or are using a slower machine, selecting Above Normal or High might improve the performance of the software. Note that FlexRadio Systems does not recommend using the Real Time setting as this could cause timing problems with the operating system.

[The rest of this page has been left blank intentionally]


**ClickTune Offsets (Hz)**



*Figure 69: Digital ClickTune Offsets*

- ❑ **DIGU:** Sets the offset in Hz to use when click tuning in DIGU mode. Defaulted to 1200 for SSTV.
- ❑ **DIGL:** Sets the offset in Hz to use when click tuning in DIGL mode. Defaulted to 2210 for RTTY.

**Miscellaneous**




*Figure 70: Always On Top*

- ❑ **Always On Top:** Check to paint the Front Console on top of any other windows (even an active window).
- ❑ **Disable ToolTips:** Check to avoid seeing the explanatory tool tips that appear when you hover with your mouse over a control.
- ❑ **Snap ClickTune:** When checked, clicking (with the yellow or red cross hairs) on a signal in either the Panadapter or Waterfall will tune the VFO to the nearest multiple of the **Tune Step** (see page 52). E.g. if Tune Step is set to 1 kHz, the VFO will jump to the nearest kHz.
- ❑ **Zero Beat – RIT:** When checked and with **RIT** activated, the **0 Beat** button on the Front Console will offset the peak of a signal by the RIT frequency, such that VFO = actual peak frequency – RIT frequency. This can be useful if you want to zero beat the receive frequency without changing the transmit frequency.
- ❑ **Mouse Tune Step:** When checked, clicking the mouse button (middle click) will cycle through the tune steps.

[The rest of this page has been left blank intentionally]

## Keyboard



*Figure 71: Quick QSY*


- ❑ **Enable Shortcuts:** Enables the use of keyboard keys to perform various PowerSDR functions. The keyboard shortcuts can be set on the Setup Form-Keyboard Tab, described on page 123).
- ❑ **Quick QSY:** Enables the user to quickly enter a frequency in MHz on the keyboard and hit [Enter] to jump to that frequency (main receiver RX1 only). With this option disabled, using a mouse to tune or to click inside the VFO is the quickest way to change frequency. This feature is normally enabled by default, but can be disabled to prevent changing the VFO frequency due to accidental key presses.

## Custom Title Text

Enter the text you would like appended to the standard text (FlexRadio Systems PowerSDR v1.n.n) in the title bar of the Front Console.

[The rest of this page has been left blank intentionally]

### Calibration Sub-Tab




*Figure 72: Setup Form - General Tab, Calibration Sub-Tab*

To reveal the Frequency Calibration Sub-Tab, you will need to check the **Expert** box, which will generate a warning that this is meant only for experienced users. If you decide to proceed tune your radio to a known accurate frequency source (e.g. WWV), enter the frequency in the **Frequency** control and click the **Start** button.

[The rest of this page has been left blank intentionally]



## Filters Sub-Tab




*Figure 73: Setup Form - General Tab, Filters Sub-Tab*

- ❑ **Max Filter Width:** Sets the maximum filter width to be set by the Filter Width Slider on the front console.
- ❑ **Width Slider Mode:** Sets the behavior of the Width Slider. Linear, Log, and Log10 are the options. The log options offer more resolution on the smaller filter sizes.
- ❑ **Max Filter Shift:** Sets the maximum swing in Hz that the Filter Shift Slider on the front panel will allow in either direction.
- ❑ **Save Slider/Display Changes:** If checked, any changes to the filters made by the filter sliders or by using the click and drag on the filter edges on the display will be saved to the Variable filters and will be recalled as such. If not checked, the Var filters can only be changed by adjusting the Filter Low and High Cut controls on the front panel.
- ❑ **Default Low Cut (Hz):** Sets the default low frequency cut-off for the USB/LSB filters.

[The rest of this page has been left blank intentionally]

## RX2 Sub-Tab



*Figure 74: Setup Form - General Tab, RX2 Sub-Tab*

Check **Auto Mute RX2 on TX** to mute the second receiver RX2 while transmitting. Check **Auto Mute RX1 on VFO B TX** to mute the first receiver RX1 while transmitting on the RX2 frequency shown in VFO B.

[The rest of this page has been left blank intentionally]

# Audio Tab

## Primary Sub-Tab




Figure 75: Setup Form - Audio Tab, Primary Sub-Tab

### Buffer Size

You should set your audio **Buffer Size** as low as your computer system will tolerate. Larger buffers mean more delay, but smoother audio. Smaller buffers yield less latency, but at the cost of CPU load. The 2048 sample buffer size means that a single buffer at 48kHz sample rate is  $2048/48000 = 42.7\text{ms}$  in length. Faster machines should be able to run with a buffer size of 512 without issue at the lower **Sample Rate** settings (see below). For best CW performance (and if your computer can handle it), set the audio buffer to 512 or less. (see also the **DSP Buffer Size** on page 101).

### Sample Rate

The sample rate can be set to 48kHz, 96kHz or 192kHz. Using the higher sample rates will result in a wider frequency range in the panadapter and waterfall displays. Higher sample rates at a given buffer size will reduce the latency in the system, but at the same time widen the filter skirts. It is this trade-off that needs to be made, especially for CW where latency is more critical.

[The rest of this page has been left blank intentionally]

**Note:** The FLEX-5000 Driver will not automatically follow your audio Buffer Size, so make sure they are both set identically (see page 27), as a mismatch can lead to audio pops and clicks. The Driver will, however, follow the sample rate setting in PowerSDR.

### **Mic Boost**

Check this check box if your microphone audio is sounding too weak and you cannot increase it further with the **Mic Gain** control on the Front Console and the **Mic Input** control on the Mixer Form

### **Expert**


This check box will show additional controls that you should only consider using if you are an experienced user. You should proceed with caution. Vary rarely, if ever, will you need to access these controls.

### **Latency (with Expert checked)**

Using the manual option, the user may add additional latency (in milliseconds) to the audio buffering system for better audio performance. When the manual setting is off, the delay is set to 0ms. Note that some systems will have trouble with the manual setting on and values below approx. 15ms. We recommend using the default automatic latency setting for best results.

[The rest of this page has been left blank intentionally]

## VAC Sub-Tab




*Figure 76: Setup Form - Audio Tab, VAC Sub-Tab*

Use these controls to configure the VAC (Virtual Audio Cable) settings for use with PowerSDR. This is ideal for running digital modes, but can serve as another way to get audio in and out of PowerSDR. The **Buffer Size**, **Sample Rate** are similar to those described in the previous section. Below we describe the unique controls on this form.

### Virtual Audio Cable Setup

Select the driver type you wish to use. With most digital software MME will work well. Select the Input and Output channels as shown in Figure 76.

### Gain (dB)



*Figure 77: Gain (dB) Controls*

These settings adjust the gain for signals coming in and out of the VAC interface.

- ❑ Use the **RX** control to adjust the audio level going to third party programs. Note that this control supersedes the front panel AF control for third party applications.
- ❑ Use the **TX** control to adjust the volume of audio coming from third party applications. Use this control instead of the MIC control on the front panel to calibrate transmit (adjust for 0 dB on the ALC meter).

**Latency**

Using the manual option, the user may add additional latency (in milliseconds) to the audio buffering system for better audio performance. When the manual setting is off, the delay is set to 0ms. Note that some systems will have trouble with the manual setting on and values below approx. 15ms. We recommend using the default automatic latency setting for best results.


**Mono/Stereo**

Check this check box for stereo audio channels. Most third party applications require monaural audio. In this case leave the box unchecked. However, several DRM applications such as DREAM and HamPal require stereo audio.

**Combine VAC Input Channels**

Becomes enabled when **Mono/Stereo** is checked. Check to combine both L and R stereo input channels.

**Auto Enable**



*Figure 78: Auto Enable*


Use this control to automatically enable VAC when operating digital modes (DIGL, DIGU, DRM). This allows the user to easily switch between digital modes and SSB/AM/FM without having to separately enable/disable VAC.

**Allow PTT to override/bypass VAC for Phone**

Check this box if you wish to override or bypass VAC when activating PTT, e.g. to use your microphone.

[The rest of this page has been left blank intentionally]

## Direct IQ




*Figure 79: Direct I/Q*

Check **Output to VAC** to send “pre-processed” I/Q to the VAC output instead of “post-processed” audio, to enable you to use third-party software that has the ability to directly process I/Q signals. Check **Calibrate I/Q** to correct the raw I/Q signal and avoid any image signals going to the third-party software.

[The rest of this page has been left blank intentionally]

# Display Tab




*Figure 80: Setup Form - Display Tab*

[The rest of this page has been left blank intentionally]



## Spectrum Grid




*Figure 81: Spectrum Grid*

The spectrum grid controls define the range and scale of the vertical axis (signal level in dBm) shown in the Spectrum, Histogram, and Panadapter displays.

- ❑ **Max:** The maximum displayed signal level in dBm (i.e. top of the display).
- ❑ **Min:** The minimum displayed signal level in dBm (i.e. bottom of the display).
- ❑ **Step:** Spacing between the horizontal grid lines in dBm.
- ❑ **Align:** Sets the position of the vertical axis. The Left, Center, Right, and Off settings are self-explanatory. The Auto option automatically places the vertical axis at the 0Hz position in the Spectrum and Histogram displays.


## Refresh Rates



*Figure 82: Refresh Rates*

- ❑ **Main Display FPS:** Sets the update rate of the main display to the selected value in frames per second. Note that this is a good control to reduce if you are running on a slower machine to save CPU cycles. Raising this value will give faster updates at the cost of CPU load. Lowering the value will slow the display down.
- ❑ **Peak Text (ms):** Sets the update rate of the peak signal location text box located just beneath the display. Raising the value increases the delay between peak updates and slows the display down. Conversely, lowering the value will accelerate the updates.
- ❑ **CPU Meter (ms):** Sets the update rate of the CPU Meter in the lower left of the front console. Raising the value will add more delay between updates while lowering the value will yield faster responses. Note that the CPU Meter measures your entire system load and not just that of PowerSDR process.


**Waterfall**



*Figure 83: Waterfall*

- ❑ **Low Level:** The lower end of the dynamic range to view in dBm. Signals at or below this level will use the **Low Color**.
- ❑ **High Level:** The high end of the dynamic range to view in dBm.
- ❑ **Low Color:** Color used if the signal level is at or below the **Low Level**.
- ❑ **Averaging Time:** Time in ms over which the signal is averaged for the Waterfall Display. The **AVG** button on the Front console has no effect for the waterfall.
- ❑ **Update Period:** Time in ms between updates to the Waterfall. The higher the period, the slower the Waterfall will progress from top to bottom of the display.

**Multimeter**




*Figure 84: Multimeter Display options*

- ❑ **Analog Peak Hold (ms):** The length of time in milliseconds to hold the peak on the analog edge or bar meter. Raising this value will lengthen the hold time and peaks will be held for a longer period of time.
- ❑ **Digital Peak Hold (ms):** The length of time in milliseconds to hold the digital meter when using the **Fwd Pwr** TX Meter. Raising this value will lengthen the hold time and peaks will be held for a longer period of time.
- ❑ **Average Time (ms):** The time over which the signal is averaged when using the **SigAvg** RX Meter setting.
- ❑ **Analog Refresh (ms):** Controls how often the analog meter is updated.
- ❑ **Digital Refresh (ms):** Controls how often the digital meter is updated.

- Show Decimal:** Check to show decimal values in the digital meter.

**Phase Resolution**



*Figure 85: Phase Resolution*

This control sets the Phase display resolution in number of points displayed per 360°.


**Scope Time Base**



*Figure 86: Scope Time Base*

This control adjusts the time base in  $\mu$ s (horizontal time scale) of the Scope Display.


**Averaging**



*Figure 87: Display Averaging*

This control sets the averaging time in ms of the Spectrum, Panadapter and Histogram displays when **AVG** is enabled on the Front Console.

**Polyphase FFT**



*Figure 88: Polyphase FFT*

Enable this feature to display sharper peaks in the spectrum displays (Spectrum, Panadapter, Waterfall, Histogram). Expect to see an up to 4 times narrower area of the displayed "spike" of a tone, especially when the displayed frequency span is relatively large in comparison.

[The rest of this page has been left blank intentionally]

# DSP Tab

## Options Sub-Tab




Figure 89: Setup Form - DSP Tab, Options Sub-Tab

## Noise Reduction





Figure 90: Noise Reduction Controls

Noise Reduction (**NR**) attempts automatic computation of a filter that maximizes the coherent or non-noise like signals and as a result, filters out the rest of the signal, which includes noise. It is best used for speech signals with a good signal to noise ratio or tones.

[The rest of this page has been left blank intentionally]

- ❑ **Taps:** The number of taps determines the length of the computed filter. The longer the filter, the better the non-coherent signals (noise) will be canceled. It also introduces latency equal to the number of filter taps divided by the sample rate in samples per second and is in addition to Delay (see below). The larger the number of taps, the longer it takes for the filter to converge but upon achieving convergence, the better the filter will be.
- ❑ **Delay:** Determines how far back to look in the signal before beginning to compute a coherent signal enhancement filter. With large delays, there is a higher likelihood of detrimental affects to normal speech. Latency is also introduced that is equal to the Delay.
- ❑ **Gain:** Determines the adaptation rate of the filter. The larger the number, the faster the filter will converge but the less stable it will be.

### Automatic Notch Filter



*Figure 91: Automatic Notch Filter Controls*

The Automatic Notch Filter (**ANF**) attempts automatic computation of a filter to remove one or more carrier tones that are interfering with the signal of interest.

- ❑ **Taps:** This determines the length of the computed notch filter. The longer the filter, the larger the number of tones that can be canceled and the more effective the cancellation will be. It also introduces latency (signal delay) equal to the number of filter taps divided by the sample rate in samples per second and is in addition to Delay (see below). The larger the number of taps, the longer it takes for the filter to converge but upon achieving convergence, the better the filter will be.
- ❑ **Delay:** Determines how far back to look in the signal before beginning to compute a cancellation filter. The larger the delay, the less the impact on normal speech, and the more likely the filter will be able to concentrate only on longer term coherent signals such as carrier tones. Latency is introduced that is equal to the Delay.
- ❑ **Gain:** Determines the adaptation rate of the filter. The larger the number, the faster the filter will converge but the less stable it will be.

### Use Peak Readings for TX Meter DSP Values

When checked, the MIC, EQ, Leveler, CPDR and ALC TX Meters will show peak values instead of RMS values.

[The rest of this page has been left blank intentionally]


**Buffer Size**

The DSP buffers can be preset separately for receive (RX) and transmit (TX), for each of the Phone, CW and Digital modes. Selecting an operating mode on the front console will then automatically select the corresponding (RX or TX) preset DSP buffer: Phone for LSB, USB, DSB, FMN, AM and SAM; CW for CWL and CWU; Digital for DIGL, DIGU and DRM.

The size of the the DSP buffer, which determines the size of the FFT filter and therefore the group delay (latency) through the digital filter. Higher values will result in more latency and sharper (“brick wall”) filters. Lower values will allow nearly real time monitoring, but with wider filter skirts that “roll off” (as opposed to the typical “brick wall” filters). Therefore a trade-off needs to be made and this trade-off is often different, depending on the mode of operation.

- For example if the sample rate (see Figure 75 on page 90) equals 192kHz and the DSP buffer equals 2048 then the minimum attainable 3dB filter width equals  $1.5 \cdot 192000 / 2048 \approx 140\text{Hz}$ , where the factor 1.5 is due to the Blackman-Harris windowing function (see below).<sup>1</sup> Either lowering the sample rate or increasing the DSP buffer size will enable narrower and sharper filters.

To dramatically illustrate this effect Figure 92 below shows two traces of the same 25Hz CW filter. The red trace is at a sample rate of 192kHz and a DSP Buffer size of 512, yielding a minimum filter width of  $1.5 \cdot 192000 / 512 \approx 563\text{Hz}$ !! The blue trace at 48kHz and 4096 yields a minimum 3dB filter width of  $1.5 \cdot 48000 / 4096 \approx 18\text{Hz}$ .



**Figure 92: 25Hz CWL Filter at 192kHz Sample Rate/512 Buffer Size (Red) and 48kHz/4096 (Blue)**

- The minimum audio latency is determined by the maximum of the group delay due to the DSP Buffer and the delay due to audio buffering (see page 90). In the above example the group delay equals  $2048 / 192000 = 11\text{ms}$ . If the audio buffer is set to say 1024 then its latency equals  $1024 / 192000 = 5\text{ms}$ . In this case the overall latency is determined by the DSP buffer size and the group delay of 11ms.

[The rest of this page has been left blank intentionally]

<sup>1</sup> The same filter shape is achieved for 96kHz and 1024 or 48kHz and 512.

- Therefore, you should set your Audio Buffer as low as your computer system will tolerate at the set Sample Rate. Next you should set your DSP Buffer as high as you can, without experiencing noticeable latency. Finally, for the narrowest (CW) filters you may need to lower your Sample Rate further, especially in extreme conditions such as contests.

### Noise Blanker

This controls the detection threshold for impulse noise. If a signal sample exceeds this detection threshold, the sample will be set to zero and the filtering in the radio serves to interpolate through this zero sample. This noise blanker is identical in theory to those in traditional radios. The detection threshold in our noise blanker has the unique feature that it is signal strength dependent. This enables it to function properly at all signal levels.

This control is preferable when the spikes are very large in comparison to the average signal. However, when the spike is smaller, **Noise Blanker 2** provides a much cleaner reconstruction of the signal since the signal is more likely to look like the mean. For this reason, the Noise Blanker 2 threshold should always be about four or five less than the Noise Blanker threshold.

### Noise Blanker 2

This controls the detection threshold for a pulse. If a signal, pulse or not, exceeds this detection threshold, the sample will be replaced by a computed estimation of what the signal sample should have been given an interpolation of the signal samples around it in time. By replacing the noise pulse with an interpolation of the signal, distortion is greatly reduced over that of traditional noise bankers.


When seeing a significant amount of impulsive noise, being too aggressive with **Noise Blanker (NB)** can damage the signal. However, completely removing the large pulses is desirable prior to operating the smoother acting **Noise Blanker 2 (NB2)**. Therefore, when seeing many repetitive noise pulses, it is probably best to use both NB and NB2. The NB Threshold is adjusted to just begin to lower the noise from the pulses, after which NB2 is turned on, with a threshold of four or five less than that of NB. Both together can spectacularly reduce impulse noise, resulting in increased intelligibility of the signal under severely adverse conditions.

### Window

This control selects the DSP windowing function that will be applied to the power spectrum in the main display when using Spectrum, Panadapter, Histogram, and Waterfall displays. The default is Blackman-Harris, which is the best setting for many high-level signal measurement needs. The purpose of the windowing is to diminish bleed-through to adjacent FFT "bins" which results from a tone that is not exactly on the center frequency of one of the "bins" (or parallel filters) in the power spectrum calculation. The bleed-through is caused by using the Fast Fourier Transform (FFT) to calculate the power spectrum, which we need to use for the sake of efficiency. That said, it is important to understand that the FFT writes the data (mathematically speaking) on a circle and not on a line. When the last sample meets the first sample on a circle, it is very probable that it will not meet up or join in a continuous fashion. This discontinuity acts in exactly the same manner a key click causes a wide spectrum. The window is used to mitigate this key click-like phenomenon. The Rectangular Window bleeds through the worst. The best in our selection is the Blackman-Harris Window, which bleeds through the least, but at a penalty of a slightly reduced spectral resolution (=wider filter). Appendix D describes in more detail several of the window functions available in PowerSDR.


[The rest of this page has been left blank intentionally]

Figure 93 shows the effect of using various windows with a 1kHz DSB filter. The effect is most obvious in the stop band attenuation of the filter, where the Rectangular Window (Black) shows the worst result. In this case, the Blackman-Harris Window (Red) is obviously superior.



*Figure 93: Effect of Various Windows: Rectangle (Black), Welch (Violet), Bartlett (Blue), Hanning (Green), Blackman 3 (Orange) and Blackman-Harris (Red)*

Figure 94 displays a 25Hz CW filter with a Hanning and a Blackman-Harris window. It is clear that the Hanning window offers a narrower passband at the cost of a higher stop band. Blackman-Harris offers a much improved stop band, but at the cost of a slightly wider passband. In almost all cases Blackman-Harris will be preferred, except possibly for weak CW signals, where dynamic range is much less important than a narrower passband.




*Figure 94: 25Hz CW Filter with Hanning (Red) and Blackman-Harris (Blue) Windows*

[The rest of this page has been left blank intentionally]



## Image Reject Sub-Tab



*Figure 95: Setup Form - DSP Tab, Image Reject Sub-Tab*


**Note:** Your FLEX-5000 is completely calibrated, including both receive and transmit image rejection and needs no further adjustments.

### Expert

This **Expert** check box will show controls that you should only consider using if you are an experienced user. You should proceed with caution. Very rarely, if ever, will you need to access these controls.

[The rest of this page has been left blank intentionally]

## Receive Rejection




*Figure 96: Receive Rejection*

Image Rejection means finding adjustments for phase angle and gain differences between the left and right channels in the in-phase (I) and quadrature (Q) signals.

- ❑ **Phase:** Sets the phase offset between the I and Q channels. Ideally, the phase angle difference between I and Q (right and left channels) of a tone in our passband will be 90 degrees.
- ❑ **Gain:** Sets the amplitude offset between the I and Q channels. Ideally, the amplitude of both I and Q (left and right) channels of a received tone will be equal.

## Transmit Rejection



*Figure 97: Transmit Rejection*

Similar to above, these controls enable the user to adjust the image rejection for the transmitter. The calibration requires external instruments. A spectrum analyzer is ideal but a second receiver should enable you to get satisfactory rejection levels.


To minimize the transmit image, proceed as follows:

1. Set the radio to either USB or LSB. Connect the radio to a dummy load and select **Enable TX Image Tone**.
2. Click **MOX** (front console) and a full strength tone will be transmitted at the frequency shown in **VFO A**. Adjust the output power with the **Drive** control (front console).
3. If the radio is set to USB, look at the image signal BELOW the carrier in either the spectrum analyzer or the second receiver. If set to LSB, look at the image signal ABOVE the carrier.

- Using **Phase** and **Gain** controls, null the relevant image signal.

**Note:** The image rejection will only work in an asymmetric voice mode (SSB). In a symmetric voice mode, like AM, SAM, and FMN any small amount of image problem will likely be covered up.

## Keyer Sub-Tab




*Figure 98: Setup Form - DSP Tab, Keyer Sub-Tab*

### CW Pitch

This enables the user to set the desired audio frequency for CW listening at the center of the CW filters (1kHz and lower filters). This will determine the offset that is applied to the carrier in receive and transmit. The display will continue to read the actual carrier frequency, but the software will provide for an offset to get the desired CW tone. This pitch will determine the automated tuning frequency using the display and mouse "ClickTune" functions.

[The rest of this page has been left blank intentionally]

**Connections**




*Figure 99: Connections*

The internal keyer supports two inputs. We call these inputs the primary and secondary connections. The primary connection will override the secondary input. This was designed with the idea that the secondary connection might be used for automatic CW generation while the primary could be used with manual paddles to override the automatic output.

- ❑ **Primary:** Select the connection to be used for the primary connection. Selecting "5000" allows the use of the jack on the back of the FLEX-5000.
- ❑ **Secondary:** Select the connection to be used for the secondary connection. Selecting "CAT" will allow use of the COM port that is currently being used by the CAT connection. This is useful as some programs allow both CAT commands and COM port line keying for CW. Note that the lower two controls will not show up if "None" is selected.
- ❑ **PTT Line:** Select the COM port line used for PTT.
- ❑ **Key Line:** Select the COM port line to be used to activate the key.

**Options**




*Figure 100: Internal Keyer Options*

- ❑ **Iambic:** Check this box to enable Iambic mode A emulation unless mode B is selected (see below). With the box unchecked, the key input will act like a straight key.
- ❑ **Disable Monitor:** The monitor is typically turned on when using **Break In** with the internal keyer. In order to keep the monitor off, check this option.
- ❑ **Rev. Paddles:** Using this option will reverse the paddle inputs so that the dot becomes a dash and vice versa.

- ❑ **High Res.:** This option will attempt to achieve fastest CW latency by using the high frequency event timer (if present) on motherboards containing Intel Pentium 4+ (and AMD equivalent) type processors. If the CW timing or tone production becomes unstable after checking the box, your motherboard contains the low frequency timer and you should leave the box unchecked. The option works for both manual and automatic CW.
- ❑ **Mode B:** Check this box to enable Iambic mode B emulation. Uncheck it to enable mode A emulation.
- ❑ **Auto Mode Swch:** Check to automatically switch to the appropriate CW mode (if in another mode) when you hit your paddles.


**Signal Shaping**



*Figure 101: Signal Shaping Controls*

- ❑ **Weight:** Sets the width ratio between the dot and dash.
- ❑ **Ramp:** Sets the length of the leading and trailing edge on the tones in milliseconds to avoid key clicks.

**Break In**



*Figure 102: Internal Keyer Semi Break In Controls*

- ❑ **Enabled:** Check this box to enable Break In for the internal keyer.
- ❑ **Delay (ms):** Sets the amount of time between the last detected input and when the radio will drop back to receive. The smallest possible setting is 10 ms.

[The rest of this page has been left blank intentionally]

## AGC/ALC Sub-Tab




Figure 103: Setup Form - DSP Tab, AGC/ALC Sub-Tab

These controls allow the user to customize the AGC/Leveler/ALC to their own particular tastes.

### AGC

The AGC is a state of the art, dual track AGC with anticipatory response on both fast and slower tracks. Or, stated differently, the AGC is in essence the combination of two AGCs, one with a very fast time constant, the other with a much slower time constant (for more detail see the article [A Discussion on the Automatic Gain Control \(AGC\) Requirements for PowerSDR](http://support.flex-radio.com/Downloads.aspx?fr=1) on the Downloads page of our website at <http://support.flex-radio.com/Downloads.aspx?fr=1>). The **Attack**, **Decay** and **Hang** settings may only be adjusted when the Front Panel **AGC** control is set to Custom. However, they do display the values for the selected **AGC** setting.

- ❑ **Slope (dB):** The AGC gain once the signal is above the AGC threshold (or knee, not to be confused with the Hang Threshold below). Setting a Slope higher than 0dB allows stronger signals above the threshold to sound louder than weaker ones (also above the threshold).
- ❑ **Max Gain (dB):** The maximum amount of gain allowed by the AGC system for signals below the AGC threshold. The total AGC gain equals the Max Gain + the Slope (Gain). See also Appendix C.

- ❑ **Attack (ms):** This sets the time constant for the attack for the AGC, When a signal gets stronger, this determines how quickly the AGC will respond to the need for decreased gain. Note that in order for this and the two controls below it to be enabled, the AGC control on the front panel must be set to Custom.
- ❑ **Decay (ms):** This sets the time constant for the decay for the AGC. When a signal gets weaker, this determines how quickly the AGC will respond to the need for increased gain.
- ❑ **Hang (ms):** To keep the AGC system from adjusting too much, an adjustable hang time is provided. This Hang time will only be applied if the signal level is above the Hang Threshold (see below), otherwise a fixed "Fast Hang" time of 100ms is applied. After this time has expired, the Decay will then determine how quickly the AGC gain recovers.
- ❑ **Hang Threshold:** The Hang will NOT occur if the signal is weaker than this threshold. Instead the "Fast Hang" will be applied.
- ❑ **Fixed Gain:** When you choose Fixed AGC on the front panel, this control is used to amplify the signal.

Table 9 details the AGC parameters used in the various settings.

*Table 9: AGC Setting Details*

Setting	Attack	Decay	Hang	Fast Hang
Fast	2ms	100ms	100ms	100ms
Med	2ms	250ms	250ms	100ms
Slow	2ms	500ms	500ms	100ms
Long	2ms	2000ms	750ms	100ms

**Leveler**


The Leveler is intended to even out the variations in input to your microphone caused by varying distance from or angle presented to it. It is an attempt to "level" the amplitude presented to the rest of the DSP audio processing. The leveler is **disabled** in DIGU and DIGL modes.

**ALC**

The ALC is what you would typically consider ALC to be in a transmitter. It is an attempt to prevent overdrive of the amplifier and the distortion that would accompany that. Because of the dual track AGC algorithm we use, this ALC will allow very high average power while maintaining peaks at a controlled level. The Comander (**DX** and **CPDR** on the Front Console (see Mode Specific Controls – Phone on page 59) work very well with the ALC to increase average power without overdrive.

[The rest of this page has been left blank intentionally]


## Transmit Tab



*Figure 104: Setup Form - Transmit Tab*

The transmit Tab has controls that allow the user to tailor the transmit signal characteristics using features like compression and filtering.

### TX Profiles



*Figure 105: TX Profiles*


The two default TX Profiles are **Default** and **Default DX**. The TX Profiles selection allows the user to save and restore the various TX settings with ease. The TX profile includes settings for: EQ, Filter, MIC Gain, Drive, DX, CPDR, Leveler, and ALC. Click the **Save** button to save the current profile. You will be prompted for a name. To change profiles, select the named profile from the drop down list. To remove a profile, select it using the drop down menu, and then click the **Delete** button.

[The rest of this page has been left blank intentionally]



**Hint:** Check the Expert box to reveal many more standard TX Profiles. See below.

**Transmit Filter**



*Figure 106: Transmit Filter Controls*

- ❑ **High:** Controls the high cut of the Transmit Filter.
- ❑ **Low:** Controls the low cut of the Transmit Filter.


**Note 1:** You will receive a "good practice" warning if the transmit filter bandwidth exceeds 3kHz.

**Note 2:** You can view the transmit filter on the Panadapter or Waterfall displays when you enable **Show TX Filter on Display** on the Front Console.

**DC Block**

Attempts to block any DC noise from entering the filter.

**Tune**




*Figure 107: Tune Settings*

- ❑ **Power:** Sets the power in Watts to be used whenever the **TUN** (Tune) function is used on the Front Console (sets the **Drive** control). Changes made to the **Drive** level while **TUN** is active will be reflected in this control.
- ❑ **TX Meter:** Selects which TX Meter to use when **TUN** on the Front Console is clicked.

[The rest of this page has been left blank intentionally]

## Noise Gate




*Figure 108: Noise Gate*

- ❑ **Enabled:** Enables the transmit noise gate.
- ❑ **Threshold (dB):** The threshold below which the transmitter is silenced (gated). When adjusted correctly, the noise gate prevents prevailing noise in the room (ambient noise) from being transmitted while the microphone is keyed and the operator is not talking. It is very useful if there are close by fans that degrade your signal and make your transmissions disturbing to copy. The noise gate operates identically, whether using VOX or PTT.

To adjust the noise gate:

1. While wearing headphones, activate **MON** and **MOX** on the Front Console (use a dummy load). Disable the noise gate and turn up the Monitor AF so that you can hear your ambient noise clearly and preferably louder than without headphones. Without speaking, enable the noise gate.
  - If you still hear your ambient noise, increase the noise gate threshold level until the noise is just silenced.
  - If your ambient noise disappears when enabling the noise gate, decrease the threshold level until you just start to hear it. Then increase it until it just disappears.
2. With the noise gate adjusted, speak into the microphone and verify that your voice sounds as natural as possible.

## VOX



*Figure 109: VOX*

- ❑ **Enabled:** Enables/Disables the VOX operation.
- ❑ **Sensitivity:** The threshold above which PowerSDR automatically starts transmitting. Use this in combination with the **Noise Gate** for best results.
- ❑ **Delay (ms):** Time to stay in transmit after the last peak above the threshold.

**Monitor**



*Figure 110: Transmit Monitor AF Control*

Use the Monitor TX AF control to set the value that the **AF** control (Front Console) will use as an initial value when transmitting. Any change made on the Front Console **AF** control will be remembered.


**AM Carrier Level**



*Figure 111: AM Carrier Level*

The **Carrier Level** determines the percentage of carrier level to be applied to the transmit signal where 100% is one quarter of full power output (25W when **Drive** on the front console is set to 100). So a setting of 80 would yield roughly 16W when **Drive** is set to 100. This is useful as it allows the modulation to appear much stronger due to the weaker carrier.

**Standard TX Profiles**




*Figure 112: TX Profile Defaults*

Click to place a check mark in **Expert** box and reveal many more **TX Profile Defaults** shown in Figure 112. To use one of these, click to select it from the list and then click **Import**. It will now be active and show up in the **Profiles** list described above.

[The rest of this page has been left blank intentionally]

## PA Settings Tab



*Figure 113: Setup Form - PA Settings Tab*

The FLEX-5000 is fully calibrated and requires no further adjustments. If you suspect your power amplifier requires adjustments, please first contact [FlexRadio Support](http://www.flex-radio.com) (on our website [www.flex-radio.com](http://www.flex-radio.com) select Support and then Service and Repair) for further guidance and how to proceed.

To view the controls, you will need to select Expert. A warning will appear, asking if you wish to proceed or not. Heed the warning.

### **Gain By Band (dB)**

To view these controls uncheck **Use Advanced Calibration Routines**. This shows the total hardware (radio + PA) signal chain gain. These controls are used to manually balance the output power across the ten supported amateur bands. A higher gain figure for the hardware (as shown) means a lower audio drive gain requirement.


**Reset:** this button is included to reset all of the values to 48.0dB (low power output).

When you are done, do not forget to recheck **Use Advanced Calibration Routines**.

# Appearance Tab

The appearance controls allow the user to completely customize the appearance of the front console.

## Display Sub-Tab




*Figure 114: Setup Form-Appearance Tab, Display Sub-Tab*

[The rest of this page has been left blank intentionally]

**Overall Display**

These controls change the appearance of all the display types, where relevant.




*Figure 115: Overall Display Appearance Controls*

- ❑ **Background:** The background color for the display.
- ❑ **Grid:** The color of the grid in display types where a grid is necessary.
- ❑ **Zero Line:** The color of the zero line in frequency displays.
- ❑ **Text:** The color of the text on the display for frequency and level callouts.
- ❑ **Data Line:** The color of the actual data being displayed.
- ❑ **Line Width:** The width in pixels of the actual data being displayed.

**Cursor/Peak Readout**

These controls change the appearance of the cursor and peak texts under the frequency domain displays.




*Figure 116: Cursor/Peak Readout Appearance Controls*

- ❑ **Peak Text:** The color of the Peak signal location text located under the display.
- ❑ **Background:** The background color of the Peak signal location text.

[The rest of this page has been left blank intentionally]

## Panadapter

These controls change the appearance unique to the Panadapter display (and Waterfall for the filters across the top).




*Figure 117: Panadapter Appearance Controls*

- ❑ **Main RX Filter Color:** The color of the Main RX Filter.
- ❑ **MultiRX Filter Color:** The color of the MultiRX Filter.
- ❑ **TX Filter Color:** The color of the TX filter-edges.
- ❑ **MultiRX Zero Line:** The color of the 0 Hz line of the Sub RX Filter.
- ❑ **Band Edge:** The color of the lines marking the edge of an Amateur band.
- ❑ **Show Freq. Offset:** When selected, the offsets from the Main RX Filter 0Hz line are shown across the top as opposed to the actual frequencies.

[The rest of this page has been left blank intentionally]

## General Sub-Tab

These controls change the appearance of the buttons and the VFOs.




*Figure 118: Setup Form-Appearance Tab, General Sub-Tab*

**Button Selected:** The color of buttons when they are in the selected state.

[The rest of this page has been left blank intentionally]




VFO



*Figure 119: VFO Appearance Controls*

- ❑ **Inactive:** The color of the text in the VFOs when they are inactive.
- ❑ **Active:** The color of the text in the VFOs when they are active.
- ❑ **Background:** The background color of the text in the VFOs.
- ❑ **Small 3 Digits:** When selected, the three least significant digits of the frequency displayed in the VFOs are shown smaller than the other digits for clarity.
- ❑ **Small Color:** The color of the smaller, least significant digits.

Band Data




*Figure 120: VFO Band Data Appearance Controls*

- ❑ **Inactive:** The color of the band information text when that VFO is inactive.
- ❑ **Active:** The color of the band information text when that VFO is active.
- ❑ **Out Of Band:** The background color of the VFO band information when outside the amateur radio bands.
- ❑ **Background:** The background color of the VFO band information when inside the amateur radio bands.

## Meter Sub-Tab

These controls enable selection of the analog meter style and change the appearance of the meters.



*Figure 121: Setup Form-Appearance Tab, Meter Sub-Tab*

- ❑ **Meter Type:** Selects the type of graphical meter to display: **Original** displays the bar graph meter and **Edge** displays an analog edge style meter.
- ❑ **Digital Text:** The color of the text of the digital meter.
- ❑ **Digital Background:** The background color of the digital meter.

[The rest of this page has been left blank intentionally]


**Original Style**



*Figure 122: Appearance Controls for the Original Style Meter*

- ❑ **Left Color:** The color of the left side of the original style meter gradient.
- ❑ **Right Color:** The color of the right side of the original style meter gradient.
- ❑ **Background:** The background color of the original style meter.

**Edge Style**




*Figure 123: Appearance Controls for the Edge Style Meter*

- ❑ **Low Color:** The color of the low values of the edge meter’s scale.
- ❑ **High Color:** The color of the high values of the edge meter’s scale.
- ❑ **Background:** The background color of the edge meter.
- ❑ **Indicator:** The color of the indicator in the edge meter.

[The rest of this page has been left blank intentionally]

# Keyboard Tab

These controls associate keys on the keyboard with several operating functions as keyboard shortcuts.




*Figure 124: Setup Form - Keyboard Tab*

The **Tune** mapping options allow you to tune each digit (with resolution to 1Hz) up or down using the key of your choice. The digit to be tuned is shown in the labels above these hot keys as an 'x'. Similarly, you can map keys to change the **Band, Filter, Mode, RIT, or XIT** up or down using the drop down controls in the respective sections.

**Note:** Choosing any of the arrow keys will require using Alt + [arrow key].

[The rest of this page has been left blank intentionally]

## Cat Control Tab




*Figure 125: Setup Form - Cat Control Tab*

The **CAT** (Computer Aided Transceiver) **Controls** enable the PowerSDR software to provide the user with a way to interface with third-party logging and remote control software. In conjunction with N8VB’s vCOM virtual serial port software (see page 175), interaction is possible with programs such as Ham Radio Deluxe (HRD), DXLab, N1MM Contest Logger, MixW and numerous other third-party software (aids).

[The rest of this page has been left blank intentionally]john

## Cat Control



CAT Control

Enable CAT

Port: COM20

Baud: 1200

Parity: none

Data: 8


Stop: 1

*Figure 126: CAT Control*

- ❑ **Enable CAT:** Check this box to open the com port using the settings below. Note that you will need to uncheck this box in order to adjust the settings.
- ❑ **Port:** Com port number to use. If using N8VB's vCOM utility, note that you will use one end of the null-modem pair here and the other on the third-party software (e.g.. HRD).
- ❑ **Baud:** The speed at which to transfer data.
- ❑ **Parity:** Sets whether to send a parity bit.
- ❑ **Data:** Sets how many data bits are sent with each byte.
- ❑ **Stop:** Sets whether to send a stop bit.

[The rest of this page has been left blank intentionally]

## PTT Control



*Figure 127: PTT Control*

Some software utilizes a separate COM port than the CAT to activate PTT. These controls allow the user to configure this separate port to handle these signals.

- ❑ **Enable PTT:** Used to enable the hardware PTT. This control is unavailable (grayed out) unless a check mark is placed in at least one of the RTS or DTR boxes (see below).
- ❑ **Port:** The COM port used for the PTT signal.
- ❑ **RTS:** Select this box to use the RTS line to engage PTT.
- ❑ **DTR:** Select this box to use the DTR line to engage PTT.

## DigiL/U Returns LSB/USB

By default DigiL sends or returns the CAT command FSK-R and DigiU sends or returns the CAT command FSK. If this check box is checked, they will instead send or return LSB and USB respectively. The third party digital program you are using will determine which behavior is required.

## FlexProfiler Installed

Enables the PowerSDR menu for selection for "Remote Profiles". When this menu option is available, the user can select console profiles created remotely in FlexProfiler<sup>1</sup> from the local PowerSDR console.

## Allow Kenwood AI Command


Enables the Kenwood AI command which causes PowerSDR to broadcast the transmit frequency (normally VFO A, but VFO B (or lower part of VFOA if RX2 is installed and on) if in Split) changes to the CAT system. Normally, CAT only responds to polling from the remote program. There are a few programs that expect frequency changes to be broadcast.

[The rest of this page has been left blank intentionally]

<sup>1</sup> FlexProfiler is provided free, courtesy of K5KDN and can be installed from the SVN subversion control location: [svn://206.216.146.154/svn/repos\\_sdr\\_windows/FlexProfiler/trunk/bin/Release](http://svn://206.216.146.154/svn/repos_sdr_windows/FlexProfiler/trunk/bin/Release) . To do so, you will need to use a program like TortoiseSVN, downloadable for free from <http://tortoisesvn.tigris.org/> . Search for SVN on our Knowledge Center at <http://kc.flex-radio.com/search.aspx> for further information.

**Test**

Click **Test** to bring up the CAT Command Tester form as shown in Figure 128 below. A valid CAT command may be entered in the **CAT Command** text box. The command will execute when the Enter key is depressed or the **Execute** button is clicked. Typing the semicolon, the CAT terminator, at the end of the command is optional. The CAT response will appear in the **CAT Response** text box..




*Figure 128: CAT Command Tester Form*

[The rest of this page has been left blank intentionally]



**RTTY Offset**



*Figure 129: RTTY Offset*

The **RTTY Offset** controls add or subtract the offset entered in **DIGU** and **DIGL** respectively, from the VFO frequency before CAT reports it to a third party program.

- ❑ **Enable Offset VFOA:** Check to apply the RTTY Offset to VFOA
- ❑ **Enable Offset VFOB:** Check to apply the RTTY Offset to VFOB
- ❑ **DIGL/DIGU:** Select the offset to be applied when in DIGU and DIGL mode respectively.

**Note:** This differs from **ClickTune Offsets** (see page 83), as the **ClickTune Offsets** actually change the Front Console VFO frequency, whereas the **RTTY Offset** only offsets the frequency reported by CAT.

[The rest of this page has been left blank intentionally]

## Tests Tab




Figure 130: Setup Form - Tests Tab

### Two Tone Test:


Used to test the two-tone IMD of the transmitter. To run the test, enter the two tone frequencies in the **Freq #1** and **Freq #2** controls. Enter the **Power** to be sent to the front panel **Drive** control. Make sure you have a dummy load connected. Click the **Start** button to begin transmitting a side-tone signal using the parameters entered. Manually adjust the **Power** control on this tab to set the tones to 6dB below PEP using a spectrum analyzer. Click the **Start** button again to stop the test and read the **Power** value thus found. A single sweep function on a spectrum analyzer is an excellent tool to capture the output for analysis.

### Audio Balance Test

Use this test to ensure that the Powered Speaker/Line Out cable is getting both output channels. The test will send a tone to each speaker and prompt to see if you hear audio in that one speaker. If you hear no audio or audio in both channels during this test, then either the connector is not properly seated or you may have a problem with the cable going to the Powered Speaker/Line out jack on the Back Panel.

[The rest of this page has been left blank intentionally]

## Signal Generator



*Figure 131: AF Signal Generator*

This Signal Generator sends an AF signal to either the input or output of either the receiver or the transmitter DSP. It is used to test the PowerSDR.

- ❑ **Mode:** Select the type of signal to generate. "Soundcard" means the Signal Generator is turned off and FLEX-5000 hardware can be used.

**Note:** When finished with the Signal Generator, do not forget to place the Signal Generator back to "Soundcard".

- ❑ **Scale:** A scaling factor to adjust the level of the signal being generated. This is only available when "Tone" is selected. Only values smaller than 1 are possible.
- ❑ **Input:** The generated signal is sent to the Input of the DSP, as if it were coming from the ADC like your antenna signals would. The generated signal is therefore perceived as an IF signal by PowerSDR.

For example, if your IF is set at the default 9kHz, then for the Receive Signal Generator a 0Hz generated "Tone" would be displayed 9kHz below the VFO frequency on the Panadapter. As you increase its frequency, upper and lower side band mixing products appear. If you have selected USB mode on the Front Console you will only start to hear a tone when the frequency slider is above 9kHz such that the tone's upper side band is within the audio passband. If you select the Scope display, you will only see the signal when it is within the audio passband.

- ❑ **Output:** The generated signal is sent directly to the output, bypassing the DSP. The tone of the Receive Signal Generator is available from the Line Out jack on the back panel for viewing on an external scope, for example. The effect of the DSP can be observed by comparing the Output signal to the Input signal.
- ❑ **RX2:** Check to send the generated signal to the second receiver RX2.
- ❑ **Frequency Slider:** Determines the frequency of the generated signal

- ❑ **Sweep:** Click this button to sweep the generated signal frequency from **Low** to **High** at a rate of **Hz/Sec**. While sweeping, the button will be yellow. To prematurely stop the sweep click the **Sweep** button again.

**Hint:** Together with the **Peak** display setting the Sweep function allows you to display the actual shape of your audio passband filter. To do so, set your display to **Spectrum**, activate **Peak**, set the Receive Signal Generator to "Tone".

Set the **Low** and **High** frequencies to sweep through the selected filter, taking into account the selected mode and IF offset. E.g. for a 2.7kHz LSB filter the "high" end of the filter is at -2.9kHz and the "low" end at -200Hz. To include any filter skirts, you may want to set **Low** at -4kHz  $-(-9\text{kHz}) = 5\text{kHz}$  and **High** at 1kHz  $-(-9\text{kHz}) = 10\text{kHz}$ .

### Enable HW Signal Generator

The so called "HW" Signal Generator is an RF signal generator as opposed to the AF Signal Generator described above. Check to activate the HW Signal Generator and adjust its frequency by using **VFO B**.

- ❑ To test RX1, switch RX2 off (if installed), and set the VFO to **SPLT**.
- ❑ To test RX2, switch RX2 on and make sure **SPLT** is off.


**Note 1:** The Receive AF Signal Generator must be set to "Soundcard", to use the RF Signal Generator.

**Note 2:** In actual fact, the RF signal is generated using the transmit DSP and sent through the QSE, which is then looped back to the QSD and the receive DSP.

[The rest of this page has been left blank intentionally]

# Operating Forms

This chapter describes each of the so-called operating forms. You can access each form individually by clicking on the relevant menu item to the right of Setup at the top left of the front console (see Figure 132). For ease of reference, the numerical identifiers from the previous chapter on the Front Console are repeated in this chapter. Additionally, the key combination Ctrl-Shift-I activates the voltage and temperature form (see page 154)



*Figure 132: Operating Form Identifiers*


[The rest of this page has been left blank intentionally]

## (32) Memory Form

Click the Memory menu allows saving and retrieving information such as frequency, mode, filter and various other settings.

### Save...

Opens the Save Memory Channel form as shown in the figure below.




*Figure 133: Save Memory Channel Form*

The current **Mode**, **Filter**, **Step Size**, **Frequency**, **Squelch** and **AGC** settings are automatically transferred from the console. The **Group** Drop Down Box allows a further level of characterization of the type of entry. In the future this Group list will be customizable. The **Callsign** and **Comments** fields are free form and the user can enter details as desired. Clicking the **OK** button will save the information shown above into the memory database before closing the form. Clicking **Cancel** simply closes the form (the data is not saved).

[The rest of this page has been left blank intentionally]

## Recall...

Presents the user with a Memory form with data from all previously stored memory locations (shown in the figure below).




*Figure 134: Memory Form*

The data grid displays each memory that has been saved to the database. Clicking in the left hand margin will allow a particular memory to be selected. Clicking on the column titles will sort the data using the information in that column. Repeatedly clicking will alternate between ascending and descending order as indicated by the small arrowhead in the column title.

- ❑ **Edit:** Click the Edit button to manually change the saved memories. Make sure to click the button again when finished editing to prevent unintended changes from getting saved to the database.
- ❑ **Recall:** Click the Recall button to send the data in the memory to the front console (i.e. restore a memory). You can also double-click on a row to accomplish this, although this method is less consistent. Select **Close on Recall** to close the Memory Form when clicking **Recall**.
- ❑ **Delete:** Click the Delete button to remove a memory from the database. A prompt will be shown to prevent unintended loss of memories.

## (33) Wave Form



*Figure 135: Wave Form*

The Wave form allows the user to Record and Playback either the post-processed audio of the current station, or up to 192kHz bandwidth (as determined by the audio sample rate setting) of pre-processed IF (I and Q) "audio" from the FLEX-5000.

### Playback

- ❑ **Currently Playing:** Displays the filename of the currently playing wave file.
- ❑ **Play:** Click this button to start or stop playback of the current wave file. Note that clicking this button twice while a file is playing will restart the file.
- ❑ **Pause:** Pauses the wave file playback. Click once to pause and again to resume playback.
- ❑ **Prev (Previous):** When there is more than one file in the playlist, clicking this button will cause the previous file in the list to begin playing.
- ❑ **Next:** When there is more than one file in the playlist, clicking this button will cause the next file in the list to begin playing.

[The rest of this page has been left blank intentionally]



## Playlist

- ❑ **Add...:** Click this button to open a file menu to select wave file(s) to add to the playlist. Note that incompatible wave files will be removed from the list when they are played for the first time.
- ❑ **Remove:** Removes the currently selected file in the playlist. If the file is currently being played, then you will be prompted asking if you would like to stop playing the file and remove it from the list.
- ❑ **Loop:** When there is more than one file in the playlist, this option is enabled and allows playback to continue after finishing the last wave file in the list. At this point it will start playing the file at the top of the list.

## Record

Click the **Record** button to begin recording a wave file. Click it again to complete the recording. The wave file will be date and time stamped automatically and saved in the default folder (where the PowerSDR software resides).

## TX Gain (dB)

Use this control to adjust the volume of audio being played back when transmitting. Use this control instead of the MIC control on the front console to calibrate transmit (adjust for 0 dB on the ALC meter).


## Quick Rec and Quick Play

The **Quick Rec** and **Quick Play** buttons offer a quick and easy way to record and play back a signal audible on the main receiver RX1. Click **Quick Rec** to record a signal and click **Quick Rec** again to stop recording. Once recorded, the signal can be played back by clicking **Quick Play**. Subsequently clicking **Quick Rec** will overwrite any audio file previously recorded in this way. These two buttons perform the same function as the **Rec** and **Play** buttons on the Front Console (see page 73).

[The rest of this page has been left blank intentionally]

## Record Options

Click **Options** at the top of the Wave Form (see Figure 135) to open the following form:



*Figure 136: Wave Recording Options*

The Wave Record Options can be used to modify what is recorded in either receive or transmit modes.

### Receive

- ❑ **Pre-Processed Audio** will record the whole bandwidth of the receiver input. The bandwidth is determined by the sample rate you set on the Setup Form-Audio Tab, Primary Sub-Tab. This is useful for playing back through the console at a later time (e.g. for demonstration purposes).
- ❑ **Post-Processed Audio** will record only the filtered, AGC'd audio as you hear it coming out of the speaker. This is useful for playing back the received audio through a typical wav file player.

### Transmit

- ❑ **Pre-Processed Audio** will capture the audio as it is seen at the microphone input without any of the effects of filtering, compression, companding, equalization or any other audio processing features that may be turned on in the transmit chain.
- ❑ **Post-Processed Audio** allows the recording to capture the audio after it has been filtered, compressed, companded, equalized or modified by any other audio processing feature turned on in the transmit chain.

### Sample Rate

Sets the sample rate at which the wave file will be recorded.

[The rest of this page has been left blank intentionally]

## (34) Equalizer Form

There are three equalizers available: a 3-band, a 10-band and a 100-band equalizer. The equalizers may be enabled either from the Equalizer Form or in the phone modes, from the Front Console (see page 59)

### 3-Band Equalizer


The screenshot shows the 'Equalizer Settings' dialog box. At the top, there are two radio buttons: '3-Band Equalizer' (selected) and '10-Band Equalizer'. Below this, the 'Receive Equalizer' section is visible. It includes an 'Enabled' checkbox (unchecked), a 'Preamp' slider (set to 0dB), and three frequency sliders: 'Low', 'Mid', and 'High'. Each slider has a scale from -12dB to 15dB. A 'Reset' button is located at the bottom of the 'Receive Equalizer' section. The 'Transmit Equalizer' section is also visible, with identical controls.

*Figure 137: Three-Band Equalizer Form*

In most situations the 3-Band Equalizer will suffice. The receive and/or transmit audio can be modified by adjusting the gain for the **Low**, **Mid** and **High** audio bands. The **Preamp** applies gain across the whole audio spectrum. Easily compare the audio with and without the equalizer using the **Enabled** check box. The **Reset** button will reset all of the sliders to the 0dB position.

**Hint:** Hover with your mouse over a slider to see its frequency range of operation.

## 10-Band Equalizer



*Figure 138: Ten-Band Equalizer Form*

The 10-Band Equalizer offers a finer degree of audio frequency control than does the 3-band equalizer. You may want to use this equalizer if the 3-band equalizer does not give you the result you want.

[The rest of this page has been left blank intentionally]

## (35) XVTRs Form

Enabled	Band Button	UCB Address	Button Text	LO Offset (MHz)	LO Error (kHz)	Begin Freq (MHz)	End Freq (MHz)	RX Gain (dB)	RX Only	Power	Split RF
<input checked="" type="checkbox"/>	0	0	1296	1268	0.000	1296.000000	1298.000000	0.0	<input type="checkbox"/>	5	<input checked="" type="checkbox"/>
<input type="checkbox"/>	1	1	1	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	2	2	2	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	3	3	3	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	4	4	4	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	5	5	5	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	6	6	6	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	7	7	7	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	8	8	8	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	9	9	9	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	10	10	10	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	11	11	11	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	12	12	12	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>	13	13	13	0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>		14		0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>
<input type="checkbox"/>		15		0.0	0.000	0.000000	0.000000	0.0	<input type="checkbox"/>	100	<input type="checkbox"/>

Use XVTR PWR for Tune

*Figure 139: XVTR Setup Form*


The XVTR (transverters) Setup Form allows the user to configure up to 16 external transverters for use with the PowerSDR software.

- Enabled:** Enables that particular Band Button on the front console with the options selected.
- Band Button:** Band button to use for the particular transverter that is being configured.
- UCB Address:** Used to set the FlexWire to switch the correct external device (or a relay that controls the external device).
- Button Text:** The text that will be shown on the Band Button.
- LO Offset (MHz):** The difference between the transverter low frequency and the IF frequency. For example, on 2m, you might use 144-28MHz = 116.0.
- LO Error (kHz):** This setting allows the user to correct for any error in the transverter's oscillator.
- Begin Frequency (MHz):** The lower frequency bound for the transverter.
- End Frequency (MHz):** The upper frequency bound for the transverter.
- RX Gain (dB):** Amount of gain to apply to the incoming signals to compensate for gain within the transverter. *Please note that this does not yet work as intended.*

- ❑ **RX Only:** If this box is checked, the radio will not transmit while in this configured band.
- ❑ **Power:** Sets the **Drive** control on the front console to this value whenever the VFO is within the configured band.
- ❑ **Split RF:** Check if the transverter you are using for this band uses separate connectors for transmit and receive RF. In this case connect your transverter to the Back Panel **XVTX/COM** port for transmit RF and the **XVRX** port for the receive RF. Otherwise, connect it to the **XVTX/COM** port only.
- ❑ **Use XVTR PWR for Tune:** When you click the **TUN** button on the Front Console the power will be set to the value you enter in the **Power** control on this form (see above). Otherwise, the Tune Power setting on the Setup Form – Transmit Tab (page 111) will be used.

[The rest of this page has been left blank intentionally]

## (36) CWX Form



*Figure 140: Standard CWX Form*

The CWX form is designed to allow you to control automatic Morse code transmission and to send code from your computer keyboard. Pressing the **CWX** button on the main console menu opens this form. The radio must be in either **CWL** or **CWU** mode for transmission to take place.

### Standard CWX Controls

- ❑ **Red Indicator:** The small red indicator shows when the radio is transmitting.
- ❑ **Yellow Indicator:** The yellow indicator shows when the key is being 'pressed' by the program.
- ❑ **Key:** Clicking this button will cause the radio to start transmitting a steady carrier for up to one minute. Clicking **Key** again will stop the steady sending.
- ❑ **Stop (ESC):** Clicking this button or pressing the **Esc** key on your keyboard will terminate most functions and prepare the program to receive new orders or allow the iambic paddle to be used.
- ❑ **Notes:** Clicking this button will cause a small page of useful notes to be displayed. You can leave the notes up on the screen while you continue to work.
- ❑ **Speed WPM:** This control lets you set the speed of the Morse code being sent. The speed is computed by the standard PARIS method. The softness of the edges may be set by the **RAMP** control on the **Setup Form - DSP Tab, Keyer Sub-Tab**. The weighting is always 50% for the memory/keyboard keyer.

**Note:** This setting is separate from the control on the front console.

- ❑ **Repeat Delay:** This control specifies the amount of time that the keyer will wait when a special pause character is encountered.
- ❑ **Drop Delay:** This control specifies the amount of time that the semi-break in keying will wait before dropping the transmitter when there is no keying occurring.

### CWX Memories

There are nine CWX memories, three of which are hidden on the extended form to the right (see below). Each memory can hold thousands of characters and in a standard single line text box. The numbered buttons to the left of each memory box may be clicked to start the message. A message may be stopped at any time by clicking the **Stop (Esc)** button or pressing the **Esc** key. Starting a message will seamlessly stop any current message or other automatically keyed transmissions from the radio, including the iambic paddle. The keyer will start the transmitter and send the Morse code for each character until the message ends, at which time the transmitter will shut down. Messages may be edited at any time but the changes will not take place until the memory is started again.

### Special Characters

There are several predefined characters that provide non-Morse code functionality or to send familiar combinations like AR and SK (see Table 10 below). For beacon transmissions, the character # will send a long 23 element time dash comparable to a zero, with the key down the whole time. Multiple # characters can be strung together for longer continuous dashes. The \$ character works in a similar manner but generates a long 23 element time space. The "or ditto" character may be placed at the end of a message. When encountered, the keyer will shut down for the delay time set in the **Repeat Delay** control and then restart the message. This allows you to program a CQ and then listen for a reply with the radio back in receive. If the delay is set to zero then the message will simply repeat without the radio switching to receive. Six special combinations are preprogrammed, as shown in Table 10.

*Table 10: Overview of Special Characters*

Special Character	Action
#	Beacon - transmits 23 element "zero" time dash
\$	Beacon - transmits 23 element time "space"
+	AR ( . - . - . )
(	KN ( - . - - . )
*	SK ( ... - . - )
!	SN ( ... - . )
=	BT ( - ... - )
\	BK ( - ... - . - )
& ` ) : ; < > [ ] ^	User definable, up to any combination of 9 contiguous dots or dashes

The remaining special characters & ` ) : ; < > [ ] and ^ are undefined and may be defined to produce any combination of nine contiguous dots and dashes. Characters that are undefined have no dots and dashes and are simply sent as a space.

[The rest of this page has been left blank intentionally]



## Keyboard and Extended Controls

Click the little square button in the lower right corner of the form to expand it. When you do this, the remainder of the memories and controls will be visible including the keyboard window as shown below.




Figure 141: Extended CWX Form

### Extended CWX Controls


- ❑ Keyboard area: the four-line text box at the bottom. Unsent characters are shown in black and sent characters in gray.
- ❑ **Keyboard/KEYS ACTIVE/KEYS OFF.** This button has three labels:
  - At first use, the button is labeled **Keyboard**, the indicator is grayed out and the keyboard cannot be used to enter characters.
  - When clicked it changes to **KEYS ACTIVE** and the indicator shows cyan. The keyboard can now be used to enter characters at the end of the unsent area. As soon as a character is typed it will be sent and then moved to the unsent area. If you type faster than the code is being sent, it will be buffered in the bottom area.
    - The **Backspace** key will work in the unsent area.
    - Other editing keys like cut and paste are not implemented.
    - Pressing **Alt 1** to **Alt 9** or right clicking on the message number button will cause the numbered message memory to be copied into the unsent area just as if you had typed it.
    - The ditto character is ignored in the keyboard mode.

- Clicking **Clear(F2)** (see below) deactivates the keyboard, changes the **KEYS ACTIVE** button to **KEYS OFF** and the indicator shows black. Clicking **KEYS OFF** reactivates the keyboard, changing the label to **KEYS ACTIVE** again and the indicator to cyan.
- **Pause (F1):** Clicking this button or the pressing the **F1** key will cause keyboard buffer sending to pause.
- **Clear (F2):** Clicking this button or pressing the **F2** key will clear the keyboard area, stop it sending and deactivate the keyboard (**KEYS ACTIVE** button changes to **KEYS OFF** and indicator changes to black). Of course, the **Stop (Esc)** button or the **Esc** key will do the same.
- **PTT Delay:** This control allows you to set the time delay between switching the radio to transmit and the first key closure.
- **Always On Top:** Check to keep this form always on top of any other windows that may be open.

### *Morse Definition Editor*

The Morse definition editor allows you to define and even redefine almost all of the characters in the sixty-four-character set. The combo box control to the right of the **cyan indicator** lets you view and select any of the characters in the set. Each one is displayed as four fixed width fields separated by the | character. There are five special control characters that you may not change and they have an \* in the element field.

Once you have selected the character that you wish to edit, left click to select and then right click to bring up the editor dialog.




*Figure 142: CW Definition Editor*

The editor dialog example above shows the `|` character being changed to send didahdidah which is the German code for **ä** (umlaut a). When your definition appears to be correct, click the **Save** button and the definition file will be resaved to the disk.

- The definition file is called **morsedef.txt** and can be found in the same folder as **PowerSDR.exe** and **PowerSDR.mdb**. It will not be automatically carried from one version to the next so if you make many changes you might want to save a copy elsewhere.
- The **morsedef.txt** file can be manually edited with a simple character editor like notepad (not Word), but the format must be followed *exactly*. Each line must be 26 characters long, not including the two end-of-line codes. It is not free-formatted. The line structure is: a two-digit number field (the decimal ASCII code) | a one-character code field | a nine character elements field | a ten-character comment field preceded by a space and followed by a carriage return and linefeed code. If you mess this file up too badly, simply close PowerSDR, delete **morsedef.txt**, and a clean, default copy will be created the next time you start. The editor makes simple changes relatively easy to do.

[The rest of this page has been left blank intentionally]

## (37) Mixer



*Figure 143: Audio Mixer Form*

The Mixer controls the audio lines into and out of the FLEX-5000. In essence it is no different than the usual Windows sound card mixer.

### Input

The FLEX-5000 has four possible sources of input audio. These are the **MIC** connector on the Front Panel and on the Back Panel through the **Line-In RCA** connector, the **Balanced Line In** ¼" TRS connector and the **FlexWire In** (pin 2 of the FlexWire connector). Check to select the desired input source (only one may be selected at a time) and adjust its signal level with the corresponding slider. Click **Mute All Inputs** to mute all the inputs.

### Output

There are three or four possible audio outputs depending on your radio model. These are the **Internal Speaker** (not available on the FLEX-5000A), the Front Panel **Headphones** connector and on the Back Panel the **Powered Speaker** and **Line Out RCA** connectors. The latter also adjust the FlexWire AF out (pin 9). More than one output can be selected at a time. Check to select the output and adjust its level with the slider. Click on **Mute All Outputs** to mute all the outputs.

[The rest of this page has been left blank intentionally]

## (38) Antenna

The Antenna Selection Form offers two levels of complexity:

- ❑ **Simple** uses the same antenna ports and keying lines for all bands. Different antennas can be selected for each receiver and the transmitter, but they will remain the same for all bands. This is the recommended setting if you use only one antenna.
- ❑ **Expert** allows you to customize antenna ports and keying lines for each band.

**WARNING!** Make sure you have an antenna connected to the Transmit antenna port you selected. Failing to do so may damage your radio and void your warranty.

**WARNING!** Do not switch the transmit antenna while transmitting (hot switching). You could damage your radio and void your warranty.

**Note:** If you switch between the **Expert** and **Simple** levels your settings will be remembered should you decide to change back.

[The rest of this page has been left blank intentionally]

## Simple

*Figure 144: Antenna Selection Form - Simple*

The following selections are possible:

- ❑ **Receiver 1:** ANT1 (default), ANT2, ANT3 or RX1 IN
- ❑ **Receiver 2** (if installed): N/C (not connected), RX2 IN, RX1 TAP (default) or ANT1<sup>1</sup>
- ❑ **Transmit:** ANT1 (default), ANT2 or ANT3<sup>2</sup>.
- ❑ **Use RX1 Out to RX1 In Loop:** If either ANT1, ANT2 or ANT3 is selected for Receiver 1, then this option becomes available to enable the insertion of external signal enhancing devices such as preamps, filters and preselectors, without requiring complicated switching mechanisms to avoid transmitting through them. Check to
  - Direct the signal on the selected antenna port to RX1 OUT and connect Receiver 1 to RX1 IN

<sup>1</sup> Earlier versions of the FLEX-5000, with the HRFIO board Assembly Number (ASSY) 27 installed instead of the later HRFIO board ASSY 34, do not have ANT1 available as an option for Receiver 2. You can check which board is installed in your FLEX-5000 by opening the Setup Form – General Tab, Hardware Config Sub-Tab, in the section marked FLEX-5000 Config. The Assembly Number is shown between brackets at the end of the line beginning with RFIO (see e.g. Figure 64 on page 81). Also see the Knowledge Center articles [HRFIO Capabilities by Assembly Number](#), [How to Identify the HRFIO Assembly Number](#) and [Antenna Selection Options for the RX2](#) (or search for HRFIO on our Knowledge Center at <http://kc.flex-radio.com/search.aspx>). If you have the earlier HRFIO ASSY 27, you can upgrade to ASSY 34. See the [Flex-Radio Systems website \(www.flex-radio.com\)](http://www.flex-radio.com) for more information.

<sup>2</sup> For the earlier RFIO board ASSY 27 (see above), the 6m transmit antenna port is fixed to ANT3 and cannot be changed. Only the ANT3 port meets the -60dBc spurious output requirement at 6m. For the later HRFIO ASSY 34, this is not the case and the 6m transmit antenna port can be assigned to any of ANT1-3, just like any other band.

- ❑ **Enable Preamp controls on 6m:** Check to enable the preamp to be turned off on 6m. Doing so will display a warning that the user accepts full responsibility for inserting an external preamp to maintain CE compliance.
- ❑ **Lock:** Check to lock the antenna selections for Receiver 1 and Transmit.
- ❑ **Switch Relay with TR:** Select the keying line(s) you use, if any, to key your amplifier(s) or other external equipment.
  - For each, check **Delay** to delay the switching of that keying line by the amount of time set in milliseconds. This enables sequential switching of the three keying lines to account for relay switching times and the like. Especially when using transverters, this can be useful.

Close the Antenna Form when you are done.

## Expert

*Figure 145: Antenna Selection Form - Expert*

In addition to the selections discussed for the Simple complexity level, the Expert level offers the **Band** control. For each band, set the various controls as desired and these settings will automatically be enabled when operating on that band.

[The rest of this page has been left blank intentionally]

**Hint:** To quickly set the various controls, make the selections first for the Simple complexity level. Then switch to Expert and adjust where necessary for those bands that need adjustment from the original settings.

[The rest of this page has been left blank intentionally]



## (39) ATU

*Figure 146: ATU Settings Form*

The ATU Settings form enables you to control the internal, optional ATU. If you do not have an ATU installed, this form will not be available to you.

### Operating Mode

- ❑ **Bypass:** Bypasses the internal ATU. When selected the **Tuning Options** become unavailable.
- ❑ **Semi-Automatic:** Requires pressing either **Memory Tune** or **Full Tune** to find a match.
- ❑ **Automatic:** Will automatically tune when RF is detected. You do not need to press either **Memory Tune** or **Full Tune**. Once selected, you can close the form. The ATU will now continuously monitor the SWR and retune as required.

**Note:** When set to **Automatic** it is possible that the ATU frequently retunes. If this is the case you can either try to select a higher **SWR Threshold** or select **Semi-Automatic** instead.

### Tuning Options

- ❑ **Memory Tune:** When pressed the ATU will perform a tuning cycle by first checking its memory for a match. If no match can be found, a **Full Tune** is performed. This is the fastest tuning option. While tuning is in progress, the button will be highlighted in yellow.
- ❑ **Full Tune:** When pressed, the ATU performs a tuning cycle ignoring its internal memory, which may take longer than **Memory Tune**. While tuning is in progress, the button will be highlighted in yellow.
- ❑ **Use TUN:** Check to transmit a carrier at the power level set by the **Tune Power** control on the Setup Form-Transmit Tab (see page 111). The ATU will use this carrier when either **Memory Tune** or **Full Tune** is selected.

## SWR Threshold


Sets the maximum SWR allowable for a match. This is measured at the input to the ATU. Setting a higher threshold may result in finding a faster match. Setting may result in taking longer to find a match and even risk finding no match at all.

## Tuner Feedback

Result of the tuning cycle. The possible messages are:

- ❑ **Tune Completed Successfully:** A match was found. The ATU will also display the detected Frequency of the input signal and the resulting SWR, Forward and Reflected Power, all measured at the input to the ATU.
- ❑ **Failed Tune – RF Carrier Lost:** ATU was attempting to tune, but the Input signal disappeared before a match could be found
- ❑ **Failed Tune – Unable to Bring the SWR Down to the Threshold:** No match could be found below the set **SWR Threshold**. If possible, try raising the threshold.
- ❑ **Failed tune – No RF Detected:** No input signal was detected while the ATU was attempting to tune.

## Voltage and Temperature Information



*Figure 147: Info Form*

The keyboard combination **Ctrl-Shift-I** will display the voltage and temperature. Clicking on the temperature will alternate its value between Celsius and Fahrenheit. Either value may be displayed against a yellow or red background indicating increasing levels of criticality.

[The rest of this page has been left blank intentionally]

# Operation

This chapter is intended to provide the user with a clear understanding of how the FLEX-5000 should be used when performing basic operations such as Powering Up or making a voice transmission. We chose to use this section in this way in lieu of listing all of the features of the radio since the feature list would essentially repeat the information given in the three preceding chapters. Please refer to those chapters for complete feature descriptions and how to use the controls.

**Note 1:** For consistency we will use the same control identifiers as used in Figure 33 on page 50. For clarity we will leave out any identifiers of controls not referenced in the relevant section

**Note 2:** If you have any questions, issues or problems operating PowerSDR and/or the FLEX-5000, you may be able to find the solution on the [Support Pages](http://support.flex-radio.com/) (<http://support.flex-radio.com/>) of our website, in our [Knowledge Center](http://kc.flex-radio.com/search.aspx) (<http://kc.flex-radio.com/search.aspx>), or through our highly active [Reflector](#). (search for *reflector* on our Knowledge Center at <http://kc.flex-radio.com/search.aspx>). If none of these sources provide you the assistance required, please contact FlexRadio Systems using the information provided on the [Contact page](#) of our website (on our website [www.flex-radio.com](http://www.flex-radio.com) click *About FlexRadio* and then *Contact Us*).

[The rest of this page has been left blank intentionally]

## Power-Up Procedure

To power up the FLEX-5000A

1. Connect the FLEX-5000A to the computer and the power supply. (see **Installing the FLEX-5000A** on page 18 for more detailed information). Check the connections to ensure good contact.
2. Boot up the computer and make sure PowerSDR is ready to be launched (no hour glass cursor).
3. Turn on the power supply for the radio and press the FLEX-5000A power switch. After a few seconds you will hear the internal power relay click and see the blue LED illuminate. The FLEX-5000A will be recognized by Windows and its driver will be available for PowerSDR to use.
4. After waiting at least 30 seconds, start up PowerSDR. It will automatically recognize the FLEX-5000 driver. You are now ready to operate.

To power up the FLEX-5000C

1. Connect a monitor, mouse and keyboard to the FLEX-5000C. (see **Installing the FLEX-5000C** on page 14 for more information) and connect the FLEX-5000C to the power supply.
2. To start both the radio and the internal computer, turn on the power supply and press the FLEX-5000C power switch. After a few seconds you will hear the internal power relay click and see the blue LED illuminate as well as the green light on the wireless keyboard controller.
  - a. Press and release the **connect** button on the wireless keyboard controller.
  - b. Press and release the **connect** button on the bottom of the keyboard. Wait at least 20 seconds before the next step.
  - c. Press and release the **connect** button on the wireless keyboard controller again.
  - d. Press and release the **connect** button on the bottom of the mouse.
  - e. Move the mouse and check for pointer motion on the display.
3. At this point you should see the Windows opening screen.
4. After waiting at least 30 seconds, start up PowerSDR. It will automatically recognize the FLEX-5000 driver. You are now ready to operate.

[The rest of this page has been left blank intentionally]

## Power-Down Procedure

The power-down sequence is almost the reverse of the power-up procedure.

1. Stop PowerSDR by clicking on the Start/Stop button.
2. Close PowerSDR by clicking on the "X" in the upper right hand corner of the Front Console.
3. Press the FLEX-5000 blue illuminated Power switch to turn off the transceiver.

**CAUTION:** Make sure PowerSDR is shut-down before turning off the radio. Failing to do so may result in instability of your computer system, leading to a *Blue Screen*.

**Note:** The FLEX-5000C power switch will turn on both the transceiver and the internal computer, but only turn off the transceiver. To turn off the internal computer, click with your mouse on **Start** and then on **Turn Off Computer**, just as you would any other Windows computer.

[The rest of this page has been left blank intentionally]

## Tuning Methods

### *Spectrum Drag and Click*

The easiest way to tune signals on the display when set to Panadapter or Waterfall is simply to click on the signal, and drag it into the filter area. You can also drag the displayed filter edges to adjust the filter width as well. This will work for RX1 and RX2, depending on which Panadapter/Waterfall the mouse cursor is in.

### *Mouse Wheel*

A mouse wheel is the next easiest way to tune the radio. While the PowerSDR window is active, tune **VFO A** using the mouse wheel, with the mouse cursor anywhere on the screen. The frequency will change in steps equal to the selected **Tune Step (2)** for each click of the mouse wheel. Adjust the **Tune Step** using the controls, clicking the mouse wheel or pressing Ctrl + Left or Right Arrow key.

If RX2 is installed and on, then the mouse wheel will tune **VFO B** only if the mouse pointer is anywhere in the RX2 Panadapter or Waterfall display.

**Note:** When the **Tune Step** equals 1kHz, each click of the mouse wheel will first snap tune up or down to the nearest 1kHz and then change in 1kHz steps. E.g. if **VFO A** is tuned to say 14.000258MHz then with the tuning rate set to 1kHz, using the mouse wheel to tune up will first increase **VFO A** to 14.001000MHz and then to 14.002000MHz, and so on.

**Hint:** Holding down the Shift key while turning the mouse wheel will change **VFO A** (or for RX2 **VFO B**) at the next lower **Tune Rate**.

### *Mouse Wheel Hover*

Hover with the mouse over a digit in either **VFO A** or **VFO B** (or the lower part of **VFO A** if applicable) and increase or decrease its value using the mouse wheel. The digit to be tuned will be underlined.

### *Spectrum Click Tuning*

With the RX1 display set to Spectrum, Panadapter, Waterfall or Histogram, hover with the mouse over the RX1 display and right click to cycle through yellow cross-hairs to tune **VFO A**, red cross-hairs to tune **VFO B** - or the **lower part of VFO A** if RX2 is on - (only if **VFO B** is active, e.g. when **SPLT (12)** and/or **MultiRX (10)** are activated), or no cross-hairs (click tuning off). With the cross-hairs visible, hover over the desired signal in the RX1 display and click the left mouse button. The corresponding VFO will immediately tune to the frequency of the selected signal.

If RX2 is installed and on, hover with the mouse over the RX2 display and right click to activate the yellow cross-hairs; right click again to turn click tuning off. With the cross-hairs visible, hover over the

desired signal in the RX2 display and click the left mouse button. **VFO B** will immediately tune to the frequency of the selected signal.

When in CW, AM, SAM, DSB, FM, or DRM the VFO will tune the cursor frequency to the center of the filter pass band. In SSB the VFO will tune to the carrier frequency for the sideband selected.

**Hint 1:** You can very quickly center a CW, (S)AM, DSB or FM signal after click tuning it by clicking the **0 Beat (12)** button on the Front Console (make sure the display **AVG (9) or (9b)** button is on to enable **0 Beat**).

**Hint 2:** If you have checked **Snap ClickTune** (Setup Form, General tab - Options sub-tab; see page 85) then spectrum click tuning will tune the VFO to the nearest discrete multiple of the Tune Step. E.g. if the Tune Step is set to 1kHz, the VFO will only ClickTune in steps of 1kHz.

## *Keyboard Keys*

Use the following keys on your keyboard to tune the VFO.

- ❑ **Numeric Keypad:** Key any frequency in MHz (e.g. 7.250) into the numeric keypad and hit enter to immediately tune **VFO A** to that frequency.
- ❑ **Mapped Keys:** You can map keys on your keyboard to tune each of the digits in **VFO A** using the Keyboard Tab on the Setup Form (page 123).
- ❑ **Ctrl +Arrow Keys:** Hold the Control key and press the
  - Up or Down Arrow key to tune **VFO A** up or down by the **Tune Step (2)**.
  - Right or Left Arrow key to increase or decrease the **Tune Step (2)**.

## *USB Tuning Knob*

Both the Griffin PowerMate and the Contour Designs Shuttle Pro v2 can be used to tune the radio. You can download the [Griffin PowerMate Quick Start Guide](#) and the [Contour ShuttlePro v2 Quick Start Guide](#) from the downloads page of our website to learn how to setup and use these controllers. Also available is the [Contour ShuttlePro Default Preferences](#) file, which can be imported as a good starting point when using this controller. (All these documents and more can be found by searching for either *PowerMate* or *ShuttlePro* on our Knowledge Center at <http://kc.flex-radio.com/search.aspx>)

[The rest of this page is intentionally left blank]

# Voice Transmission Operation

The following procedure outlines how to setup quickly for voice transmission operation (SSB, AM, or FMN). If something in this procedure is unclear, please contact us, as we would like this to be as simple as possible.




Figure 148 Front Panel Controls Used for Basic Voice Operation.

Please use Figure 148 to identify the controls referenced in the following step-by-step instruction. For consistency we have used the same control identifiers as in Figure 33 on page 50 and for clarity we have left out any identifiers of controls not referenced.

**Note:** In this chapter, we will only describe basic operation using the main RX1 receiver.

[The rest of this page has been left blank intentionally]



1. Follow the Power Up Procedure, described on page 156. Then click the **Start/Stop** button **(14)**. Set the following controls as specified in Table 11 below.

*Table 11: Initial Control Values for Voice Operation*

Ctrl	Value	Reference to Figure 148
VFO A	14.3MHz	(1)
RX1 Meter	Signal	(4)
TX Meter	MIC	(4)
BAND	20	(5)
Mode	USB	(6)
Filter	2.7kHz	(7)
Mic Gain	35	(8)
DX	Off	(8)
CPDR	Off	(8)
VOX	Off	(8)
GATE	Off	(8)
RX EQ	Off	(8)
TX EQ	Off	(8)
VAC	Off	(8)
Display Mode	Panadapter	(9)
AVG	On	(9)
PEAK	Off	(9)
MultiRX	Off	(10)
SPLT	Off	(12)
XIT	Off	(12)
RIT	Off	(12)
MUT	Off	(17)
ATU/BYP	ATU (if applicable)	(20)
AF	50	(21)
AGC-T	70	(22)
Drive	50	(23)
AGC	Med	(24)
Preamp	On	(25)
SQL	Off	(26)
RX2	Off (if applicable)	(29)

2. In the **Antenna Form (38)** choose **Simple** complexity level and set **RX1** to **ANT1** (see page 149 for more on the Antenna Form). Connect a 50 ohm dummy load to the ANT 1 antenna jack, or tune **VFO A (1)** to a quiet frequency on the selected band. Use the **TUN (19)** button to verify power output on the **TX Meter (4)** (Set to **Fwd Pwr**). If using the optional, integrated ATU, select **Automatic** on the **ATU Form (39)** and then click the **TUN (19)** button. See the section on the **ATU Form** on page 153 for more on how to use the ATU.

[The rest of this page has been left blank intentionally]

**CAUTION:** If using neither the ATU, nor a 50 ohm dummy load, ensure that the antenna presents a 50 ohm load with a low SWR or damage may occur to the FLEX-5000 output transistors.

3. Press the Push-to-talk button on the microphone or click the **MOX (16)** button and speak into the microphone to transmit your voice. Release the Push-to-talk button or click the **MOX (16)** button to switch the transceiver back to receive.

If you do not see modulation on the spectrum, please check that the correct input for your microphone is selected in the **Mixer Form (32)** (see page 148) and that your microphone is connected correctly (see pages 5 and 10 for pin-outs of the MIC connector and Balanced Line-In jack respectively). If you are using any external audio processing equipment, make sure it is turned on and hooked up correctly. Finally, if your audio level seems very low, you might try checking **Mic Boost On** on the Setup form – Audio tab, primary sub-tab (see page 90).

4. Now that you can see the modulation on the spectrum, it is time to adjust the input. While transmitting, monitor the values with the **TX Meter (4)** set to **Mic**. Modify the **MIC Gain (8)** setting until the **TX Meter** shows 0dB on peaks while talking in a normal voice at a normal distance from the microphone (above 0dB the signal will be compressed).
5. You are now ready to begin a QSO. If a 50 ohm dummy load was connected, connect an antenna in its place. Tune to the desired frequency using one of the methods outlined in the Tuning Methods section above.

Use the **Mode Specific Controls – Phone (8)** including **DX**, **CPDR**, **VOX** and **(Noise) Gate**. Generally, use either **DX** or **CPDR** to increase average power without adjusting the peaks. Check **Show Transmit Filter on Display** to visualize the band edges of the transmit filter. This filter can be adjusted on the Transmit Tab of the Setup Form.

**Hint:** For information on how to optimize your audio further, please refer to the **Knowledge Center** (<http://kc.flex-radio.com/search.aspx>) on our website.

6. In order to monitor voice transmissions, enable the **MON (15)** button. You may notice a delay due to buffering in the audio/DSP system. This processing delay is largest when using large buffer sizes and low sampling rates. If you find this delay objectionable, try decreasing it by reducing the **Buffer Size** and increasing the **Sample Rate** settings on the Audio tab, Primary sub-tab (page 90) and/or DSP tab, Options sub-tab (page 99) of the Setup Form. Make sure that when changing either the Audio Buffer Size, you first **Stop (14)** PowerSDR and make the same change in the FLEX-5000 Driver (see page 27) before Starting PowerSDR again. See also Appendix A.
7. The **Fwd Pwr** setting on the **TX Meter (4)** will read out average power in Watts according to the PA ADC. While the average has a short time constant, it is still an average and will not approach 100W in voice modes if calibrated properly even when the **Drive** control (**21**) is set to 100. This is also true when monitoring voice transmissions on an external watt meter.

**Note:**

The typical male voice has a peak to average power ratio of 14dB. Therefore a typical male voice transmission that is peaking at 100W will only average less than 10W. To raise the average power, use the **DX (8)** control and the associated slider to increase the compression in 1dB steps. This must be done carefully and incrementally as adding too much compression can result in high levels of distortion.

[The rest of this page has been left blank intentionally]

# CW Transmission Operation

The following procedure outlines how to setup quickly for CW transmissions using the Internal Keyer and paddles, an external keyer, the CWX-form or a third party program. For the latter, we will use MixW as an example.




Figure 149: Front Panel Controls Used for CW Operation

Please use Figure 149 to identify the controls referenced in the following step-by-step instruction. For consistency we have used the same control identifiers as in Figure 33 on page 50 and for clarity we have left out any identifiers of controls not referenced.

[The rest of this page has been left blank intentionally]

## Initial Settings

1. Follow the Power Up Procedure, described on page 156. Then click the **Start** button **(14)**. Set the following controls as specified in Table 12.

*Table 12: Initial Control Values for CW Transmission*

Ctrl	Value	Reference to Figure 149
VFO A	14.05MHz	(1)
RX Meter	Signal	(4)
TX Meter	Fwd Pwr	(4)
Band	20m	(5)
Mode	CWU	(6)
Filter	500Hz	(7)
VAC	Off	(8)
Display Mode	Panadapter	(9)
AVG	On	(9)
PEAK	Off	(9)
MultiRX	Off	(10)
SPLT	Off	(12)
XIT	Off	(12)
RIT	Off	(12)
MON	On	(15)
MUT	Off	(17)
ATU/BYP	ATU (if applicable)	(20)
AF	50	(21)
AGC-T	70	(22)
Drive	25	(23)
AGC	Med	(24)
Preamp	On	(25)
SQL	Off	(26)
RX2	Off (if applicable)	(29)

2. In the **Antenna Form (38)** choose **Simple** complexity level and set **RX1** to **ANT1** (see page 149 for more on the Antenna Form). Connect a 50 ohm dummy load to the ANT 1 antenna jack, or tune **VFO A (1)** to a quiet frequency on the selected band. Use the **TUN (19)** button to verify power output on the **TX Meter (4)** (Set to **Fwd Pwr**). If using the optional, integrated ATU, select **Automatic** on the **ATU Form (39)** and then click the **TUN (19)** button. See the section on the **ATU Form** on page 153 for more on how to use the ATU.

**CAUTION:** If not using the ATU and not using a 50 ohm dummy load, ensure the antenna presents a 50 ohm load with a low SWR or damage may occur to the SDR output transistor.

[The rest of this page has been left blank intentionally]


**Hint:** There is a trade-off to be made of minimum latency versus sharpest (narrowest) filters. Both are driven by the buffer (DSP and Audio) settings and the sample rate setting. For optimal CW performance, you may need to use either the 48kHz or 96kHz sample rates, where the former will give the narrowest filters. Next you need to set your audio buffer as low as your computer system will tolerate. The DSP buffer setting should then be set as high as possible, without introducing disturbing latency. See Appendix A for a more detailed explanation.

**Note:** **CW VFO Frequency Offset**  
The VFO on the PowerSDR software is designed to show the zero beat of the CW tone relative to the selected CW Pitch. This allows click-tuning of CW signals as well as the traditional CW VFO readout. This also enables the VFO to remain constant when switching from CWL to CWU mode. Every effort is made to preserve a CW signal when switching between any SSB and CW modes.

## Internal Keyer

If using PowerSDR's internal keyer, open the Setup Form – DSP Tab, Keyer Sub-Tab shown in Figure 150 below. Several of the controls in this form are also available in the **Mode Specific Controls – CW (8)** section on the Front Console.

[The rest of this page has been left blank intentionally]



*Figure 150: Setup Form – DSP Tab, Keyer Sub-Tab*


1. Connect your paddles or keyer to the Key jack on the back panel (see page 8) and set the **Primary Connection** to **5000**.
2. In the **Options** section, check **Iambic** for Iambic mode, otherwise leave unchecked (e.g. for a straight key). If the paddles seem reversed, check **Rev. Paddle**. The **Break In** option allows the radio to start transmitting simply with detection of keyer input. Set **Delay** to the amount of time between key up and when the radio will switch back to receive (a value of 70-75ms seems to work best in most cases).
3. Select the settings for **CW Pitch**, **Weight** and **Ramp** as desired (refer to the Keyer Sub-Tab section on page 106 for more detail).
4. If not using **Break In**, click **MOX (16)** on the Front Console and begin transmitting using your paddles. If using **Break In (8)**, simply begin transmitting to key the radio. If using Iambic mode, adjust the speed with **CW Speed (8)** on the Front Console. If **Disable Monitor** is unchecked, you should hear the side tone. Verify with the **TX Meter (4)** set to **Fwd Pwr** that there is forward power.
5. You are now ready to begin a QSO. If a 50 ohm dummy load was connected, connect an antenna in its place. Tune to the desired frequency using one of the methods outlined in the Tuning Methods section above. Select either **CWL** or **CWU (6)** and proceed with the QSO.

## External Keyer

1. Connect your paddles or keyer to the Key jack on the back panel (see page 8) and set the **Primary Connection** to **5000** (see Figure 150 above)
2. In the **Options** section, leave **Iambic** unchecked. If your external keyer does not seem to be keying, try checking **Rev. Paddle**. If using an external keyer with a side tone, check the **Disable Monitor** check box to avoid hearing the side tone from the internal keyer. The **Break In** option allows the radio to start transmitting simply with detection of keyer input. Set **Delay** to the amount of time between key up and when the radio will switch back to receive.
3. If using the side tone from the internal keyer, select the settings for **CW Pitch**. Select the settings for **Weight** and **Ramp** as desired (refer to the Keyer Sub-Tab section on page 106 for more detail).
4. If not using **Break In**, click **MOX (16)** on the Front Console and begin transmitting using your external keyer. If using **Break In**, simply begin transmitting to key the radio. If **Disable Monitor** is unchecked, you should hear the side tone. Verify with the **TX Meter (4)** set to **Fwd Pwr** that there is forward power.
5. You are now ready to begin a QSO. If a 50 ohm dummy load was connected, connect an antenna in its place. Tune to the desired frequency using one of the methods outlined in the Tuning Methods section above. Select either **CWL** or **CWU (6)** and proceed with the QSO.

## CWX Form

If you wish to send CW automatically, click on **CWX (36)** on the Front Console menu to open the CWX Form shown Figure 151 below. (Refer to the CWX Form section on page 143 for more detail on how to use this form).



*Figure 151: CWX Form*

1. Click on one of the numbered buttons to start transmitting the corresponding CW sequence. Verify with the **TX Meter (4)** set to **Fwd Pwr** that there is forward power.
2. You are now ready to begin a QSO. If a 50 ohm dummy load was connected, connect an antenna in its place. Tune to the desired frequency using one of the methods outlined in the Tuning Methods section above. Select either **CWL** or **CWU (6)** and proceed with the QSO.




## Third Party Program

To operate CW with a third party program, you will need to download and install N8VB's vCOM driver to create a virtual COM port pair through which PowerSDR can be connected to your third party program. The installation and setup of vCOM is described below in the Digital Mode Operation section on page 175.


In the following we will use MixW as an illustrative example and we will assume the COM6-COM16 virtual COM port pair. We will also assume that PowerSDR is connected to COM6 and MixW to COM16 of this pair (see page 175 for details on how to do this).

In PowerSDR open the **Setup Form – DSP Tab, Keyer Sub-Tab** shown Figure 152 below to access the Internal Keyer controls



*Figure 152: Setup Form – DSP Tab, Keyer Sub-Tab*


2. Set **Secondary Connection** to **CAT** to use the same virtual COM port COM16, as selected on the **CAT Control Tab**. This will open up two additional selection boxes. Set **PTT Line** to **DTR** and **Key Line** to **RTS** as shown above.
3. In MixW, click **Configure** on the Menu bar and then select **TRCVR CAT/PTT** to open the screen shown in Figure 153.



*Figure 153: MixW PTT & CAT*

4. On the **PTT & CAT Interface**, click on the **Details** button to open the following form (Figure 154):

[The rest of this page has been left blank intentionally]



*Figure 154: MixW Serial Port Details*

5. Set the **Port** to **COM16**, **RTS** to **CW** and **DTR** to **PTT**. Click OK on this form and the previous form.
6. Change the mode in MixW to CW. Click on the **TX** button on MixW's main panel. It should key PowerSDR without generating a tone. Click **RX** in MixW and PowerSDR should return to receive. If you have entered your callsign in MixW, click on the **CQ** button. It should key the radio and produce Morse code calling CQ with your call sign. Verify with the **TX Meter (4)** set to **Fwd Pwr** that there is forward power.
7. You are now ready to begin a QSO. If a 50 ohm dummy load was connected, connect an antenna in its place. Tune to the desired frequency using one of the methods outlined in the Tuning Methods section above. Select either **CWL** or **CWU (6)** and proceed with the QSO.

[The rest of this page has been left blank intentionally]

# Digital Mode Operation

To operate digital modes, PowerSDR needs to connect to third party digital mode programs with both CAT control and Audio connections. PowerSDR realizes the CAT control connection through N8VB's virtual COM port utility (VCOM) and the Audio connection through the Virtual Audio Cable (VAC) utility. We will explain later in this section how to install and setup each of these two utilities. First, however, we will outline how to operate digital modes with these utilities installed and setup.

**Note:** Throughout this section we will refer to *digital mode programs*, which also include logging programs. For the latter the CAT control section applies to enable reading and possibly also controlling PowerSDR's frequency, band, and operating mode. If the logging program includes a voice keyer, the VAC section may also be relevant.




Figure 155: Front Panel Controls Used for Basic Digital Mode Operation

Please use Figure 155 to identify the controls referenced in the following step-by-step instruction. For consistency we have used the same control identifiers as in Figure 33 on page 50 and for clarity we have left out any identifiers of controls not referenced.

1. Follow the Power Up Procedure, described on page 156. Then click the **Start** button **(14)**. Set the following controls as specified in Table 13.

*Table 13: Initial Control Values for Digital Mode Operation*

Ctrl	Value	Reference to Figure 155
VFO A	14.09MHz	<b>(1)</b>
RX Meter	Signal	<b>(4)</b>
TX Meter	Fwd Pwr	<b>(4)</b>
BAND	20	<b>(5)</b>
Mode	DIGU	<b>(6)</b>
Filter	2.7kHz	<b>(7)</b>
VAC	On	<b>(8)</b>
Display Mode	Panadapter	<b>(9)</b>
AVG	On	<b>(9)</b>
PEAK	Off	<b>(9)</b>
MultiRX	Off	<b>(10)</b>
SPLT	Off	<b>(12)</b>
XIT	Off	<b>(12)</b>
RIT	Off	<b>(12)</b>
MUT	Off	<b>(17)</b>
ATU/BYP	ATU (if applicable)	<b>(20)</b>
AF	50	<b>(21)</b>
AGC-T	70	<b>(22)</b>
Drive	25	<b>(23)</b>
AGC	Med	<b>(24)</b>
Preamp	On	<b>(25)</b>
SQL	Off	<b>(26)</b>
RX2	Off (if applicable)	<b>(29)</b>

2. Ensure that on the PowerSDR Setup Form **Cat Control** is enabled (see page 125). Also check that **VAC (8)** is enabled (if VAC is auto-enabled on the Setup Form (see page 93) it will automatically be enabled when **DIGL, DIGU** or **DRM (6)** modes are selected).
3. Start up your digital mode program and ensure its CAT control and sound card selection are configured to connect to PowerSDR. If so, your digital mode program's frequency should correspond to PowerSDR's VFO frequency and it should be receiving Audio from PowerSDR. Use the **RX Gain (8)** control to adjust the audio level going to your digital mode program (instead of the **AF (21)** ).
4. In the **Antenna Form (38)** choose **Simple** complexity level and set **RX1** to **ANT1** (see page 149 for more on the Antenna Form). Connect a 50 ohm dummy load to the ANT 1 antenna jack, or tune **VFO A (1)** to a quiet frequency on the selected band. Use the **TUN (19)** button to verify power output on the **TX Meter (4)** (Set to **Fwd Pwr**). If using the optional, integrated ATU, select **Automatic** on the **ATU Form (39)** and then click the **TUN (19)** button. See the section on the **ATU Form** on page 153 for more on how to use the ATU.

**CAUTION:** If not using the ATU and not using a 50 ohm dummy load, ensure that the antenna presents a 50 ohm load with a low SWR or damage may occur to the SDR output transistors.

5. Click on the Transmit button of your digital mode program. It should switch PowerSDR to transmit. Transmit a test signal (e.g. several CQ calls) in the mode you plan to operate and use the **TX Gain (8)** control to adjust the volume of audio coming from your digital mode program. Set the **TX Meter (4)** to **ALC** and adjust for 0dB to calibrate transmit. Click on Receive on your digital mode program and PowerSDR should switch back to receive.
6. You are now ready to begin a QSO. If a 50 ohm dummy load was connected, connect an antenna in its place. Tune to the desired frequency using one of the methods outlined in the Tuning Methods section above. Select either **DIGL** or **DIGU (6)** for lower or upper side band digital mode operation respectively. Select **DRM (6)** for DRM mode operation.

**Note 1:** The **DIGL**, **DIGU** and **DRM (6)** mode buttons bypass all signal processing in PowerSDR, except for AGC and Filtering. With **DIGL** and **DIGU** you have control over the filter width using the filter buttons **(7)**. **DRM** mode invokes a fixed 10kHz wide double side band filter.

**Note 2:** **DIGL** and **DIGU (6)** apply an offset when using Spectrum Click Tuning (see page 85). By default, the offsets are set to 1200 Hz (SSTV) in **DIGU** mode and 2210 Hz (RTTY) in **DIGL** mode respectively. These offsets can be modified on the Setup Form - General Tab, Options Sub-Tab.

Separately, so called **RTTY Offsets** (for **DIGU** and **DIGL** mode) can be applied to the **VFO A** (and/or **VFO B**) frequency, before CAT reports it to a third party program (see page 124). These offsets can be modified on the Setup Form - CAT Control Tab.

**Hint 1:** When operating digital modes you have two options with regard to using filters. On the one hand you can use a wide band-pass filter in PowerSDR and use the filters within your digital mode program for selectivity.

On the other hand you can home in on a specific signal with PowerSDR's filters and ignore the filters in your digital mode program. Although circumstances and operator preference will dictate which to use, many operators have found the second option to be especially valuable to them. However for very narrow and/or steep filters, the latency versus minimum filter bandwidth trade-off holds just as much as with CW. See Appendix A for more detail.

**Hint 2:** Please check our [Knowledge Center](http://kc.flex-radio.com/search.aspx) (<http://kc.flex-radio.com/search.aspx>) for more articles on how to use PowerSDR with various digital mode programs.

If you already have VCOM and VAC up and running, you may ignore the following sub-sections.

We will now focus on installing and setting up N8VB's VCOM driver and VAC. We will then use MixW as an example on how to use these utilities to operate digital modes.

## CAT Control Setup

The CAT control commands of PowerSDR are based on those of the Kenwood TS2000 and have been extended to cover PowerSDR's many unique features. Additionally, PowerSDR can provide a virtual COM port connection to third party software through VCOM port driver. Special thanks go to N8VB, K5KDN, and KD5TFD for their work on the CAT interface to make all of this work.

The following procedure outlines how to install and setup VCOM.

### *Install VCOM*

First download and install N8VB's [Virtual Serial Port Driver \(VCOM\)](http://support.flex-radio.com/Downloads.aspx?fr=1) (search for N8VB on the Downloads page of our website at <http://support.flex-radio.com/Downloads.aspx?fr=1>). This program installs one or more pairs of virtual COM ports connected in null modem style. Locate the file you just downloaded (**N8VBvCOMSetup-226a.exe**) and double-click to start the Windows installer. The following screen will appear (Figure 156).



*Figure 156: VCOM Installer Language*

Select your language of choice and click **OK**. The welcome screen appears (Figure 157).

[The rest of this page has been left blank intentionally]




*Figure 157: VCOM Installer Welcome Screen.*

Click the **Next** button to continue the driver installation (Figure 158).

[The rest of this page has been left blank intentionally]






*Figure 158: VCOM License Agreement.*

Review the License Agreement and click the **I Agree** button.


[The rest of this page has been left blank intentionally]



*Figure 159: VCOM Installer Component Selection.*

Select the components you wish to install and click the **Next** button.

[The rest of this page has been left blank intentionally]



*Figure 160: VCOM Install Location*

Choose the folder in which to install the driver application in and click the **Install** button.

[The rest of this page has been left blank intentionally]



*Figure 161: VCOM Installer Complete*

Click the **Finish** button to complete the installation of VCOM. The virtual serial port driver will now be installed on your system. A Command Prompt window displaying status messages will open followed by the warning screen shown in Figure 162 below.

[The rest of this page has been left blank intentionally]




*Figure 162: Hardware Installation Warning*

Click on the **Continue Anyway** button to complete the installation.

### *Configure the VCOM Port Pairs*


By default VCOM will install 4 COM port pairs. To view these pairs, to change the default or to remove the driver, locate and start the **VCOMConfigurator** application (Start→All Programs).



*Figure 163: VCOMConfigurator Application*

This will open the following screen (Figure 164).

[The rest of this page has been left blank intentionally]




*Figure 164: VCOMConfigurator*

With VCOMConfigurator, you can select, unselect and modify the desired COM port pairs. Click the **Save Configuration** button to save your configuration and click **Update Driver** to update the driver with the new settings. From here you can also remove and install the driver. When you are finished, close VCOMConfigurator .

Now that the virtual COM port pairs are installed, we need to setup the applications to use them. We'll start with the PowerSDR software. Start up the program and pull up the CAT Control Tab on the Setup Form. For the purpose of this example, we will use the COM6-COM16 pair.

[The rest of this page has been left blank intentionally]

## Configure PowerSDR CAT Control



*Figure 165: Setup Form Cat Control Tab*

Set the controls in the **CAT Control** Group on the left side of this form to match those shown in Figure 165 to connect PowerSDR to COM 6 of the COM6-COM16 pair. (If you changed the COM port pair settings in VCOMConfigurator you will need to modify the COMx setting to match that change). Set the **ID** as **TS-2000**. Once all of the settings are correct, click the **Enable CAT** check box.


**Note 1:** Until external applications incorporate the **FLEX-5000** with its extended set of CAT controls, it is more prudent to select the **TS-2000**.

**Note 2:** Some third party applications do not allow you to connect to a high COM port number. In such a case swap COM6 to COM16 above and connect the digital program to COM6. Alternatively, create an even lower virtual Com port number (e.g. COM3), that is not physically present.

[The rest of this page has been left blank intentionally]

### Configure PowerSDR Keyer Connections

We can setup PowerSDR to connect to third party CW programs using the CAT port (i.e. the COM port used for CAT control - COM 6 in Figure 165). To do so, on the PowerSDR Setup Form, select the DSP Tab and then the Keyer Sub-Tab (Figure 166).



*Figure 166: Setup Form - DSP Tab, Keyer Sub-Tab*

Within the **Connections** Group, set **Primary** to the port you have your paddles or straight key connected to (Figure 166 shows 5000 to indicate the FLEX-5000 rear panel key jack). Set **Secondary** (used for keyers and programs) to **CAT** to use the same (virtual) COM port used for CAT Control. Set **PTT Line** to **DTR** and **Key Line** to **RTS**. Note that CAT Control must be enabled (see the previous section) before this will work. Click **OK**.

[The rest of this page has been left blank intentionally]




## Virtual Sound Connection

Although you can use a second sound card to connect to an external digital mode program, PowerSDR has the ability to use a virtual sound connection. To do so you will first need to download and install the third party [Virtual Audio Cable \(VAC\)](http://software.muzychenko.net/eng/vac.html) (<http://software.muzychenko.net/eng/vac.html>) application from one of many sources. VAC is neither free nor open source.

**Note:** PowerSDR will work correctly with VAC version 3.12 as well as version 4.02 and above. In the following we will use version 4 to illustrate, but version 3 works essentially the same way.

In essence VAC enables the creation of so called digital virtual audio cables between two software applications, in our case PowerSDR and a digital mode (or sound card program) as shown in Figure 167. When setup correctly, these cables appear as input and output audio devices, as if they belonged to a sound card.



*Figure 167: VAC Connects Audio Digitally Between PowerSDR and a Digital Mode Program*

### Create the Virtual Audio Cables

The first step is to create the two identical virtual cables. To do so open the Virtual Audio Control Panel.

[The rest of this page has been left blank intentionally]




Figure 168: VAC Control Panel

By default two audio cables will be defined. Highlight the appropriate cable and change the values to match Figure 168. In the **Ms per int** box enter a value between 1 and 20 ms. The lower the value, the smaller the VAC audio buffer. In the example above, 7 ms was selected. Depending on your computer setup you may have to adjust this value to prevent the audio from dropping out or "popping".

You can choose two different **Stream limit formats**; cable format and cable range. Since PowerSDR defines both audio cables' format when VAC support is enabled, using the **Cable format** is recommended. If you decide to use the **Cable range** stream format, a required format conversion will use significant CPU resources and may noticeably slow your applications causing audio drops-outs. Using **Cable format** as the stream format may then help.


Repeat these changes for the second audio cable. After completing all of the necessary changes, click on **Set** for each cable when completed. Do not close the Control Panel just yet.

**Note:** Do NOT check the **Volume Control** box in the VAC control panel. This enables the Windows Mixer and can cause unpredictable results.

[The rest of this page has been left blank intentionally]

## Setup VAC in PowerSDR

Next we need to connect PowerSDR to one side of each of these cables. Startup PowerSDR, but do not click on the **Start** button. Open the Setup Form, click on the Audio Tab and then click on the VAC Sub-Tab (Figure 169).



*Figure 169: Setup Form - Audio Tab, VAC Sub-Tab*

Configure the settings as shown above. If your selected Buffer Size setting is too small, you may experience audio popping or dropping out. Click **Enable VAC** to manually enable the virtual audio connection or click Auto Enable to automatically enable it when clicking the **DigL**, **DigU** or **DRM** mode button on the Front Console.

**Note 1:** Select a *higher* **Sample Rate** than the sample rate of the digital mode program for best audio quality. In some cases, however, the digital mode program can not handle format down conversion very well. In such cases, set the **Sample Rate** to *exactly match* that of the digital mode program.

**Note 2:** Certain **DRM** programs (DReaM, HamPal) require Stereo to be selected.

## Setting up Third Party Digital Programs

Each third party program has its own method of configuring CAT Control and selecting the COM port and the sound card. In the following, we will use MixW as an illustrative example. We will also discuss how to deal with digital programs that are only able to connect to the default sound device.

**Note:** Instructions for MMTTY, MMSSTV and WSJT 6 and others can be found in our [Knowledge Center](http://kc.flex-radio.com/search.aspx) at <http://kc.flex-radio.com/search.aspx>.

### Using MixW with PowerSDR

Start MixW, which may be downloaded from <http://www.mixw.net/>.





Figure 170: MixW Console

First we will configure MixW to connect through the virtual COM port pair to PowerSDR. Click **Configure** on the Menu bar and then select **TRCVR CAT/PTT** to open the following screen (Figure 171).




*Figure 171: MixW PTT & CAT*

Configure the controls as shown above. MixW does not recognize the extended FLEX-5000 CAT controls yet. Therefore we set it up as if PowerSDR were a Kenwood radio (In MixW **All Kenwoods** is the only option available when **CAT** is set to **Kenwood**).

On the **PTT & CAT Interface**, click on the **Details** button to open the following form (Figure 172):

[The rest of this page has been left blank intentionally]




*Figure 172: MixW Serial Port Settings*

Recall that we are using the COM6-COM16 virtual COM port pair and that we setup PowerSDR to connect to the COM6 end of this pair (see the CAT Control Setup section above). We therefore now select **COM16** as the **Port** in the form above. Set the **Baud rate** to **115200** (it makes no difference what you set this to).

For **RTS** and **DTR** we need to match the settings on the PowerSDR Setup Form, Keyer Sub-Tab. Therefore set **RTS** to **CW** and **DTR** to **PTT** as shown above. Click **OK** on this form and then on the **PTT & CAT** form respectively to accept the settings and close the forms.

On the MixW front console, click again on **Configure** on the menu bar and this time select **Sound device settings...** to open the following form (Figure 173):

[The rest of this page has been left blank intentionally]



*Figure 173: MixW Sound Device Settings*

Recall that we previously created two virtual audio cables and then configured the PowerSDR VAC Input as Virtual Cable 1 In and Output as Virtual Cable 2 Out.


We now need to connect MixW to the other ends of those two virtual audio cables respectively. Therefore, set **Device** to **Computer sound card**, **Input** to **Virtual Cable 2** and **Output** to **Virtual Cable 1** as shown in Figure 173 above. If you change the **Sample rate** setting, MixW will tell you to exit and restart MixW.

Exit MixW for now so we can illustrate the functioning of the virtual audio cables.

Click the **Start** button to turn PowerSDR on and make sure MixW is running. When you now view the VAC Control Panel it will look like Figure 174 below:

[The rest of this page has been left blank intentionally]





*Figure 174: VAC Control Panel: PowerSDR Running and MixW Receiving*

Notice that the value in the **Rc Stream** for Cable 2 has changed for a 0 to a 1. This indicates that cable 2, which is the input for MixW is actively receiving audio from PowerSDR. The **Pb Stream** value for VAC Audio Cable 1 is still 0. This will not change to a 1 until you start transmitting and MixW is sending audio through that cable.

Change the mode in MixW to CW. Click on the **TX** button on MixW's main panel. It should key PowerSDR without generating a tone. Click **RX** in MixW and PowerSDR should return to receive. If you have entered your callsign in MixW, click on the **CQ** button. It should key the radio and produce Morse code calling CQ with your call sign. Close the VAC Control Panel; you will no longer need this, unless you intend to create more audio cables.

### ***Programs Needing to Connect to the Default Sound Device***

Certain digital programs can only select the default sound card (or at best choose a single card by index). For example, MMTTY and MMSSTV choose by index. To enable PowerSDR to work with these programs you will need to change the system default sound card. VAC offers the ability to continue to use your other audio applications through its **Audio Repeater** utility, which we will now discuss.

To change the default sound card, in Windows click Start and then Control Panel. In Control Panel, double-click on **Sounds and Audio Devices** to open the Sounds and Audio Devices Properties Form (Figure 175):

[The rest of this page has been left blank intentionally]






*Figure 175: Sounds and Audio Devices Properties Form*

Set up the **Default device** for **Sound playback** and **Sound recording** as shown above. (Midi playback is of no concern). Click **Apply** and then **OK**. If you now setup your digital program to select the default sound card, it will work with PowerSDR.

To enable you to continue using other sound programs (MP3 players, etc) despite changing your default sound card settings, VAC comes with a utility called **Audio Repeater**. Locate Audio Repeater in the VAC program folder and double-click to start it. You should see the following screen (Figure 176):

[The rest of this page has been left blank intentionally]



*Figure 176: Audio Repeater Utility*

To play back audio, set **Wave in** to **Virtual Cable 1 In** and **Wave Out** to the sound card you wish to use. You should keep the **Total buffer (ms)** as small as practicable to prevent long latency between the sound arriving at the virtual audio cable and it being played to the sound card.

[The rest of this page has been left blank intentionally]

# Specifications and Architecture

Specifications are subject to change without notice or obligation, and specifications are guaranteed only within the amateur radio bands.

## **FLEX-5000A and FLEX-5000C Transceiver Specifications**

Table 14 on page 196 displays an overview of the specifications for the FLEX-5000A and the FLEX-5000C transceiver.

[The rest of this page has been left blank intentionally]

Table 14: Overview of FLEX-5000A Specifications

General	
Receiver Frequency Range	10 kHz – 65 MHz (operating – requires external, customer provided filters below 1.8 MHz to eliminate images); 160m – 6m (specified Amateur bands only)
Transmitter Frequency Range	160m – 6m (specified Amateur bands only)
Frequency Stability	±0.5 ppm 32 °F to 122 °F (0 °C to +50 °C)
Operating Temperature Range	14 °F to 122 °F (–10 °C to +50 °C)
Emission Modes	A1A (CW), A3E (AM), J3E (LSB, USB), F3E (FM), F1B (RTTY), F1D (PACKET), F2D (PACKET)
Frequency Steps	1 Hz minimum
Antenna Impedance	50 Ohms, unbalanced 6 - 1000 Ohms, unbalanced (With Optional Tuner ON, 160m - 10m Amateur bands) 16 - 150 Ohms, unbalanced (With Optional Tuner ON, 6m Amateur band)
Max Rating TX1-3 Key Lines	50V, 400mA
Audio In/Out	Unbalanced: 10dBV nominal (consumer level), Input Impedance: 5k Ohms Output Impedance 600 Ohms Balanced: +4dBu, Input Impedance >50k Ohm
Recommended Headphones	40mW, 16 Ohms, 1% THD+N; higher impedance headphones will also work
Frequency Reference Input	0 to +10dBm required
Power Consumption	Rx 1.5A (typ); Tx (100 W) 25A (max.)
Supply Voltage	DC 13.8 V ± 10%
Maximum Interconnect Cable Length	10 feet (3m), No restriction on DC cable within voltage tolerance limits under load.
Special EMI/RFI Requirements – CE Compliance Cable Requirements	1 snap on ferrite bead on DC cable (supplied), 2 snap on ferrite beads on FireWire cable (supplied), and 1 snap on ferrite bead on FlexWire cable. All beads to be located adjacent to rear panel of radio.
Dimensions:	FLEX 5000A: (WxHxD): 9.3" x 9.0" x 12.4" (23.5cm x 22.9cm x 31.6cm) FLEX-5000C: (WxHxD): 17.7" x 9.0" x 14.7" (44.9cm x 22.9cm x 37.3cm)
Weight (approx.):	FLEX-5000A: 13 lbs (5.9 kg); FLEX-5000C: 34 lbs (15.4 kg)
Receiver	
Circuit Type	Direct conversion, low IF
Intermediate Frequency	Software selectable from DC to 20 kHz
MDS	14 MHz Preamp off/on: 1.3/0.3 µV; MDS: -123 dBm/-133 dBm in 500 Hz BW
IP3	+30 dBm at 14 MHz with preamp off at 2 kHz or less tone spacing (S5 IM3 method)
Selectivity (–6/–60 dB)	CW: 500 Hz –6/–60 dB: 5.00/6.40 SSB: 2.4 kHz –6/–60 dB: 2.39/2.54 AM: 6.6 kHz –6/–60 dB: 6.60/6.74
Image Rejection	70 dB or better (160 - 6m Amateur bands)
Transmitter	
Power Output	1-100 watts PEP CW and SSB (25 watts AM carrier)
Power Out XVTR	up to +5dBm adjustable
Emission Modes	A1A (CWU, CWL), J3E (USB, LSB), A3E (AM), F3E (FM), DIGITAL
Harmonic Radiation	Better than –55 dB (160 - 10m Amateur bands) Better than –65 dB (6m Amateur band)
SSB Carrier Suppression	At least 55 dB below peak output
Undesired Sideband Suppression	At least 55 dB below peak output
Audio Response	(SSB): Flat Response 10 Hz to 20 kHz, 3-band or 10-band Software EQ
3 <sup>rd</sup> Order IMD	Better than 33 dB below PEP @14.2 MHz 100 watts PEP
Microphone Impedance	600 Ohms (200 to 10 kOhms)
Balanced Line In Impedance	600 Ohms (200 to 10 kOhms)

## FLEX-5000C Embedded Computer Specifications

Table 15 displays an overview of the specifications for the embedded computer in the FLEX-5000C.

*Table 15: FLEX-5000C Embedded Computer Specifications*

<b>Hardware</b>	
<b>Motherboard</b>	High performance Mini-ITX, incorporating mPGA478 socket, which is able to accommodate a wide range of Intel® Core 2 Duo™ Processors. Front Side Bus 533/667 MHz Intel 945GM + Intel ICH7R chip set Intel GMA950 graphic controller on board Dual independent display support (two DVI interfaces) DDR2 memory support SATA 150/300 IDE memory controllers 10/100/1000 Mbps Ethernet ports USB 2.0 ports External RS232C serial port IEEE 1394 FireWire ports
<b>Processor</b>	Core 2 Duo x86 processor (installed)
<b>Memory</b>	1 GB dual-channel DDR2 (installed)
<b>Hard Drive</b>	160GB SATA/150 (installed)
<b>Keyboard and Mouse</b>	Wireless keyboard and mouse supplied
<b>Monitor(s)</b>	External (not supplied); VGA or (dual) DVI; Resolution: 1024 x 768 min/2048 x 1536 max
<b>Software</b>	
<b>Operating System</b>	Windows XP Professional
<b>PowerSDR</b>	Latest version installed
<b>Other</b>	Collection of Ham Radio Software installed, including vCOM virtual serial port software

[The rest of this page has been left blank intentionally]



## Declarations of Conformity

### FCC

The FLEX-5000 complies with FCC Part 97 rules for the Amateur Radio Service.

### EU Compliance



### European Union Declaration of Conformity

FLEX-5000A Amateur Radio Transceiver Series

Council Directive --- 89/336/33c; EMC Directive

Standards: EN 301 489-1

EN 301 489-15

EN 301 783-1 Essential Radio Test Suite

TYPE OF EQUIPMENT: Amateur Radio Base Station

EQUIPMENT CLASS: B

WE, THE UNDERSIGNED HEREBY DECLARE THAT THE EQUIPMENT SPECIFIED ABOVE CONFORMS TO THE ABOVE STANDARDS PER 89/336/EEC.

FlexRadio Systems Date of testing: August 23, 2007

FlexRadio Systems  
8900 Marybank Drive  
Austin, TX 78750

[The rest of this page has been left blank intentionally]

## Buffers and Sample Rate

Rather than a theoretical discourse on the consequences of Buffer Size and Sample Rate settings, this appendix will attempt to illustrate how these settings effect both the minimum possible filter bandwidth, filter slope or steepness and latency for each of the settings available in PowerSDR. We will start with the filter effects and then move on to latency. Finally a little underlying theory is offered to help gain some more insight without the need to delve into a DSP tomb.

### Filter Effects

The minimum filter width possible at a given DSP Buffer Size  $N$  and a Sample Rate  $f_s$  equals  $1.5 \cdot f_s / N$ , where the factor 1.5 is due to the additional roll-off due to the Blackman-Harris window function. Therefore, for the steepest and narrowest filters we want a low Sample Rate and a high DSP Buffer Size. Exactly how this effects the filter shapes is shown on the following two pages in Figure 178 through 180 for a 2.7kHz LSB filter and in Figure 181 through 183 for a 25Hz CW filter.

It is clear that as the Sample Rate increases and/or the DSP Buffer size decreases, the filter skirts become less "brick-wall" and more "roll-off", thus reducing a filter's effectiveness.

[The rest of this page has been left blank intentionally]






Figure 178: 2.7kHz LSB Filter at 48kHz Sampling Rate




Figure 179: 2.7kHz LSB Filter at 96kHz Sample Rate




Figure 180: 2.7kHz LSB Filter at 192kHz Sample Rate




Figure 181: 25Hz CWL Filter at 48kHz Sample Rate




Figure 182: 25Hz CWL filter at 96kHz Sample Rate




Figure 183: 25Hz CWL Filter at 192kHz Sample Rate

## Latency Effects

The latency in the system will be at least equal to the minimum of the Audio and DSP Buffer Sizes divided by the Sample Rate. Because both the DSP Buffer and the Sample Rate also determine the minimum filter width, setting the Audio Buffer as small as your computer system will tolerate is preferable. That way, latency will not be unnecessarily long. If latency is an issue with your computer system, you may have to resort to a smaller Buffer Size and/or a higher Sample Rate than you would otherwise prefer based on filter shapes.

## Underlying Theory

To transform signals from the time domain to the frequency domain we start with the Discrete Fourier Transform (DFT), which is the Fourier Transform for time sampled signals (The FFT or Fast Fourier Transform is an efficient algorithm to calculate the DFT). It is important to realize that the result of the DFT is a continuous function of the frequency, from  $-\infty$  to  $+\infty$ . The annoying thing about this transform, however, is that it needs to "know" the temporal signal over a time domain of  $\pm\infty$ . Needless to say, this is not practical.

We can limit the time domain  $T$  to a limited number of samples (equal to the "slice" of time represented by the **DSP Buffer**) if we assume the temporal signal to repeat continuously, with a period  $T$ . The result is, however, no longer a continuous function of the frequency, but a discrete function, that is, the power spectrum is only calculated at frequency intervals equal to  $1/T$ . These discrete frequencies are called *bins*. These bins can be envisioned as a series of  $1/T$  Hz wide parallel filters, spaced every  $1/T$  Hz. Each bin "fills" with the average power at its center frequency and averaged over  $1/T$  Hz. The frequency resolution is therefore limited to  $1/T$  Hz.

- Because we assume the time domain signal at hand to repeat with period  $T$ , any discontinuity between the last sample in a buffer and the first sample in the next buffer will violate this condition. To understand this, it helps to know that the result of an FFT is complex, including magnitude and phase information (this is even true if the temporal signal is real). In other words, rather than on a straight line, the FFT writes the data on a circle in the complex plane, where one revolution represents  $N/T$  Hz ( $N$  being the number of samples in the DSP Buffer). When the last sample in the DSP Buffer meets the first sample in the next DSP Buffer, chances are they will not meet in a continuous fashion. Any discontinuity will lead to a wide associated spectrum across multiple bins, a phenomenon known as "bleed-through".
- Another way of looking at this is that a signal with period  $T$  (and any harmonic thereof), can be represented as a combination of its fundamental frequency  $1/T$  Hz and higher order harmonics, all spaced at multiples of its fundamental frequency. These spectral components are therefore at the center of each FFT bin. If on the other hand, the temporal signal does not have a periodicity equal to (an integer multiple of )the fundamental frequency, it's spectral components will not be centered on each bin and bleed through will occur from one bin to the next, resulting in a loss of frequency resolution.
- To avoid this happening, the samples in the DSP Buffer are first multiplied by a window function (see page 102 and Appendix D), such that the spectral smearing is limited, but it is not completely eliminated. Each window function has advantages and disadvantages depending on the situation at hand. For our purposes, the Blackman-Harris window offers the best trade-off between loss of frequency resolution and stop-band characteristics.

The time slice  $T$  that the DSP buffer represents, often called the FFT size, equals the number of samples it can hold (the Buffer size  $N$ ) divided by the **Sample Rate**  $f_s$ , e.g. if the Buffer size equals 1024 and the sample rate 96kHz, the DSP Buffer represents a time slice of  $1024/96\text{kHz} = 10.67\text{ms}$ .

- ❑ If a signal suddenly appears, we will need to wait until the Buffer is filled, at which time it can be processed by the FFT. Waiting for the buffer to fill limits our resolution in the time domain (we have to wait  $T$  seconds). This temporal resolution is also known as latency: a high temporal resolution equals a low latency. To decrease our latency (increase our temporal resolution), we therefore need to keep  $T$  **small** by either reducing the Buffer size or increasing the Sample Rate, or both.
- ❑ However, we have already seen that the frequency resolution equals  $1/T$  Hz (ignoring effects due to windowing). Therefore to increase frequency resolution, we need to increase  $T$  as much as possible by using a **large** Buffer Size and a low Sample Rate. It is this frequency resolution that determines the possible steepness and narrowness of our filters. A higher resolution enables steeper and narrower filters.
- ❑ Clearly we cannot have both a high temporal and a high frequency resolution. We must make a trade-off by setting the temporal resolution (latency) to an acceptable level and accepting the resulting frequency resolution (minimum filter width).

[The rest of this page has been left blank intentionally]

# Updating the Flex-5000 Firmware

## Automatically

This procedure outlines how to update the FLEX-5000 Firmware using a software utility called [FlexLoader](http://support.flex-radio.com/Downloads.aspx?fr=1) (courtesy of K3NC; search for *flexloader* on the downloads page of our website at <http://support.flex-radio.com/Downloads.aspx?fr=1>). FlexLoader is a radio firmware management program, that facilitates Firmware updates for the FLEX-5000. FlexLoader comes with its own built-in Help files, which explain in detail how to use it.

On startup, FlexLoader automatically checks all the Firmware versions that have been made available and recognizes whether any have not previously been saved to the computer. If any are found, it requests whether or not to download these. (To make sure that a downloaded file is correct and has not be modified in any way, each file has a 128 bit cryptographic MD5 checksum generated and checked prior to using it.) After a brief moment, it then makes all the downloaded versions available through a drop-down list box. The user selects which version to install and FlexLoader takes care of the rest.

## Manually

The procedure below outlines how to manually update the FLEX-5000 Firmware.

### Download and Extract the Firmware

The most current version of the FLEX-5000 firmware can be downloaded as a zip-file from the Downloads page on our website, at <http://support.flex-radio.com/Downloads.aspx?id=171>.


**Note:** If you need to revert to an earlier version of the firmware, search for *firmware* on the Downloads page of our website at <http://support.flex-radio.com/Downloads.aspx?fr=1> and select the version you are seeking from the list.

Save the zip-file to a location on your computer, extract it and then open it. Inside you will find four files. Open the text file labeled **FLEX-5000\_Firmware\_ReadMe.txt** to verify you have the correct firmware version. This file also contains instructions on how to update the firmware. Close the file when you have finished reading it.

## Update the Firmware

To update the firmware, power-up the FLEX-5000, make sure it is communicating with your computer. You can verify this by successfully opening the FLEX-5000 Driver Control Panel. Close this Control Panel if you opened it.


Next, locate the batch file labeled **Burn.bat** in the firmware folder (the same folder containing the ReadMe file) and double-click on it to open the window shown in Figure 184 below.



*Figure 184: Burn.bat Initial Screen*

Press any key to continue and you will subsequently receive the message **Uploading Binary**, followed by **Deleting Flash Image** and then **Programming Flash Image**, each preceded by a progress counter. When the upgrade is completed successfully you will hear the relays click and see the screen shown in Figure 185 below.

[The rest of this page has been left blank intentionally]




*Figure 185: Burn.bat Final Screen*

**Note:** If you do not hear the relays click, switch off the FLEX-5000 and then switch it on again. Start up PowerSDR and if you do not get a firmware version error message (see Figure 26 on page 43) all is well. If you do get the error message, try updating the firmware again following the procedure described above.

[The rest of this page has been left blank intentionally]

## Optimizing the AGC

To gain an understanding of how to set the AGC-T or Max Gain control it is helpful to think in terms of signal levels instead of gains. Figure 186 shows the input and output signal levels (pre and post AGC) at various settings of the Max Gain control with the Slope set to zero.



*Figure 186: Input and Output Signal Levels at Various Max Gain Settings*

For example (assuming the preamp is off) the violet line (with a Max Gain setting of 60dB) shows that as the level of the input signal into the AGC increases from -121dBm (S1) to -73dBm (S9) the level of the output signal out of the AGC increases from -61dBm (-121dBm + 60dB) to -13dBm. For input signal levels higher than -73dBm, the output level remains constant at -13dBm because we have set the Slope to zero. The input signal level at which the output just reaches the maximum of -13dBm is known as the AGC Threshold (this is different from the Hang Threshold).

If the Max Gain setting is increased, say from 60dB to 78dB (the blue line), the output signal level reaches its maximum at a lower signal level. For a Max Gain of 78dB, the AGC Threshold is at -91 dBm



(S6). If the preamp is turned on then that raises the input signal level into the AGC by 14dB. To keep the Threshold at -91dBm, we therefore need to reduce the Max Gain by the same 14dB to 64dB.

To obtain the most optimal Max Gain setting it is important to know where the Threshold is in relation to the desired input signal.

- ❑ If the Threshold is placed far to the right of the desired signal's input level (Max Gain is too low) then you may not be able to copy a weak signal. Also a suddenly appearing strong signal may blow your ears off.
- ❑ If the Threshold is placed far to the left of the desired signal's input level (Max Gain is too high) then the desired signal will sound as loud as the noise, because you have amplified everything up to the -13dBm level. In other words, you have destroyed your signal to noise ratio.
- ❑ If the Threshold is placed at or just above the desired signal's input level you will have amplified it to the maximum attainable without destroying the signal to noise level. A (suddenly appearing) much stronger signal will be kept at about the same output level as that of the desired signal and your ears will be thankful. If the desired signal is a very strong signal, the benefit will be that its output level can be reduced, thus also reducing the noise level.


[The rest of this page has been left blank intentionally]

# Window Functions

In the following we will consider some of their characteristics, where we assume  $N$  to equal the number of samples in the DSP Buffer and  $n$  to be an integer with  $0 \leq n \leq N-1$ .

- **Rectangular:** This means the data has no window applied. No shaping is applied to the incoming signal. As a result, you will have the greatest sensitivity in the power spectrum and the greatest bleed through or interference with adjacent bins.

$$w(n) = 1$$




*Figure 187: Rectangular Window Function and Frequency Response to a Sinusoid*

[The rest of this page has been left blank intentionally]


- **Hanning, Hamming:** These windows are based on a raised cosine shape. In addition to providing continuity (Hanning) or near continuity (Hamming), both provide a shape that makes the slopes of the signal agree at the beginning and the end of the signal buffer. This filter provides for both good sensitivity and less bleed-through in the FFT. In situations of low dynamic range requiring a higher spectral resolution, such as (weak signal) CW using the narrowest filters.

- Hanning (also known as Hann):  $w(n) = 0.5 \left( 1 - \cos \left( \frac{2\pi n}{N - 1} \right) \right)$



**Figure 188: Hanning Window Function and Frequency Response to a Sinusoid**

- Hamming:  $w(n) = 0.53836 - 0.46164 \cos \left( \frac{2\pi n}{N - 1} \right)$



**Figure 189: Hamming Window Function and Spectral Response to a Sinusoid**



- **Blackman, Blackman-Harris and Blackman Nuttall:** We use Blackman-Harris to design all filters in the signal processing chain for all modes. This provides for minimal bleed through as we have described and the best shape factor for our needs in the overlap-save filtering routines. While it has some good features, these features are probably not ideal for the CW power spectrum displays. There is a penalty to pay for the smoothing near the ends afforded by the windows. If you have experience in the use of FFTs and the display of the power spectra that result, you know that a smaller FFT (smaller DSP Buffer) at a fixed sample rate causes a wider range of frequencies to be contained in one bin of the power spectral results. This means that a tone will look more like a large lobe or finger than a tone spike. The same phenomenon is present in the best windows. While the spreading of the "main lobe" of a tone is not as bad as taking an FFT of half the size, it is wider than one bin (see also Appendix A). The formulas for all of the Blackman filters are of this form:

$$w(n) = a_0 - a_1 \cos\left(\frac{2\pi n}{N-1}\right) + a_2 \cos\left(\frac{4\pi n}{N-1}\right) - a_3 \cos\left(\frac{6\pi n}{N-1}\right)$$



The individual parameters by type:

- Blackman:  $a_0 = 0.42$ ,  $a_1 = -0.5$ ,  $a_2 = 0.08$ ,  $a_3 = 0$
- Blackman Harris:  $a_0 = 0.35875$ ,  $a_1 = 0.48829$ ,  $a_2 = 0.14128$ ,  $a_3 = 0.01168$
- Blackman Nuttall:  $a_0 = 0.3635819$ ,  $a_1 = 0.4891775$ ,  $a_2 = 0.1365995$ ,  $a_3 = 0.0106411$
- Their graphical representations are shown in Figure 187 through 188 respectively:



[The rest of this page has been left blank intentionally]



**Figure 190: Blackman Window Function and Frequency Response to a Sinusoid**



**Figure 191: Blackman-Harris Window Function and Frequency Response to a Sinusoid**



**Figure 192: Blackman-Nuttall Window Function and Frequency Response to a Sinusoid**

- **Parzen, Bartlett, Exponential, and Riemann:** These windows are much less widely used and are included for completeness. They sometimes perform better for a particular application and some experimentation on the users part should be undertaken to find the window that gives the most pleasing display to you.

For further reading on windowing, including many more examples of window functions, please see [http://en.wikipedia.org/wiki/Window\\_function](http://en.wikipedia.org/wiki/Window_function).

[The rest of this page has been left blank intentionally]